

DAILY TURBODAILY TURBODAILY 4x4


| | | |
|------|-----------|---------|
| 30.8 | 30.10 | |
| 35.8 | 35.10 | 35.12 |
| | 35.10 EDC | |
| | 35.10 W | |
| 40.8 | 40.10 | 40.12 |
| | 40.10 W | |
| | A 40.10 | A 40.12 |
| | 45.10 | A 45.12 |
| | A 45.10 | |
| | 49.10 | 49.12 |
| | A 49.10 | |
| | | 59.12 |

Repair Manual Electrical/electronic system

Update for manual
Print n°. 603.42.961

Print n°. 603.42.961/A

INTRODUCTION



This manual is produced by our Technical Publications Department for use by Technicians to assist in carrying out repairs or maintenance work and provide a better knowledge of IVECO products.

With the introduction of the new Daily/Turbodaily/Turbodaily 4x4 range our efforts have been devoted at improving the electrical system literature as a whole. It now includes this present manual entitled "ELECTRICAL/ELECTRONIC COMPONENTS" and a further manual entitled "ELECTRICAL/ELECTRONIC EQUIPMENT".

This manual provides comprehensive written and graphic information which is the result of thorough research work. It is not nor does it set out to be an exhaustive survey of electrical equipment, since the experts in this field are already familiar with the complex and specific nature of such products, but it is limited to the essential, relevant documentation that a motor vehicle electrical repair workshop must have available for information on electrical equipment, so that it can carry out its work properly.

The "ELECTRICAL/ELECTRONIC COMPONENT" manual is therefore a valuable source of information for electrical components, covering such areas as removal and refitting, inspection, bench testing, numerical codes, cable colour codes, etc. It is specifically intended for use by qualified electrical engineers.

The other manual, "ELECTRICAL/ELECTRONIC EQUIPMENT", which complements this manual, covers each individual model of the vehicle range in question and contains full circuit diagrams and descriptions of the respective electrical systems.

TABLE OF CONTENTS

| | CHAPTER |
|-------------------|---------|
| GENERAL | |
| ELECTRICAL SYSTEM | I |
| STARTING | II |
| BATTERY CHARGING | III |
| INSTRUMENTS | IV |
| LIGHTS | V |
| SIGNALS | VI |
| SERVICES | VII |
| SPECIAL CIRCUITS | VIII |
| INDEX | IX |

GENERAL

| | Page |
|---|------|
| GENERAL | 9 |
| GRAPHIC SYMBOLS USED IN THIS MANUAL | 10 |
| GENERAL INSTRUCTIONS | 11 |
| GENERAL INSTRUCTIONS CONCERNING ELECTRONIC COMPONENTS | 12 |
| EARTH CONCEPT AND ELECTROMAGNETIC COMPATIBILITY | 13 |
| READING KEYS | 15 |

GENERAL

Composition of the manual

This manual consists of the section "GENERAL" plus nine chapters identified by Roman numerals, as follows:

Chapter I -- POWER NETWORK

Chapter II -- STARTING

Chapter III -- CHARGING

Chapter IV -- INSTRUMENTS

Chapter V -- LIGHTS

Chapter VI -- SIGNALS

Chapter VII -- SERVICES

Chapter IX -- SPECIAL CIRCUITS

Chapter X -- INDEX

All subjects covered in this manual are correct at the time of its preparation. This practically corresponds to the date of printing.

Each chapter has its own progressive page numbering system to make future updates easier: Pictures have a double numbering system: the first figure refers to the chapter number while the second one is a progressive number; this way, pictures can be easily traced in case a cross reference is needed.

In the following pages you will find the key that will help you read the information contained in this manual.



On reading through this manual you will find a special information entitled "Simplified diagnosis" (above the component diagram, see page II.28 as an example). This information is meant to facilitate circuit diagnosis as described on page I.52. The electrical network to which the component under examination belongs is to be looked for in the "Electric/electronic System" manual, print no. 603.42.961.

Unless otherwise specified, simplified diagnosis tests should be carried out on a vehicle in the following condition: engine switched off, parking brake engaged and transmission in neutral.

Graphic symbols and abbreviations used in this manual

| | | | | | |
|---|--|---|--|----------|-------------------------------|
|  | Warning |  | Component identification numbers/letters | NA | Normally open |
|  | Warning relating to electronic equipment | 52502 | Component code | N.B. | Note |
|  | Chassis and/or body earth connection | A | Ampere | NC | Normally closed |
|  | Refer to | ABS | Wheel antilock system | SU | Ultrasound welding point |
|  | Analogue check | EDC | Electronic injection control device | TGC | General current relay |
|  | Digital check | ET | Engine Tester | V | Volts |
|  | Component supplier/manufacturer | ISO K/L | Programming and diagnosis serial line | 0Ω | Zero Ohm (circuit continuity) |
|  | Identification of a component and electronic control units | IT | Iveco Tester | – 7777 – | Cable colour code |
|  | Symbol identifying an electric function | MI | Earth point: M = Earth I = Identification number | | |
|  | Vehicle model | MO | Workshop Manual | | |

N.B. Technical data and component specification given in this manual are supplied by way of example and must be checked on the test bench.

General instructions



NEVER DISCONNECT THE BATTERIES FROM THE SYSTEM OR OPEN THE ISOLATING SWITCH WITH THE ENGINE RUNNING.

ALWAYS CONNECT THE BATTERIES IN A PERMANENT WAY PRIOR TO STARTING THE ENGINE.

Before carrying out any servicing operation on the vehicle, chock the wheels securely to prevent the truck from moving on its own.

Do not use quick charging devices to start the engine. Enginestarting should be performed only by means of separate batteries or a suitable trolley.

- Ensure correct polarity of battery terminals when starting the engine by means of an auxiliary trolley.
- Incorrect polarity of electronic control unit input voltage (i.e. incorrect polarity of battery terminals) can lead to electronic module breakage.

When disconnecting the batteries from the system, always disconnect the chassis earth cable from battery negative terminal first of all.

Before connecting the batteries, make sure the system is properly isolated.

When tracing the cause of a circuit failure, place a spare fuse between the battery negative terminal and the chassis earth cable (main current breaker on).

Before removing electrical/electronic components, disconnect the earth cable from the battery negative terminal.

When tracing the cause of circuit failure, place a spare fuse between the battery negative terminal and the chassis earth cable (main current breaker on).

Before removing electrical/electronic components, disconnect the earth cable from the battery negative terminal.

Disconnect the battery from the system when recharging it from an external source.

Disconnect external battery charger from mains supply before disconnecting it from the battery terminals.

Never connect/disconnect the electronic module jack when the input line is alive.

Dismantle electronic control units when working with temperatures over 80°C (drying oven).

While performing electrical welding on the chassis, disconnect connectors from electronic control modules.

- Always use the specified tightening torque data in connector nuts (temperature, pressure sensors, etc.).



Measurements on electronic modules controlling plugs, plug connections and electrical connections to components must be taken using exclusively the specified testing lines and plugs. Under no circumstances should metal wires, screwdrivers, clips or other similar devices be used. In addition to short circuit risks, this could cause damage to plug connections with consequent contact problems.

General information on electronic components

- Before disconnecting the electronic module jack make sure the system is properly isolated (ref. A fig. on this page).

Do not generate sparks when testing voltage presence in a circuit.

Do not touch connector plugs of electronic modules with your hands.

Do not use a test lamp to check circuit continuity. Use exclusively the specified testing equipment (ref. B).

Do not supply electronic unit assisted components with the vehicle nominal voltage.

- Do not plug meter terminals into electronic module sockets. Measurements should be taken using the UNITESTER equipment only. (ref. C).

Make sure the harness pertaining to electronic devices (length, cable type, label band position, braided wire connection, earthing, etc.) is in compliance with the IVECO system and is properly restored after any servicing operation has been carried out. To avoid damage to electronics on board the vehicle, ensure the wiring pertaining to additional equipment follows a different route.





Use IVECO original spare parts only.

Do not install electrical/electronic equipment not approved by IVECO or not authorized by the local legislation.

Do not connect negative poles of additional equipment to negative poles of electronic modules.

- While performing electrical welding on the vehicle, disconnect all electronic modules and/or the battery positive terminal power cable and connect it to the chassis earth (ref. D).

- Remove all electronic modules and components when drying paints in a furnace.



Earth concept and electromagnetic compatibility

The standard system is traditionally a single-pole system. The body, chassis, metal container of electromechanical components act as equipotential return conductor to the generator; since any point of the metal structure or any unisolated negative terminal is at the same potential or EARTH. This is why the earth has been chosen as the reference for the entire system, conventionally giving it a rating of 0.

For obvious constructive reasons, different earth points scattered over the vehicle according to the location of the components influence the system in the negative network.

Ideally, all the equipment should be connected to **only one** earth point to warrant a clearly defined earth reference, especially for the electronic devices.



Due to the above mentioned reasons, the **supply earth** or system earth characterised by strong direct current intensity ($> 1\text{ A}$ for electromechanical components) must be distinguished from the **analogue earth** characterised by wave shapes at determinate frequencies and with very small current intensities ($\text{mA}, \mu\text{A}$) of the electronic/numerical systems.

The definition of signal earth or analogue earth depends on the sensitivity of the electronic systems to EMC (electromagnetic compatibility) since parasite signals induce malfunctioning and/or deterioration of the actual systems (as they are emitted by systems on board and/or outside the vehicle).

In order to minimise continuous or transient disturbances or interferences caused by parasite radiations, it is of the **utmost importance** to bear in mind all the time that the soundness of the reference plan or system earth depends on the excellent conduction features (contact resistance tending to zero) in each of its connecting points.

To sum up we can say that earth intended as equipotential electric conductor, i.e. as potential reference of all the electric/electronic components on board, is subdivided into system earth and analogue earth.

Earth points (M1, M2, M3 etc) are established by the manufacturer and must obviously be free from paint, oxidation, grease, dust etc.



- 1 EARTH CONNECTIONS: A. EFFICIENT EARTH POINT B. INEFFICIENT EARTH POINT
- 2 FASTENING SEQUENCE: A. SCREW B. WIRE TERMINAL C. WASHER D. NUT
- 3 EARTH CONNECTION

When refitting the earth wires to the chassis, thoroughly remove the old conductive paint and apply a new even coat of BH44D or Kontaktolon paint, proceeding as described below:

1. Chemically or mechanically remove the paint on both chassis and terminal.
2. Apply the paint with a brush or a sprayer.
3. Connect earth wires within 5 minutes from paint application.
4. If mounting a new earthing contact, file the chassis anaphoresis paint around the terminal clamp fixing hole and prepare a smooth supporting surface.

Reading key

| | | | | | |
|---|--|---|---|--------------------------------------|---|
| COMPONENT UNDER EXAMINATION - FAULT DIAGNOSIS PROCEDURE | 12V/5 THE VEHICLE'S NOMINAL VOLTAGE (OPERATING VOLTAGE IS 14V APPROX.) | COMPONENT UNDER EXAMINATION - WIRING SYSTEM - CONNECTIONS | COMPONENT UNDER EXAMINATION - INNER WIRING SYSTEM | GRAPHIC REPRESENTATION OF MULTIMETER | COMPONENT UNDER EXAMINATION - CODE NUMBER |
|---|--|---|---|--------------------------------------|---|

Electronic rev Counter Sender unit


SIMPLIFIED DIAGNOSIS

Disconnect connector [A] from component under examination.

Set multimeter to Ω HM.

- Check for 0Ω by setting one multimeter prod to terminal 1 of connector [A] and the other one to terminal 3 of combined module connector A (page N3).
- Check for 0Ω by setting one multimeter prod to terminal 2 of connector [A] and other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no 60342961 Diagram no 3

48030




NUMERICAL CODE OF COMPONENT UNDER EXAMINATION

COMPONENT UNDER EXAMINATION - LOCATION ON WIRING DIAGRAM

MULTIMETER POSITIVE PROD

MULTIMETER NEGATIVE PROD



Electronic rev Count

SIMPLIFIED DIAGNOSIS

Disconnect connector [A] from

Set multimeter to Ω HM.


- Check for 0Ω by setting
- for [A] and the other one
- A (page N3).
- Check for 0Ω by setting
- for [A] and other one to ea

If readings are other than sp

the circuit or replacing the co


FUNCTION CONNECTED TO COMPONENT UNDER EXAMINATION - COMPLETE WIRING SYSTEM

Key to components described in chapters II – III – IV – V – VI – VII – VIII



LAYOUT WITH ELECTRICAL CONNECTIONS

Key to components described in chapter VIII (ABS/ASR, EDC etc. electronic control units)



LAYOUT WITH ELECTRICAL CONNECTIONS

Key to component characteristics and possible faults

COMPONENT TRADE MARK (MANUFACTURER/SUPPLIER)

COMPONENT IDENTIFICATION LETTERS/NUMBERS

76

Daily/Turbodaily/Turbodaily 4x4

STARTING 11.5

Batteries

Specifications

MODEL TYPE



SIZE

MARELLI

12V-88Ah-395A

Daily



SIZE

MARELLI

12V-95Ah-450A

Turbodaily



SIZE

DELCO

12V-102Ah-RC310A

Turbodaily (either right-hand drive or fitted with air-conditioning system)



SIZE

MARELLI

12V-110Ah-450A

Turbodaily (either bus version or fitted with optional extras)


Quick diagnosis

POSSIBLE FAILURES AND REMEDIES


| Defect | Possible cause | Remedy |
|-----------------------------|---|---|
| Starting defect | 1. Discharged battery | Check battery charge. If correct, check recharging circuit. |
| | 2. Terminals loose or oxidized or burnt | Restore terminal efficiency, as required. |
| | 3. Faulty starting circuit | See "Starting" section. |
| Electrolyte level often low | 1. Excessive voltage | Check recharging circuit and/or check if terminals are loose. |
| | 2. Oxidized terminals | Clean or replace. |
| Electrolyte level often low | 1. Excessive voltage | Check recharging circuit and/or check if terminal are loose. |

ELECTRICAL SYSTEM

| | Page |
|---|------|
| ENGINE TYPES | 3 |
| SYSTEM SPECIFICATIONS | 4 |
| LOCATION OF EARTH POINTS ON THE VEHICLE | 6 |
| CABLE ULTRASOUND WELDING | 7 |
| COMPONENTS | 8 |
| CONNECTOR BLOCKS | 10 |
| INSERTING/REMOVING WIRE TERMINALS – HOW TO PROCEED WITH CONNECTOR BLOCKS OF DIFFERENT TYPES | 13 |
| COMPONENT REPLACEMENT INSTRUCTIONS | 26 |
| CIRCUIT DIAGNOSIS | 52 |
| COMMON COMPONENTS | |
| CENTRAL INTERCONNECTING UNIT | 57 |
| STEERING WHEEL SWITCH | 62 |
| DASHBOARD | 64 |
| COMBINED MODULE | 66 |
| CENTRE CONTROL PANEL | 68 |

ELECTRICAL SYSTEM**Engine types**

SUPERCHARGED ENGINE TYPE (8140.23 – 8140.43 – 8140.47)




ASPIRATED ENGINE TYPE (8140.67 F)

SYSTEM SPECIFICATIONS**Daily/Turbodaily vehicles (truck version) – Main electrical data**

The wiring system installed on the various Daily and Turbodaily models is basically the same, with the exception of the following data:

| | |
|--|--------------------------|
| Nominal voltage | 12V |
| Operating voltage | ~ 14V |
| Battery capacity (depending on vehicle model) | 88 Ah 95 Ah 102 Ah |
| Alternator rating (depending on vehicle model) | 55 A 90 A |
| Starter motor rating | 2.2 kW |

**1.2 LOOM LOCATION**


A. HOOD LOOM – B. RH DOOR LOOM – C. ROOF LOOM – D. CAB LOOM – E. LH DOOR LOOM – F. CHASSIS LOOM – G. ENGINE LOOM

Daily/Turbodaily vehicles (Bus version) – Main electrical data

Regardless of optional extras and variants requested by the different countries, the standard wiring system installed on the bus version includes the following components:

- General Current Relay
- Emergency circuit
- Swing sliding door
- Internal lighting


| | |
|----------------------|--------|
| Nominal voltage | 12V |
| Operating voltage | ~ 14V |
| Battery capacity | 110 Ah |
| Alternator rating | 90 A |
| Starter motor rating | 2,2 kW |








1.3 LOOM LOCATION

A. HOOD LOOM - B. CAB LOOM - C. ROOF LOOM - D. CHASSIS LOOM - E. LH DOOR LOOM - F. ENGINE LOOM

Location of earth points on the vehicle



| Earth connection | Location | Components concerned |
|---|--------------------------------------|---|
| <p>M1</p>  | Engine block rh side | Battery negative terminal – Windscreen wipers – Roof components – Cab interior components – Engine cooling electromagnetic joint |
| <p>M2</p>  | Engine block lh side | Earth connection between engine and chassis |
| <p>M3</p>  | Lh side member | Power steering fluid level indicator control device – Horns – Fuel level sender unit – Side marker lights – Brake fluid level indicator control device – Tail external lighting – Telma – |
| <p>M4</p>  | Hood (close to rh headlight cluster) | High/low beam light with rh parking light – Rh front turn signal light – Air cleaner restriction indicator switch – Windscreen washer pump – Engine coolant level indicator |
| <p>M5</p>  | Hood (close to lh headlight cluster) | High/low beam light with lh parking light – Lh turn signal light – Fog lamps |

Cable ultrasound welding

This is the first time that ultrasound welding is used on a commercial vehicle with the purpose of eliminating the considerable number of power and earth jumpers included with other components in its electrical system (fig. 1.4).


Welding points are fitted inside the cable loom and are isolated from other cables by means of heat-shrinking sheaths or insulating plastic material. All component lines meet on one side of the point while on the other side a single wire supplies earth or power connection for all of them (fig. 1.5).

Several welding points can be connected to one another and therefore a number of lines will meet on each side of them.



In this case, the wire assigned the power or earth function will be connected to the last serially-connected welding point (fig. 1.6).

Ultrasound welding enables the following advantages:



- considerable reduction of electromagnetic disturbances from outside the vehicle
- improved reliability of electrical system operation due to the elimination of jumpers and consequent possible system malfunction.




1.4 COMPONENT EARTH CONNECTION
A. CONNECTION VIA JUMPERS B. CONNECTION VIA ULTRASOUND WELDING



1.5 ULTRASOUND WELDING
A. TECHNICAL DIAGRAM B. WIRING DIAGRAM




1.6 CONNECTION BETWEEN ULTRASOUND WELDING POINTS
A. TECHNICAL DIAGRAM B. WIRING DIAGRAM




4995

1.7 CIRCUIT MODULARITY DIAGRAM
A. C.I.U. - B. CAB - C. HOOD - D. ROOF - E. ENGINE
F. CHASSIS



4996

1.8 BIPOLAR COMPONENT
A. C.I.U. B. JUNCTION BLOCK C. COMPONENT
M. EARTH



4997

1.9 SINGLE POLE COMPONENT
A. C.I.U. - B. JUNCTION BLOCK - C. COMPONENT -
M. EARTH

Components

The new electrical system for the Daily/TurboDaily range is designed to guarantee a high level of operational efficiency over a period of time and make the different cables which comprise the vehicle electrical network independent from one another:

The new connections which are sealed against external agents (humidity, water, dust, acid, temperature changes, etc.) considerably reduce both oxidation at electrical component terminals and the possibility of contact to earth due to wire exposure.

Circuit modularity or, better still, the separation of electric cable looms (cab, hood, roof, engine and chassis looms) enable the replacement of one single cable loom without having to remove them all in the event of a circuit fault.

To ensure circuit continuity, the network is connected to the power source on-board the vehicle (batteries) via positive conductors for supply of the various components and negative conductors for current return.

Negative cables are connected to the hood or engine earth points and to the chassis earth depending on component location. Furthermore, a cable connects the engine to the chassis earth to ensure vehicle equipotentiality. Earth point potential as to on-board voltage is the reference potential, that is to say 0 Volt.

N.B. The negative cable of several components is insulated from the chassis earth as this wire is connected to the battery negative terminal.

Figure I.8 shows circuit making to earth for a bipolar component whose terminals are isolated from the component body.

Figure I.9 shows circuit making to earth for a single-pole component whose negative terminal is not isolated from the component body.

The following components feature the above-described property:

- temperature sender unit and engine coolant indicator switch
- variable resistance for ignition timer control
- thermostarter
- engine stopping solenoid
- solenoid valve for connection of fuel tank to atmosphere (thermostarter)
- engine oil pressure indicator switch
- preheating system operation switch

Connector blocks

Cable junction blocks

Figure I.10 shows various connectors with relevant conductors.

Type A connectors are used as junction blocks between the following cable looms:

- hood/engine
- hood/chassis.

The multi cell female junction block (which forms part of the hood cable loom) is fitted with locking tabs designed to secure it to special mountings positioned close to the windscreen wiper motor:



Type B connectors are used as junction blocks between the following cables:

- cab/hood
- cab/doors
- cab/roof
- cab/headlight washer unit
- cab/power windows and adjustable mirrors
- cab/ABS
- ABS/ABS sensors



Type C connectors are used as junction blocks between the following cables:

- hood/electronic tachometer sender unit
- hood/windscreen water and engine oil level indicator switch
- hood/fog lamps
- chassis/heated fuel filter



A




B




C






5004

I.11 CONNECTORS FITTED WITH LOCKING TABS



1397

I.12 PACKARD CONNECTORS - PLASTIC SEALS



1397

I.13 CABLE COLOUR IDENTIFICATION

Connector types and cable section identification

Connectors shown in figure I.11 are fitted with a locking tab to prevent them from loosening due to vibrations. To remove a connector it is therefore necessary to either press or lift the relevant tab.

Packard type connectors are fitted with a plastic seal to ensure protection from external agents (dust, water, etc.). Conductor ends are fitted with seals fastened to the wire terminal (fig. I.12).


Single cables or conductors (with 0.5 mm² copper plait core for signals and 1 mm² or more for supply lines) are insulated with heat and dust/waterproof polyvinyl material.

Polyvinyl insulation also proves very efficient in the prevention of corona and galvanic effects produced by direct current. Such effects cause contact oxidation resulting in voltage drops at the electrical component terminals.


By way of example, we can say that maximum carrying capacity (this may vary from one country to another) at continuous duty is 6A for 0.5 mm² conductors and 11A for 1 mm² conductors.

The heavy type number at the side of the cable colour code identifies, on circuit diagrams, cable sections above 1 mm².


For instance, figure I.13 shows that section of cable 7777 is 6 mm².



1.58 REMOVING BATTERY



1.59 REMOVING MAIN SWITCH



1.60 REMOVING PIN AND FIXING NUT

Component replacement instructions

Battery



Never disconnect the batteries with the engine running.

Cut the battery off the electrical system during the recharging operation.

Before reconnecting the battery ensure the system is properly isolated.

To replace the battery follow the operating sequence indicated below. Remember to cut the battery off the electrical system by means of the main current switch (if fitted). Then:

- Loosen terminal clamps.
- Disconnect power network supply cables. If an isolator switch is not fitted, disconnect the earth cable first and then the positive cable.
- Unscrew both battery clamp nuts from the bracket securing battery to hood (fig. 1.58).

When reinstalling the battery, connect power cables in accordance to polarity to avoid serious damage to on board mains and electronic components.

Main current switch (where fitted)

To replace the main switch comply with the following operation sequence. Remember that the first step to be carried out is to break the circuit. Then:

- Disconnect the cable from the battery negative pole.
- Remove nuts securing cables to the main switch (fig. 1.59).
- Remove handle fixing pin and take the handle out (fig. 1.60).
- Loosen nut fixing main switch to its mounting bracket (fig. 1.60).
- Remove the main current switch and carry out repairing or replacing operations.

Starter motor

Proceed as follows to remove the starter motor from the engine:

Disconnect power cables from battery.

Undo nuts to disconnect wire terminals from starter motor clamps.


Remove the three fixing nuts fastening the starter motor to the engine (fig. I.61).

Remove the starter motor.

Visually check the ring gear for wear.

Clean starter motor mounting surface.

Reassemble the unit by reversing the above steps.



I.61 REMOVING THE STARTER MOTOR

14V 50-90A Alternator

Carry out the following operations to remove the 14V 50 90A alternator:


Disconnect power cables from battery.

Disconnect alternator electrical cables.

Remove bolts from belt tension adjustment bracket and from alternator mounting (fig. I.62).

Remove the alternator.

Reassemble the unit by reversing the above steps and tension the alternator belt by means of the adjusting screw (fig. I.62 ref. A).



I.62 REMOVING THE 14V 50-90A ALTERNATOR

14V 55A Alternator


Disconnect power cables from battery.

Disconnect alternator electrical cables.

Remove bolts from belt tension adjustment bracket and from alternator mounting (fig. I.63).

Remove the alternator.

Reassemble the unit by reversing the above steps and ensure belt tension is correct.




I.63 REMOVING THE 14V 55A ALTERNATOR




Precautions to be strictly observed.

Before working on electrical components disconnect earth cable from battery negative terminal.




50 7

1.64 REMOVING THE IGNITION SWITCH BARREL
A. SCREW B. PIN



50 8

1.65 REMOVING THE PREHEATING ELECTRONIC CONTROL UNIT
(DAILY VEHICLES)



50 9

1.66 REMOVING THE PREHEATING ELECTRONIC CONTROL UNIT
(TURBODAILY VEHICLES)

Ignition switch

The steering lock device is included in the ignition switch.

Proceed as follows to replace the internal barrel:

- Loosen screw A and push pin B inwards (fig. 1.64).

This operation can only be performed with ignition switch in position P (parking) or key removed from the lock.

Daily vehicles – Preheating electronic control unit

To replace this control unit located close to the windscreen wiper unit proceed as follows:

- Undo the screw securing the control unit to the mounting bracket (fig. 1.65).
- Disconnect the connector block and separate wire terminals from control unit clamps by loosening the two fixing nuts.

Reassemble the unit by reversing the above steps.

Turbodaily/Turbodaily 4x4 vehicles – Preheating electronic control unit

To replace this control unit located in the cab right bottom side proceed as follows:

- Disconnect the two control unit connector blocks.
- Unscrew the two nuts fixing the control unit to the cab (fig. 1.66).

Reassemble the unit by reversing the above steps.

Thermostarter


Proceed as follows to remove the thermostarter:

Lift the protection cap and disconnect electrical lines.

Disconnect the pipe from thermostarter to fuel delivery solenoid valve.

Unscrew the thermostarter and remove it.

To reassemble the unit reverse the removal operation sequence and tighten the thermostarter locking nut to a moderate torque.



I.67 REMOVING THE THERMOSTARTER

Preheating plugs (aspirated engine)


Proceed as follows to remove preheating plugs:

Disconnect the wire terminal from the connection bar (fig. I.68 ref. A).

Loosen the four nuts fastening preheating plugs to the connection bar.

Loosen the plug to be removed.


To reassemble the unit reverse the removal operation sequence and tighten the preheating plug you have just replaced to a moderate torque.




I.68 PREHEATING PLUGS
A. WIRE TERMINAL FIXING NUT B. PREHEATING PLUG FIXING NUT

Dashboard


The dashboard consists of two separate areas: one is located in front of the driver. It includes all on-board instruments and the majority of control switches. The other one (central control panel) contains control devices relative to the bus version, power window switches, external mirror switches (optional extra), IVECO Control display panel (optional extra) and electric heater.




I.69 CUS PLUS VERSION DASHBOARD



I.70 REMOVING THE SWITCH FROM ITS HOUSING



I.71 REMOVING THE ELECTRONIC SPEEDOMETER



I.72 REMOVING THE COMBINED MODULE

Key switches

To gain access to the junction block of a key switch, pry the switch off the fixing tabs on its top and bottom sides by means of a screwdriver (fig. I.70).

Proceed with care to avoid disconnecting cables and damaging switches and relevant seats.

Switches are fitted with an internal test lamp of the all glass 12V 2W type.

Electronic tachometer

Proceed as follows to replace the tachometer:

- Undo both screws fastening the instrument to the dashboard (fig. I.71).
- Disconnect the junction block.

Reassemble the unit by reversing the above steps.

NOTE. We suggest that you remove the steering wheel from its seat to facilitate access to the electronic tachometer and the combined module.

Combined module

The combined module forms part of the instrument panel.

Two types of module are available. One of them includes the following components:

- electronic rev counter
- engine coolant temperature gauge
- fuel level indicator
- warning lights

The other module type contains the same instruments with the exception of the electronic rev counter arranged in a different way.

The combined module is also fitted with a lamp test switch and an instrument light dimming rheostat for checking lamp efficiency and reduce instrument light intensity.

Proceed as follows to remove the combined module:

- Undo both screws securing the module to the dashboard (Fig. I.72).
- Carefully turn the module outwards.
- Disconnect instrument junction blocks.

Reassemble the unit by reversing the above steps.

Instruments

Proceed as follows to remove instruments from the combined module:

Remove the combined module as described in the preceding page.

Remove knobs for lamp test switch and light dimmer rheostat switch.


Remove protection plates and antireflection glasses.

Unscrew fixing nuts with vibration-damping metal washers and separate them from the rest of the module.

Work from the component end to remove instruments from the module (figs. 1.74/1.75).


Reassemble the unit by reversing the above steps.

NOTE. Gently pull instruments off their seats to avoid damaging their printed circuits.




1.73 INSTRUMENT FIXING PROCEDURE


A. ENGINE COOLANT GAUGE B. FUEL LEVEL INDICATOR
C. ELECTRONIC REV COUNTER




1.74 REMOVING ELECTRONIC REV COUNTER




1.75 REMOVING ENGINE COOLANT GAUGE AND FUEL LEVEL INDICATOR



I.76 REMOVING INSTRUMENT LIGHT RHEOSTAT



I.77 REPLACING WARNING LAMP BULBS



I.78 REPLACING ASHTRAY ASSEMBLY

Instrument light rheostat

Proceed as follows to replace the instrument light rheostat (fig. I.76):

- Remove the combined module.
Remove the rheostat knob.
Remove instrument protection plates.
- Unscrew rheostat ring nut.
- Working from the module's rear end, disconnect electrical connection lines and withdraw the rheostat.

Reassemble the unit by reversing the above steps.

Warning lamps

Warning lamps are of the all-glass 12V 2W type.

Proceed as follows to replace them:

- Remove the combined module.
- Working from the module's rear end, turn the bayonet-coupling warning lamp connector until it is possible to remove it (fig. I.77).

The block is electrically connected to the system via a tinned seat included in its printed circuit.

Reassemble the unit by reversing the above steps.

Ashtray assembly

Proceed as follows to replace the ashtray (fig. I.78):

- Use a screwdriver to work on both tabs (not visible from the ashtray outside).
- Gently prize the ashtray off its seat taking care not to break its light pipe.

Steering column switch

To remove the steering column switch perform the following operations:


Remove the steering wheel.

Undo the seven screws fixing steering column shrouds (fig. 1.79);


Disconnect junction blocks connecting steering column switch to C.I.U.

Unscrew the clamp fixing nut and remove the clamp (fig. 1.80).

Reassemble the unit by reversing the above steps.



1.79 REMOVING STEERING COLUMN SHROUDS



1.80 REMOVING STEERING COLUMN SWITCH
A. CLAMP

Power window motor


To remove the power window motor perform the following operations:

Remove the door lining panel.


Disconnect junction block from power window motor.

Undo the five screws shown in fig. 1.81.


Reassemble the unit by reversing the above steps.




1.81 REMOVING LEFT POWER WINDOW MOTOR



1.82 REMOVING POWER WINDOW AND EXTERNAL MIRROR SWITCH PROTECTION PLATES



1.83 REMOVING IVECO CONTROL DISPLAY PANEL. ARROWS SHOW THE TWO SPRINGS SECURING THE COMPONENT TO THE DASHBOARD



1.84 REMOVING THE ELECTRIC HEATER CONTROL UNIT ESCUTCHION PLATE

Power window and external adjustable mirror switches

You may follow either one of the procedures described below to remove these switches:

- 1) Use the tip of a screwdriver to remove the plug covering one of the empty compartments (designed to house an optional extra not yet installed) and push the desired component off its seat through this opening.
- 2) Use a screwdriver to remove the protection plate onto which switches are assembled. To do so, prize the plate off the four tabs securing it to the central instrument panel (fig. 1.82).

Reassemble the unit by reversing the above steps.

IVECO Control

Perform the following operations to remove the IVECO Control panel:

- Remove the protection plate onto which power window and adjustable mirror switches are assembled.
- Press the IVECO Control display panel off its seat through this opening (fig. 1.83)

Reassemble the unit by reversing the above steps.

Electric heater control unit

Perform the following operations to gain access to electric heater microswitch:

- Withdraw the speed selection knob and the three air control lever buttons. Then remove the central panel escutcheon plate (fig. 1.84).
- Unscrew the four electric heater fixing screws.


Reassemble the unit by reversing the above steps.

Central Interconnecting Unit (C.I.U.)


To gain access to the C.I.U. compartment open the door located to the dashboard left bottom side (fig. I.85).

Access to junction blocks connecting C.I.U. to cab, engine, steering column switch, ABS (optional extra) cable looms is gained by loosening the four fixing screws (fig. I.86) and turning the C.I.U. outwards.


NOTE. Turn the C.I.U. on its mounting pin gently to avoid disconnecting cables from junction blocks.



I.85 C.I.U. LOCATION



I.86 C.I.U. FIXING SCREWS



I.87 CONNECTION BETWEEN C.I.U. AND ONE OF THE HOOD LOOM JUNCTION BLOCKS

Internal lighting

Internal lighting is provided by a central ceiling lamp. The lamp is either turned on whenever doors are opened via appropriate switches installed on door posts or through a switch assembled on the same ceiling lamp (I.91 ref. A).

The ceiling lamp is fitted with two 12V 10W cylindrical bulbs. To replace the bulb, use a screwdriver to remove the lens (fig. I.91 ref. D).

A swivel spotlight fitted with a 4W bulb is also available. It can be turned on/off via another switch fitted to the ceiling lamp unit (fig. I.91 ref. C). To gain access to the bulb presslightly on the ring locking the swivel spotlight and then turn it counterclockwise (fig. I.91 ref. B).

The ceiling lamp and swivel spotlight unit is secured to the roof by means of two screws. Remove the lens to gain access to these screws.

For more information on interior lighting refer to page I.47 (bus version) and page I.50 (van version).

Headlight aiming control switch

Headlights can be fitted with a light beam control system that adjusts the light beam in the vertical direction. The system is enabled via an appropriate switch.

The system is designed to adjust the light beam to the vehicle's load.

The switch is located between the air outlet and the C.I.U. compartment door. It can be removed as follows:

Use a screwdriver to press lightly on each of the four latches securing the switch to the dashboard (fig. I.92).

Pull out the switch and disconnect the junction block.

Reassemble the unit by reversing the above steps.

Headlight aiming control actuator

Carry out the following operations to remove this device:

Disconnect the the junction block.

Turn the actuator counterclockwise (lh headlight) or clockwise (rh headlight).

Turn the actuator counterclockwise until it is fully removed from its seat (complete protrusion of its pin from the headlight should be observed).


Perform the following reassembling operations:

Remove the headlight rubber plug (fig. I.93 ref. A) and fit a screwdriver through this opening to stop the actuator pin seat.


Fit the actuator into the appropriate headlight opening and push the actuator pin into its seat.

Turn the actuator clockwise (lh headlight) or counterclockwise (rh headlight) until it engages with the headlight.


Refit the rubber plug.




I.91 CEILING LAMP AND SWIVEL SPOTLIGHT UNIT
A. CEILING LAMP SWITCH B. SPOTLIGHT LOCKING RING
C. SPOTLIGHT SWITCH D. LENS



I.92 REMOVING HEADLIGHT AIMING CONTROL SWITCH




I.93 REMOVING HEADLIGHT AIMING CONTROL ACTUATOR




5049

I.94 REMOVING LEFT HAND HEADLIGHT



5011

I.95 LAMP REPLACEMENT
A. COVER B. CONNECTOR C. RETAINING SPRING

2612

I.96 REPLACING H4 HALOGEN LAMP

External lighting

The external lighting system consists of the following components:

- high/low beam lights with built-in parking lights
- fog lamps (optional extra)
- front turn signal lights
- turn signal side repeaters
- front and side marker lights (the van version has prearrangement for side marker lights)
- number plate lights
- tail headlight cluster (parking, turn signal, stop, reverse, rear fog lights)



Chapter V : External lighting
Chapter VI: Signals

High/low beam light with built-in parking light

To remove the headlight disconnect electrical lines to the front headlight cluster and unscrew the three nuts fastening the unit to the vehicle front (fig. I.94).

To gain access to bulbs turn headlight cover counter-clockwise (fig. I.95 ref. A). To replace high/low beam lamps disconnect the junction block (fig. I.95 ref. B) and remove the retaining clip (fig. I.95 ref. C).

Reassemble the unit by reversing the above steps.

Halogen lamps should be handled with care and the quartz should not be touched as this could endanger the efficiency of the lamp (fig. I.96).

Front turn signal light


Proceed as follows to remove the headlight:

Disconnect the junction block.

Undo the fixing screw and detach the lamp from the headlight cluster (fig. I.97).

To gain access to the bulb undo the two screws fastening the lens to the headlight body.

Reassemble the unit by reversing the above steps.



I.97 REMOVING FRONT TURN SIGNAL LIGHT

Turn signal side repeater


Proceed as follows to remove the headlamp (fig. I.98):

Disconnect the junction block.

Prize the headlight off the pressure clutches fastening it to the vehicle body.

Separate the lamp socket from the headlight unit to gain access to the bulb.

Reassemble the unit by reversing the above steps.



I.98 REMOVING TURN SIGNAL SIDE REPEATER

Fog lamp

Proceed as follows to remove the fog lamp:

Disconnect the junction block.


Undo the two fixing screws (arrows fig. I.99).

To gain access to the lamp undo the four screws fastening the cover fitted with a connector block to the headlight body and withdraw the retaining spring.


Reassemble the unit by reversing the above steps.

While reassembling the new lamp avoid touching its quartz bulb as this could endanger the efficiency of the lamp.


Turn in or out screw A (fig. I.99) as required to aim the light beam correctly.




I.99 REMOVING FOG LAMP
A. LIGHT BEAM AIMING SCREW



I.100 REMOVING FRONT MARKER LIGHT



I.101 REMOVING SIDE MARKER LIGHT



I.102 NUMBER PLATE LIGHT

Front marker light

Proceed as follows to remove the front marker light:

- Loosen both screws securing the headlight to the vehicle body (fig. I.100).
- Remove the lens to gain access to the bulb.
- Reassemble the unit by reversing the above steps.

Side marker light

Side marker lights are assembled on the van version. They are located on the bottom side of the vehicle's side panels and are fitted onto suitable mounting brackets.

To remove the side marker light perform the following operations:

- Disconnect the junction block.
- Undo both mounting bracket fixing bolts (fig. I.101).

Remove the lens to gain access to the bulb.

Reassemble the unit by reversing the above steps.

Number plate light

Truck version: proceed as follows to remove the lamp.

- Disconnect the junction block.
- Loosen both nuts fastening the headlight to the antitelescoping device.

Proceed as follows to gain access to the headlight bulb (fig. I.102):

- Loosen both screws securing the lens to the headlight body.
- Replace the bulb.

Ressemble the unit by reversing the above steps.

Refer to page I.50 for information on number plate lights relative to van and bus versions.

Tail headlight cluster

Proceed as follows to remove this component:

Disconnect junction blocks.

- Undo the four nuts fixing the headlight to its mounting frame. Remove the headlight.

To gain access to the headlight cluster lamps:

- undo screws fastening the lens to the headlight body (fig. I.103).

Reassemble the unit by reversing the above steps.


All lamps are fitted with a standard bayonet coupling device.

Lamps are arranged in the following way:


(left headlight: from left to right – right headlight: from right to left)

- turn signal lamp
- stop lamp
- parking lamp
- rear fog, lh headlight lamp
- reversing, rh headlight lamp

Refer to page I.50 for information on tail headlight cluster installed on van/bus versions.



I.103 REMOVING TAIL HEADLIGHT CLUSTER LENS



I.104 REMOVING WINDSCREEN WIPER MOTOR

Windscreen wiper motor

Proceed as follows to replace windscreen wiper motor:

- Disconnect motor junction block.
- Unscrew the nut fastening motor to linkage (fig. I.104 ref. A).

Unscrew the three motor fixing bolts. Remove the motor (fig. I.104 ref. B).


Reassemble the unit by reversing the above steps.

Horns


Horns are assembled on the chassis frame under the power steering fluid reservoir. Proceed as follows to remove horn(s):

- Disconnect junction block(s).
- Undo the nut securing the horn to its mounting bracket (fig. I.105).

Reassemble the unit by reversing the above steps.




I.105 REMOVING HORNS




5050

I.106 REMOVING ELECTRIC HEATER AND RESISTOR UNIT



5051

I.107 REMOVING ELECTROFAN SUPPORT



5052

I.108 REMOVING ELECTROFAN

Electric heater

Carry out the following operations to remove the electric heater (fig. I.106):

- Drain the engine cooling system.
- Loosen clamps and disconnect engine coolant delivery pipes.
- Disconnect air flow drive rods. To do so, press springs and undo screws fastening rods to electric heater.
- Disconnect electric heater junction blocks.
- Undo both screws fastening heat shield to electric heater (fig. I.107 ref. A).
- Remove the four nuts fastening electric heater to vehicle body.

The resistor unit controls the speed of the electric heater motor. To gain access to the resistor unit, disconnect the junction block and remove both screws shown in fig. I.106.

Reassemble the unit by reversing the above steps.

Carry out the following operations to gain access to the electric heater inner wiring system:

- Disconnect electric heater junction blocks.
- Loosen the screw fixing the air flow outlet door control lever to the electric heater section housing the fan (fig. I.107 ref. B).
- Remove retaining spring securing electrofan unit to electric heater.
- Remove the resistor unit (fig. I.108 ref. A).
- Loosen both screws (arrows fig. I.108) and remove the fan. Avoid damaging internal wiring.
- Disconnect electrofan junction blocks.

Reassemble the unit by reversing the above steps.

Bus version

The bus version described in this manual also applies to school buses and City Daily/Turbodaily vehicles. The latter vehicle type is equipped with smaller rear tyres compared to other bus versions to enable thorough use of the loading platform. Contrary to buses and school buses, City Daily/Turbodaily vehicles are used exclusively for goods freight.

The bus version is equipped with the following components and relevant wiring (not assembled on the truck version):

- general current relay (bus/school bus)
- emergency circuit (bus/school bus)
- swing-sliding door
- interior lighting

GCR (General Current Relay) – Operation

Energizing of the GCR (terminal 86 of its coil) is through connection of unsteady switch 53023 (fig. I.109 ref. B) assembled on the dashboard central panel. Terminals 30 and 85 of the GCR are connected to one another and are directly powered by the battery positive cable. Terminal 87 supplies battery positive, ignition switch and the entire wiring system.

To disconnect the GCR turn the ignition switch to STOP position and either operate the safety unit switch 52029 (fig. I.109 ref. A) on the centre instrument panel or the GCR opening switch 53009 (close to the GCR). This way, no energizing order reaches relay 25202 whose purpose is to supply earth for terminal 86 of the GCR coil.


Removing GCR and GCR opening switch

The GCR (fig. I.111 ref. A) is positioned close to the windscreen wiper fluid tank. To remove the GCR carry out the following operations:


- Disconnect battery power cables.
- Disconnect coil-to-relay junction blocks. Loosen both power cable wire terminal fixing nuts.
- Loosen the four nuts fastening GCR to its mounting bracket.

To remove the GCR opening switch (fig. I.111 ref. B) disconnect the switch junction block and unscrew the ring nut from the GCR mounting bracket (fig. I.111 ref. C).


Reassemble the unit by reversing the above steps.




I.109 LOCATION OF SAFETY UNIT SWITCH AND GCR CLOSING SWITCH



I.110 GCR STANDARD OPENING/CLOSING DIAGRAM




I.111 A. GCR (GENERAL CURRENT RELAY)
B. GCR OPENING SWITCH
C. SWITCH RING NUT




5056

I.112 SWING SLIDING DOOR PUSHBUTTON STRIPS REMOVING SEQUENCE



5057

I.113 REMOVING GEARMOTOR UNIT GUARD



5058

I.114 EMERGENCY DOOR OPENING HANDLE (OPERABLE FROM THE INSIDE)

Swing-sliding door control device

The device consists of the following components:

- Pushbutton control strip
- Motor unit
- Swing-sliding door drive shaft

Pushbutton control strip

On City Daily/Turbodaily and bus vehicles the pushbutton strip (fig. I.112 ref. A) is fitted with a control pushbutton, four leds and a sound warning signal.

The red led illuminates whenever the door opens and remains so until the door is perfectly closed.

The green led only illuminates when the door is thoroughly closed.

The yellow led illuminates whenever the manual opening door handle is operated.

The orange led illuminates when the antitheft device is in operation (optional extra). The latter two functions are also signalled via the sound warningsignal.

As regards the school bus version, the button strip (fig. I.112 ref. B) is equipped with two control pushbuttons: a red one for opening the door; a green one for closing it and a red warning lamp that illuminates when door opening is in progress. The lamp goes out as soon as the door is thoroughly closed. Furthermore, the pushbutton strip is fitted with a 20A fuse for protecting the swing-sliding door circuit.

Motor unit and swing-sliding door drive shaft

The motor unit is made up of a plastic frame (plate on the school bus version) housing the gearmotor with the relevant wiring. To gain access to the motor loosen both screws shown in fig. I.113 and remove the frame.

The door drive shaft is positioned next to the door. The mechanism enabling the change of the motor's rotary motion into vertical motion is housed inside the shaft.

Such motion occurs during the door opening/closing stages whenever the door windstrip meets with an obstacle or the door abuts against its housing.

In the first case, the shaft's vertical motion operates a microswitch that will reverse the door movement. In the second case, it enables correct fitting of the door in its seat thus ensuring perfect closing.

Swing-sliding door – Emergency opening from the inside

An emergency door unlocking system can be put into action in the event of a gearmotor or power failure. In this case the door can be opened via a red handle (fig. I.114) located close to the door compartment on bus and City Daily/Turbodaily versions (close to the motor unit on school bus version).

Proceed as follows: operate the black lever positioned beside the motor unit while rotating the door supporting shaft until motor gears are again in mesh.

Swing-sliding door – Emergency opening from the outside

Bus and City Daily/Turbodaily vehicles are equipped with a red handle (fig. I.115) that is positioned close to the wheelhouse.

During an emergency this handle can be pulled to open the vehicle door from the outside.

To restore normal operation of the system, follow direction given above concerning emergency door opening from the inside.

The red handle is also meant to prevent the door being opened from the outside, via a suitable key, while the vehicle is stationary. However, regardless of the fact the door is locked, it can still be unlocked from the inside.

If steps for unlocking the door using the appropriate key are not taken, this inconvenience will be signalled via the orange led and the sound signal as soon as the ignition switch is turned on.

Door locking device

City Daily/Turbodaily vehicles are fitted with a system for locking doors through a remote control device consisting essentially of a sender unit and an infrared receiver.


The sender unit includes (fig. I.116):

- a control pushbutton
- a led for visualizing the signal delivered by the sender unit


The receiver includes (fig. I.117):

- a pushbutton for storing the code of the signal delivered by the sender unit
- a led for signalling reception of the signal
- a sensor for receiving the signal


To enable the door locking function operate the sender unit control button and aim the sender unit towards the infrared receiver located in the middle of the roof.




I.115 HANDLE FOR EMERGENCY OPENING OF THE DOOR FROM THE OUTSIDE A. SWING-SLIDING DOOR KEY LOCK



I.116 SENDER UNIT A. LED B. CONTROL PUSHBUTTON




I.117 INFRARED RECEIVER A. LED – B. PUSHBUTTON – C. SENSOR




5062

I.118 CENTRAL INSTRUMENT PANEL - TOP CONSOLE (SCHOOL BUS VERSION)



5063

I.119 REMOVING SAFETY UNIT CONTROL SWITCH
A. THREADED DOWEL - B. RING NUT



5064

I.120 REMOVING WARNING LAMP AND SWITCHES
A. HAZARD LIGHTS ON WARNING LAMP
B. ELECTRIC/AIR HORN SWITCH
C. GCR CLOSING SWITCH

Top console

A console fitted on top of the centre instrument panel houses the following components:

- safety unit switch (bus/school bus)
- Telma retarder control device and associated warning lamp (optional extra)
- swing-sliding door pushbutton strip
- GCR closing switch (bus/school bus)
- electric/air horn switch
- hazard light warning lamp with built-in safety unit control switch (bus/school bus)

Safety unit control switch

Operation of this switch produces the following effects:

- engine stopping
- turning on of hazard lights
- turning on interior lighting
- GCR opening
- turning on of warning lamp for hazard lights on (fig.I.120 ref. A).

Perform the following operation to remove the safety unit switch:

- Remove the swing-sliding door pushbutton strip
- Unscrew both knob threaded dowels and ring nut securing the switch to the top console (fig. I.119 ref. A/B)
- Withdraw the switch through the button strip seat
- Disconnect both switch junction blocks.

Reassemble the unit by reversing the above steps.

Hazard lights on warning lamp and switches assembled on the top console

You may follow either one of the procedures described below to remove these components:

- 1) Use the tip of a screwdriver to remove the plug covering one of the empty compartments (designed to house an optional extra not yet installed) and push the desired component off its seat through this opening.
- 2) Use a screwdriver to remove the protection plate onto which switches are assembled. To do so, prize the plate off the four tabs securing it to the top console (fig. I.120).

Reassemble the unit by reversing the above steps.

Interior lighting

Interior lighting for the bus/school bus version includes the following components:

- driver's place ceiling lamp
- step light
- passengers door ceiling lamp
- normal/blue light interior ceiling lamp
- loading lamp

Driver's place ceiling lamp

Either opening of the driver's door or pressure applied to the lens sides enable ceiling lamp operation.

Perform the following operation to remove the ceiling lamp (fig. I.121) and gain access to its bulb:

- Remove the lens by means of a screwdriver and replace the all-glass 10W 12V bulb.
- Loosen both screws fixing the ceiling lamp to the roof
- Disconnect ceiling lamp junction blocks

Reassemble the unit by reversing the above steps.

Step light

The step light (fig. I.122) is enabled through operation of the swing-sliding door:


Perform the following operations to remove it:

- Loosen both screws fixing the lamp to the vehicle body.
- Remove the lens and the lamp.
- Remove both screws positioned on the lamp rear and disconnect lamp cables.


Reassemble the unit by reversing the above steps.

Passengers door ceiling lamp


This ceiling lamp (fig. I.123) is also enabled through operation of the swing sliding door. Follow directions given for driver's place light to remove the lamp and gain access to its bulb.




I.121 REMOVING LENS FROM DRIVER'S PLACE CEILING LAMP



I.122 STEP LIGHT




I.123 PASSENGERS DOOR CEILING LAMP




323

I.124 INTERIOR LIGHTING SWITCHES
A. NORMAL LIGHTS SWITCH - B. BLUE LIGHTS SWITCH



506B

I.125 NORMAL/BLUE LIGHT CEILING LAMP



316

I.126 LOADING LAMP
A. SWITCH

Normal/blue light interior ceiling lamps (bus)

Lights are operated via two key switches (fig. I.124) located on the dashboard. Normal lights can also be switched on by operating the safety unit control switch.

Perform the following operations to remove the ceiling lamp (fig. I.125) and gain access to the bulbs:

- Loosen both screws fastening the lens to the ceiling lamp.
- Loosen both screws fastening the blue light lens to the ceiling lamp.
- Loosen the four screws fastening the ceiling lamp to the roof.
- Disconnect junction blocks.

Reassemble the unit by reversing the above steps.

Loading lamp (bus)

With reference to the vehicle running direction, the loading lamp is assembled in the bottom rh luggage compartment. It is fitted with a special switch.

To replace the loading lamp (fig. I.126):

- Use a screwdriver inserted between the lamp rim and the vehicle body to prize the lamp off its seat gently.
- Disconnect junction blocks.


Reassemble the unit by reversing the above steps.

Air-conditioning system

In addition to the electric heater, bus/school bus vehicles are equipped with a further heating system and a foul air intake or ventilation system.

Such systems are enabled via two key switches (fig. I.127) assembled on the dashboard.

An auxiliary electric heater behind the driver's seat and an aerator located in the roof centre area are controlled by the key switches.




I.127 AIR-CONDITIONING SYSTEM SWITCHES
A. AERATOR SWITCH – B. INTERIOR HEATING SWITCH

Interior heating motor

Perform the following operations to remove the interior heating motor:

- Drain the engine cooling system.
- Disconnect motor junction block.
- Loosen clamps and disconnect engine coolant pipes.
- Unscrew the four bolts (fig. I.128) (two on each side) securing the motor to the vehicle floor.

Reassemble the unit by reversing the above steps.



I.128 INTERIOR HEATING MOTOR


Aerator

The aerator is designed to expel the foul air and intake fresh air from the outside.


Proceed as follows to remove the aerator:

- Loosen the six screws fastening the air outlet to the roof.
- Loosen the fan fixing nut and remove the fan (fig. I.129).
- Disconnect aerator motor junction block.
- Remove screws fixing motor to aerator.

Reassemble the unit by reversing the above steps.




I.129 AERATOR




5071

I.130 TAIL HEADLIGHT CLUSTER AND NUMBER PLATE LIGHT



5072

I.131 SIDE DOOR CEILING LAMP



5073

I.132 REAR DOOR CEILING LAMP PUSHBUTTON

Tail headlight cluster and number plate light

To gain access to tail headlight cluster lamps loosen the four screws fixing the lens to the headlight frame. The headlight is also fitted with a side lens that operates tail side marker lights whenever parking lights are switched on.

Lamps are arranged as follows:
(lh headlight: from left to right) – (rh headlight: from right to left)

- tail side marker light
- turn signal light
- stop light
- parking light
- rear fog light
- reversing light

Undo both screws fixing headlight to bumper to gain access to the reversing light bulb (fig. I.130).

Above lights are also assembled on the van version.

Interior lighting (van)

In addition the centre ceiling lamp (page I.37) the interior lighting system of the van version also includes a ceiling lamp located on the side sliding door (fig. I.131) and another light fitted to the top of the rear double-door.

Both lights are either operated via a pushbutton (fig. I.132) assembled on the rear door post or by pressure applied to the ceiling lamp sides.

Access to the bulb is gained by removing the lens by means of a screwdriver.

4x4 Vehicles – Special functions and switch location

Front axle

Figure I.134 shows location of the differential lock switch on the front axle.

Instead of the standard lever system, the alternative installation of a red switch (positioned on the instrument panel rh bottom side) for operating the front differential lock can be requested. The switch is designed to control the front differential lock unit assembled on the front section of the left longitudinal member.

Transfer case


Figure I.135 shows the location of the all-wheel drive switch.

Rear axle


Figure I.136 shows the rear axle. The detail highlights the position of the rear differential lock switch.

Cab


Figure I.133 shows the splitter gear engagement lever. The detail highlights the position of splitter gears on signalling switch.




I.134 FRONT AXLE
A. FRONT DIFFERENTIAL LOCK SWITCH




I.135 TRANSFER CASE
A. ALL WHEEL DRIVE SIGNALLING SWITCH




I.133 CAB
A. SPLITTER GEARS ON SIGNALLING SWITCH



I.136 REAR AXLE
A. REAR DIFFERENTIAL LOCK SIGNALLING SWITCH




507/8



1/4

I.137 TESTING THE PRESENCE OF OUTPUT VOLTAGE ON C.I.U. CONNECTORS OF FAULTY CIRCUIT
 A. C.I.U. - B. JUNCTION BLOCKS FOR CABLE LOOMS C/D/E/F ELECTRICAL COMPONENTS: CAB (C) HOOD (D) ENGINE (E) CHASSIS (F)



86013

867

I.138 TESTING CIRCUIT CONTINUITY
 A. JUNCTION BLOCK

Circuit fault diagnosis

The convergence of the different modules at the C.I.U. (Central Interconnecting Unit) facilitates diagnosis in the circuit because voltage readings can be carried out directly on C.I.U. junction blocks.

NOTE. Voltage readings on connectors should be performed on the lead wire side with the connector plugged into the C.I.U. or the electrical component.

To carry out a circuit fault diagnosis, a circuit diagram should be obtained of the defective circuit and a suitable measuring instrument should be used in order to confirm the presence (or otherwise) of an electrical signal.

The measuring instrument indicates the presence of a voltage.

If a voltage value is detected by setting the negative prod of the measuring instrument to earth (connector G cell 10) and the other one on the C.I.U. positive terminal (fig. I.137 ref. 1), this indicates that the power network is effective before the switch. Therefore the fault will have to be sought after the C.I.U. positive terminal (fig. I.137 ref. 2/3).

The measuring instrument does not indicate the presence of a voltage.

If a voltage value is not detected by setting the negative prod of the measuring instrument to earth (connector G cell 10) and the other one on the C.I.U. positive terminal (fig. I.137 ref. 1), this indicates that the power network is not effective before the switch. Therefore the fault will have to be sought before the C.I.U. positive terminal.

It should be noted that this fault finding method can be used to trace faults throughout the electrical system.

Circuit continuity test

Electrical continuity of the various circuits (fig. I.138) can be tested by insulating the battery from the mains and setting the measuring instrument to the ohmic function.

If a resistance reading equal to ∞ is obtained with the instrument prods set to either end of the cable to be tested, the wiring point where circuit continuity is failing can be traced by testing all cable/component and cable/connector junction blocks.

Particular disadvantages

The following section describes a number of particular recurring disadvantages with an analysis of their probable causes and remedies.

The batteries are quickly discharged when the vehicle is not in use and junction blocks are not connected.

In general, this problem is caused either by sulphation of the battery itself, or more probably by a partially short-circuiting component.

A defective circuit can be easily identified by connecting an analogue voltmeter in SERIES to the chassis earth cable and to the negative terminal of the battery.

Note. Before doing this, make sure that the different circuits that are permanently under voltage, such as tachograph, interior lights etc., are disconnected.

The test will reveal either:

— That the instrument pointer does not deviate from its position at rest.
The system is functioning normally (A fig. I.139). It can be concluded from this test that the discharging of the battery is due to the formation of sulphur salts between the terminals and the mounting brackets of the battery housing, or possibly because the batteries themselves do not hold the charge (because their active components have fallen to the bottom of the container or because the separators have crystallized). In this case the batteries must be renewed.

Or; that the instrument pointer does deviate from its position at rest.


This indicates a passage of current (mA) through the measuring instrument and thus a current leak throughout the system (B fig. I.139).

All that remains to be done is to identify the defective circuit or component. Remove each fuse or junction block from the C.I.U. until the instrument pointer returns to zero.


The return of the pointer to zero is an indication of a defective circuit or component.

Renewal of components


Before any component is renewed, the electrical connections – and the earth connection in particular – must be carefully inspected.




I.139 MEASURING VOLTAGE
A. RELIABLE SYSTEM – B. SYSTEM INCLUDING A FAULTY CIRCUIT OR COMPONENT



I.140 SHUNT WITH A FUSE




I.141 EXAMPLE OF POWER SUPPLY TO A COMPONENT VIA A SHUNT




177

I.142 USE OF A SHUNT TO CHECK THE EFFICIENCY OF A COMPONENT NEGATIVE NETWORK



1187



178

I.143 MEASURING VOLTAGE DROP DUE TO A CONTACT

Use a shunt equipped with a fuse to supply the component in question bypassing the on-board network and thereby checking the correct operation (fig. I.141). This shunt is also used to check the efficiency of the component earth network (fig. I.142).

NOTE. The maximum capacity of the fuse inserted in the shunt is 3 A. In the majority of cases of circuit problems, even if intermittent, the fault is due to the actual network (defective earth, drops in voltage due to electrical contacts, faulty terminal clamping or oxidation, junction block or earth points loose).

Drops in voltage

Among the most frequent causes of circuit problems are the different drops in voltage which adversely affect the reliability of the electrical system.

These drops, which occur in the electrical contacts for switches, remote control switches and relays are due either to the poor connection of the wire terminals or to the wear of the contacts or oxidation.

The method for detecting the fault in these cases consists of checking the drop in input and output voltage of the component, using a digital voltmeter and starting upstream of the defective circuit (having checked that the leads are properly connected to the battery).

The drop in voltage should not exceed 0.1 V. If this is not the case, renew the contact or replace the component (fig. I.143).

Shortcircuit

A simple method for locating a shortcircuit consists of bridging the burnt fuse using the two prods of a multimeter set to the Volt function (fig. I.144 page I.55).

During the search for the cause of a shortcircuit the use of a spare fuse between the battery negative terminal and the earth cable (main current switch off, if fitted) is more than ever justified (fig. I.145 page I.55).

Obviously the spare fuse will be inserted after having bridged the shortcircuited line using the multimeter. The maximum capacity for the fuse is 8 A.

When connected, the multimeter display should indicate 12 V.

As the wires for the circuits protected by the fuse under examination are detached, the defective circuit will be signalled by the return to zero of the multimeter display.

Once the faulty circuit is identified, disconnect junction blocks and components after the fuse.

As junction blocks are reconnected, the 12 V shown on the multimeter display will indicate which section of the cable is shorted or which is the component to be replaced.

Once circuit continuity is restored, replace the fuse observing capacity data specified by the manufacturer.

Excessive voltage


Boiling electrolyte (electrolyte has been topped up too often), silvered or blackened glass of lamps are also symptoms of a defect.

Excessive voltage may be due to a recharge circuit fault (voltage regulator; shorted diodes) as well as to a general circuit failure caused by a loosened supply cable in the vehicle power network (alternator terminals B+, 30 of starter motor; 30 of C.I.U. and battery terminal clips).


NOTE. The voltage value at alternator terminals, with engine running, is limited by the battery counter-electromotive force as batteries are connected in parallel (buffer battery) with the alternator.

If the battery is disconnected from the system, the voltage at alternator terminals may damage the electrical network and the electric/electronic components assembled on the vehicle.


Should it be necessary to leave the engine running for short periods - at an Authorized Workshop - with batteries disconnected from the system, connect terminal D+ of alternator to hood earth by means of a jumper after disconnection of excitation cable (7778).




I.144 LOCATING A FAULT USING THE MULTIMETER



I.145 SHUNT INSERTED BETWEEN BATTERY NEGATIVE TERMINAL AND BATTERY EARTH NEGATIVE TERMINAL




I.146 VOLTMETER INSERTED BETWEEN BATTERY NEGATIVE TERMINAL AND BATTERY EARTH CABLE




2673

I.147 A. POSITIVE CONNECTION B. EARTH CONNECTION - 1. BATTERY - 2. COMPONENTS - 3. ALTERNATOR - U. VOLTAGE - E. ELECTROMOTIVE FORCE (VOLTS)



5087

I.148 TERMINAL 30 STARTER MOTOR



5083

I.149 IDENTIFICATION OF TERMINALS 15 AND 30 OF IGNITION SWITCH

Supply defect

There are many possible voltage supply defects as the number of components which make up the network is large and consequently also the junction blocks.

The wiring system of Daily/Turbodaily/Turbodaily 4x4 vehicles can be divided into three sections from the point of view of on-board electrical voltage (fig. I.147): battery, components and alternator. These sections converge both in terms of positive voltage and reference voltage, that is to say earth.

If there is a supply problem, firstly ensure the efficiency of the connection to the negative terminal of the battery as well as the efficiency of the general current relay (if fitted) and the earth points.

Also ensure the efficiency of:

- connection to battery positive terminal
- connection to terminal 30 of starter motor
- connection to positive terminal of C.I.U.
- connection to terminals 30 and 15 of ignition switch.

Earth defect in exterior lighting and signalling circuits

In this case the defect can be located in as far as, for example, when the stop lights are activated, the other lights not directly involved with the circuit in question come on with decreased power.


The earth defect for the circuits in question may occur either at the connector or the actual component.

A spare shunt, connected to the chassis earth to ensure the reliability if the component before replacing it, should be used.

Common components**Central Interconnecting Unit**

Supplier

Nominal voltage


CAVIS
12V**75000**

66

FUSE ASSEMBLY

| No. | Capacity (A) | Function |
|-----|--------------|--|
| 1 | 5 | Lh front parking light, lh number plate light, rh rear parking light, rh front marker light, dashboard light |
| 2 | 5 | Rh front parking light, rh number plate light, lh rear parking light, lh marker light |
| 3 | 7,5 | Rh low beam light |
| 4 | 7,5 | Lh low beam light |
| 5 | 7,5 | Rh high beam light |
| 6 | 7,5 | Lh high beam light |
| 7 | 3 | Electronic speedometer |
| 8 | 5 | Lamp test, warning lamps, instruments |
| 9 | 10 | Fog lamps (optional extras) |
| 10 | 3 | Rear fog lamps |
| 11 | 5 | Not used |
| 12 | 7,5 | Not used |
| 13 | 10 | Hazard lights |
| 14 | 5 | Turn signal lights |
| 15 | 3 | Engine stopping |
| 16 | 7,5 | Stop lights, reversing light |
| 17 | 10 | Horns |
| 18 | 7,5 | Interior lighting, cigar lighter, radio receiver set |
| 19 | 15 | Fuel filter heating (optional extra) |
| 20 | 10 | Windscreen wiper unit, windscreen washer pump |
| 21 | 15 | Electric heater |
| 22 | 7,5 | Key switch lighting, flasher light |
| 23 | 25 | Power windows (optional extra), engine cooling system |
| 24 | 10 | Not used |

C.I.U. relays and diode holders




5034

RELAY AND DIODE HOLDER ASSEMBLY

| Relay | Description |
|-------|---|
| E1 | Relay for switching on low beam lights |
| E2 | Relay for switching on high beam lights |
| E3 | Relay for user cutoff during starting stage |
| E4 | Relay for switching on fog lamps (optional extra) |
| E5 | Fuel heating circuit relay (optional extra) |
| E6 | Relay for switching on interior lighting with safety unit on (bus) |
| E7 | Available for daylight with fog lamps (variant) |
| E8 | Horn relay |
| E9 | Windscreen wiper unit intermittent operation |
| E10 | Flasher light relay |
| E11 | 1A 3-diode holder container/2 with common cathode (bus and day lights variant) |
| E12 | Relay for switching on hazard lights with safety unit on (bus) |
| E13 | Relay for switching on brake failure warning lamp (vehicles not fitted with IVECO Control device) |
| E14A | Relay for excitation of general current relay (bus) |
| E14B | Hazard lights relay (bus) |
| E15 | Turn signal/emergency electronic flasher light |


| Wiring diagram | Function symbol | Control unit identification no. | Component code |
|----------------|-----------------|---------------------------------|----------------|
| | | E 2 | 25009 |
| 5084 | | E 3 | 25209 |
| | | E 5 | 25810 |
| | | E 8 | 25805 |
| | | E 10 | 25004 |
| | | E 1 | 25008 |
| | | E 4 | 25003 |
| | | E 6 | 25804 |
| 5085 | | E 12 | 25401 |
| | | E 13 | 25103 |
| | | E 14 A | 25202 |
| | | E 14B | 25400 |
| 5086 | | | |
| | | E 11 | 61000 |
| 5087 | | | |
| | | E 9 | 59100 |
| 5088 | | | |
| | | E 15 | 59000 |
| 5089 | | | |



C.I.U. INTERIOR WIRING SYSTEM

C.I.U. connectors

75000




1170


CONNECTOR ASSEMBLY


| Connector | Type (cell no.) | Interlocking circuit |
|-----------|--------------------|-----------------------------------|
| A | 12 | Cab (bus) |
| B | 10 | Cab (steering column switch) |
| C | 12 | Hood (standard type) |
| D | 12 | Cab (bus) |
| E | 12 | Hood (standard type) |
| F | 10 | Cab (standard type) |
| G | 10 | Hood (standard type and variants) |
| H | 12 | Cab (standard type) |
| I | 12 | Cab (standard type) |
| J | 8 | Cab (variants) |
| K | 6 | Cab (steering column switch) |
| L | 4 | Cab (standard type) |
| M | 4 | Cab (standard type) |
| N | — | — |
| + | 1 | Cab/hood/engine (standard type) |

Steering column switch



STEERING COLUMN SWITCH ASSEMBLY - FRONT VIEW






LAYOUT WITH CONNECTIONS


| Ref. no. | Cable colour | Function |
|----------------|-------------------|---|
| 1 (d) | green | Supply of high/low beam lights |
| 2 (e) | brown | Flasher light |
| 3 (g) | blue | High beam lights |
| 4 (s) | black | Horns |
| B 5 (f) | grey/black | Low beam lights |
| 6 (b) | blue/black | Lh turn signal light |
| 7 (c) | light blue | Rh turn signal light |
| 8 (n) | brown | Flasher light supply |
| 9 (a) | violet | Turn signal flasher light |
| 10 (t) | black | Horn supply |
| | | |
| 1 (l) | yellow | Windscreen wipers (intermittent operation) |
| 2 (p) | light blue/white | Windscreen wipers (reset) |
| K 3 (m) | light blue/yellow | Windscreen wipers (low speed) |
| 4 (i) | grey | Windscreen wipers (high speed) |
| 5 (q) | green/black | Windscreen washer pump |
| 6 (h) | pink/black | Supply of windscreen wiper and washer pump unit |

Dashboard



FRONT VIEW

| Ref. no. | Component code | Description |
|----------|----------------|---|
| 1 | 52006 | Tail fog lamp switch |
| 2 | 52307 | Exterior lighting switch |
| 3 | 52302 | Hazard light switch with built-in warning lamp |
| 4 | 52005 | Heated rearview mirror switch with built-in warning lamp (optional extra) |
| 5 | 40002 | Electronic tachometer with digital clock |
| 6 | 58901 | 18-optical indicator panel |
| 7 | 53000 | Lamp test switch |
| 8 | 44001 | Fuel level indicator with built-in warning lamp |
| 9 | 47011 | Engine coolant temperature gauge with built-in warning lamp |
| 10 | 61203 | Instrument light rheostat |
| 11 | 48001 | Electronic rev counter |
| 12 | 53004 | Headlamp washer switch (optional extra) |
| 13 | 52017 | Blue interior light switch (bus) |
| 14 | 52021 | Interior lighting switch (bus) |
| 15 | 52311 | Aerator switch with built-in warning lamp |
| 16 | 52030 | Interior heating switch (bus) |
| 17 | 52304 | Fog lamp/rear fog lamp interlock switch (optional extra) |




CONNECTOR END VIEW

5393

| Ref. no. | Description |
|----------|---|
| 1 | Combined module (optical indicators, lamp test switch, instruments, instrument light dimmer rheostat) |
| 2 | Electronic tachometer with digital clock |
| 3 | Heated rearview mirror switch with built-in warning lamp (optional extra) |
| 4 | Hazard light switch with built-in warning lamp |
| 5 | Exterior lighting switch |
| 6 | Tail fog lamp switch |
| 7 | Fog lamp/tail fog lamp interlock switch (optional extra) |
| 8 | Interior heating switch (bus) |
| 9 | Aerator switch with built-in warning lamp (bus) |
| 10 | Interior lighting switch (bus) |
| 11 | Interior blue light switch (bus) |
| 12 | Headlight washer unit switch (optional extra) |

Combined module (Daily vehicles)




FRONT VIEW

CONNECTOR END VIEW

| Ref. no. | Description |
|----------|---|
| 1 | Available for optional extra warning lamp |
| 2 | Power steering fluid level warning lamp |
| 3 | Water in fuel filter warning lamp |
| 4 | ABS system failure warning lamp (optional extra) |
| 5 | Available for optional extra warning lamp |
| 6 | Brake system failure warning lamp |
| 7 | Interior heating on warning lamp |
| 8 | Parking brake on warning lamp |
| 9 | Engine oil pressure warning lamp |
| 10 | Battery charging failure warning lamp |
| 11 | Turn signal lights on warning lamp |
| 12 | Parking lights on warning lamp |
| 13 | Tail fog lamp on warning lamp |
| 14 | High beam lights on warning lamp |
| 15 | Available for optional extra warning lamp |
| 16 | Rear door open warning lamp |
| 17 | Engine coolant level warning lamp |
| 18 | Available for optional extra warning lamp |
| 19 | Engine coolant temperature gauge with built-in warning lamp |
| 20 | Instrument light rheostat |
| 21 | Lamp test rheostat |
| 22 | Fuel level indicator with built-in warning lamp |
| 23 | Instrument light |
| 24 | Warning lamp protection diodes |
| 25 | Fuel reserve warning lamp |
| 26 | Warning lamp connectors |
| 27 | Instrument light rheostat |
| 28 | Instrument connector block |
| 29 | Engine coolant temperature warning lamp |

Combined module (Turbodaily vehicles and Daily vehicles equipped with rev counter unit)




FRONT VIEW

CONNECTOR END VIEW

| Ref. no. | Description |
|----------|--|
| 1 | EDC system failure warning lamp (Turbodaily.10 vehicles) |
| 2 | Power steering fluid level warning lamp |
| 3 | Water in fuel filter warning lamp |
| 4 | ABS system failure warning lamp (optional extra) |
| 5 | Air cleaner restriction warning lamp (Turbodaily) |
| 6 | Brake system failure warning lamp |
| 7 | Preheating system on warning lamp |
| 8 | Parking brake on warning lamp |
| 9 | Engine oil pressure warning lamp |
| 10 | Battery charging failure warning lamp |
| 11 | Turn signal lights on warning lamp |
| 12 | Parking lights on warning lamp |
| 13 | Tail fog lamp on warning lamp |
| 14 | High beam lights on warning lamp |
| 15 | Air suspension system failure warning lamp (optional extra on Turbodaily vehicles) |
| 16 | Rear door open warning lamp |
| 17 | Engine coolant fluid level warning lamp |
| 18 | Available for optional extra warning lamp |
| 19 | Fuel level indicator with built-in warning lamp |
| 20 | Engine coolant temperature gauge with built-in warning lamp |
| 21 | Rheostat |
| 22 | Lamp test switch |
| 23 | Rev counter |
| 24 | Instrument light |
| 25 | Warning lamp protection diodes |
| 26 | Warning lamp connector blocks |
| 27 | Instrument connector blocks |
| 28 | Rheostat |
| 29 | Fuel reserve warning lamp |
| 30 | Engine coolant temperature warning lamp |

Central control panel




FRONT VIEW

5095

Ref. no.

Description

- | Ref. no. | Description |
|----------|--|
| 1 | Central control panel top console (City Daily/Turbodaily vehicles) |
| 2 | Telma retarder control device (optional extra) |
| 3 | Swing-sliding door opening device button strip (school bus) |
| 3A | Swing-sliding door control device (bus/City Daily/Turbodaily vehicles) |
| 4 | Safety unit switch (bus) |
| 5 | Telma retarder warning lamp (optional extra) |
| 6 | Hazard lights on warning lamp (bus) |
| 7 | Air/electric horn switch (bus) |
| 8 | General Current Relay (GCR) closing switch (bus) |
| 9 | Windscreen defrosting electric heater |
| 10 | Radioreceiver set compartment |
| 11 | Cigar lighter |
| 12 | IVECO Control display panel (optional extra) |
| 13 | Passenger's door power window switch (optional extra) |
| 14 | Adjustable mirror switch (optional) |
| 15 | Driver's door power window switch (optional extra) |



CONNECTOR END VIEW

5097

| Ref. no. | Description |
|----------|---|
| 1 | Hazard lights on warning lamp (bus) |
| 2 | Air/electric horn switch (bus) |
| 3 | General current relay (GCR) closing switch (bus) |
| 4 | Telma retarder warning lamp (optional extra) |
| 5 | Safety unit control switch (bus) |
| 6 | Swing-sliding door opening device button strip (school bus) |
| 7 | Telma retarder control device (optional extra) |
| 8 | Passenger's door power window switch (optional extra) |
| 9 | Adjustable mirror switch (optional extra) |
| 10 | Driver's door power window switch (optional extra) |
| 11 | IVECO Control display panel (optional extra) |
| 12 | Cigar lighter |
| 13 | Windscreen defrosting electric heater |
| 14 | Radioreceiver set compartment |


STARTING

| | Page |
|--|------|
| TURBODAILY VEHICLES – SIMPLIFIED NETWORK | 3 |
| TURBODAILY VEHICLES (BUS VERSION) SIMPLIFIED NETWORK | 4 |
| BATTERIES | 5 |
| SPECIFICATIONS | 5 |
| ON-BOARD TESTING | 6 |
| CAPACITY TEST | 6 |
| GENERAL INFORMATION | 6 |
| BASIC DATA | 7 |
| TECHNICAL HINTS | 7 |
| MAINTENANCE | 9 |
| CONNECTIONS | 10 |
| FIXING | 10 |
| ELECTROLYTE LEVEL | 10 |
| CLEANING | 10 |
| CHECKING THE STATE OF CHARGE OF THE BATTERY | 11 |
| RECHARGING BY MEANS OF AN EXTERNAL CHARGER | 13 |
| STARTING FROM AN EXTERNAL TROLLEY | 14 |
| STARTER MOTOR | 15 |
| SPECIFICATIONS | 15 |
| ON-BOARD TESTING | 17 |
| DISMANTLING/REASSEMBLY | 19 |
| BENCH TESTING | 20 |
| GENERAL INFORMATION | 21 |
| TECHNICAL/PRACTICAL HINTS | 21 |
| IGNITION SWITCH FOR STARTER-ASSISTED SERVICES | 27 |
| PRE/AFTER-HEATING ELECTRONIC CONTROL UNIT (DAILY VEHICLES) | 27 |
| PRE/AFTER-HEATING ELECTRONIC CONTROL UNIT (TURBODAILY VEHICLES) | 31 |
| THERMOSTARTER | 35 |
| PREHEATING SYSTEM OPERATION SWITCH | 36 |
| SOLENOID VALVE FOR CONNECTION TO ATMOSPHERE FROM FUEL FILTER(THERMOSTARTER) | 37 |
| ENGINE STOPPING SOLENOID | 38 |


| | Page |
|------------------------------------|------|
| GCR CLOSING SWITCH | 39 |
| GENERAL CURRENT RELAY | 40 |
| GCR OPENING SWITCH | 41 |
| SAFETY UNIT CONTROL SWITCH | 42 |
| MAIN CURRENT SWITCH | 43 |
| IGNITION TIMER OPERATION SWITCH | 46 |
| IGNITION TIMER VARIABLE RESISTANCE | 46 |

STARTING

Turbodaily vehicles – Simplified network




Turbodaily vehicles (School bus version) – Simplified network



Batteries

Specifications




5100

MARELLI

12V-88Ah-395A

Daily




5101

MARELLI

12V-95Ah-450A


Turbodaily



5102

DELCO

12V-102Ah-RC 310A

Turbodaily
(either right-hand drive
or fitted with
air-conditioning system)

5103


MARELLI

12V-110Ah-450A

Turbodaily (either bus
version or fitted with op-
tional extras)


Quick diagnosis

| Defect | Possible cause | Remedy |
|-----------------------------|---|--|
| Starting defect | 1. Discharged battery | Check battery charge. If correct, check recharging circuit |
| | 2. Terminals loose or oxidized or burnt | Restore terminal efficiency, as required |
| | 3. Faulty starting circuit | See "Starting" section |
| Electrolyte level often low | 1. Excessive voltage | Check recharging circuit and/or check if terminals are loose |
| | 2. Oxidized terminals | Clean or replace |
| Electrolyte level often low | 1. Excessive voltage | Check recharging circuit and/or check if terminal are loose |



5104

II.3 CAPACITY TEST WITH EQUIPMENT 9933002



5105

II.4 CAPACITY TEST WITH EQUIPMENT 99309003

On-board testing



Avoid connecting/disconnecting cables with charging rheostat on. Clips connected to terminals might blaze up.


Capacity test

- Connect "Electric system test" equipment clips to battery terminals observing polarity.
- Position test selector knob on "INT" (interior).
- Work on charge rheostat lever until reading on amperometer is about three times the A/h nominal capacity.
- Hold rheostat charge for 15 seconds.
- Read voltage value attained by the battery.
- Release the rheostat.
- If voltage does not drop below 9.6 V the battery is working properly.

General information

The efficiency of the electric system is mainly dependent on the charging state and regular maintenance of accumulators, generally called batteries.

Perfect efficiency of the electric system is a prerequisite for the active and passive safety of the vehicle.



5106

II.5 BATTERY CAPACITY TEST WITH EQUIPMENT 99309003

Basic data

The battery is a reversible device. This means that it stores and supplies the energy necessary to operate electrical and electronic components fitted on the vehicle.

The battery consists of a group of elements (cells) connected in series which generate energy via chemical reactions occurring when the electric current passes through the composing substances (fig. II.6).

The property of reversibility is due to the fact that its composing elements can return to their initial state during the charging stage.

The active substance applied to plates contained in each cell is lead dioxide (PbO_2) for positive plates and spongy lead (Pb) for negative plates (fig. II.7).

The lead has a spongy consistency to facilitate chemical reaction with the acid (electrolyte) in which plates are immersed.

The electrolyte consists of a solution of sulphuric acid (H_2SO_4) diluted in distilled or demineralized water.

Density of the electrolyte varies from charging state (1270 g/l) to discharging state (1150 g/l).

During discharging, active substances (lead dioxide and lead) are transformed in lead sulphate ($PbSO_4$).

When the current flows in the opposite direction (that is to say when the battery receives the energy) active substances are restored to their initial state.


At the ends of each single cell, an electromotive force is formed (2.05 V approx.)

Technical hints


Self-discharge. A discharge resulting from internal reactions of the battery. Normally self-discharge value may amount to 1% of the daily rated capacity of the battery for each stoppage day. This percentage value should always be remembered when batteries are stored. If a battery is not recharged for more that 30 days it is irreparably damaged. Recharging of stored batteries or of sulphated batteries - provided their condition is still recoverable - is performed as permanent charge and at minimum current intensity.

Capacity. The quantity of electricity measured in a/h which can be drawn from a battery.


Rated capacity. The capacity that a battery can supply during 10 or 20 hour discharging (according to standards). This value is generally shown on battery holders (fig. II.8).



II.6 SIX-CELL BATTERY (SCHEMATIC DIAGRAM)



II.7 SECTIONAL VIEW OF A BATTERY CELL




II.8 NOMINAL FEATURES: 12 V. RATED VOLTAGE - 88 Ah. RATED CAPACITY - 395 A. QUICK DISCHARGE

Recharging current rate


| Capacity in Ah | A |
|----------------|----|
| 50 ÷ 65 | 4 |
| 65 ÷ 75 | 5 |
| 75 ÷ 85 | 6 |
| 85 ÷ 110 | 8 |
| 110 ÷ 130 | 10 |
| 130 ÷ 155 | 11 |
| 155 ÷ 170 | 13 |
| 170 ÷ 200 | 15 |
| 220 ÷ 260 | 19 |

II.9 CURRENT INTENSITY SUGGESTED FOR RECHARGING THE BATTERY



2692

II.10 CHARGING STATE AND RELEVANT VOLTAGE VALUES. WITH A VALUE OF 12.30 V THE BATTERY DOES NOT GUARANTEE ENGINE STARTING



2693

II.11 DISCHARGING PERFORMANCE CURVE RELATIVE TO TIME

Normal charging current. The current intensity used for recharging through an external source. As a rule, the charging intensity amounts to a tenth of the battery rated capacity.

Potential difference. The voltage measured at battery terminals.

Electrolyte. Ionic conductor consisting of a sulphuric acid water solution (density: 1200 g/l at 25° C).

Plates. Consisting of lead alloy-antimony grids on which active substance is pressed: lead dioxide on positive plates, spongy lead on negative plates.

Internal resistance. Resistance opposing the current flow inside the battery. It is formed by various partial resistances. In lead batteries internal resistance ranges from a few thousandths to a few hundredths ohms.

Quick discharge. Battery discharge for three minutes in the most unfavourable outdoor temperature conditions (-10° C). This value is normally shown on batteries.

Sulphuric salts. They form close to battery terminals owing either to capillary effect of electrolyte splashes or gassing. This process continues relentlessly unless parts in contact with salts are cleaned. Sulphuric salts accelerate battery self-discharge via its fixing elements.

Separators. Microporous synthetic substances allowing the flow of ionic current yet preventing contact between opposite polarity plates.

Sulphation. Lead sulphate crystals (insoluble in water) inhibiting ionic current flow inside the battery whenever the latter has been poorly serviced.

Buffer battery. This is a parallel connection between battery (or batteries) and generator (alternator). In other words, the generator positive terminal and the battery negative terminal are connected to the generator negative terminal. Buffer connection enables battery (or batteries) to act as a voltage regulator for the entire system.

Charging voltage. Voltage detected at battery terminals once the battery is recharged. This value is normally 2.4 V for each cell.

Rated voltage. Conventional value obtained by multiplying the product of a single cell by the number of battery cells.

Discharging voltage. On reaching a given voltage value (which as a rule is 10.5 V for a 12 V battery), it is advisable to stop battery discharging.

Maintenance


- When electrically welding parts on the vehicle, disconnect power cable from the battery positive terminal and connect it to chassis earth.

To prevent serious damage to the electrical system caused by extreme current intensity produced by battery, in case of a short circuit it is of the utmost importance to disconnect the chassis earth cable from the battery negative terminal before disconnecting any other terminal and before working on electrical or electronic components.

- Disconnect cable from battery terminals when recharging by means of an external battery charger.


Discharged batteries (electrolyte density 1.150 g/l at 25° C) should be immediately recharged to prevent the irreversible process of plate sulphation.

- When testing with a hydrometer, if one or more cells are found with milky white or brick red electrolyte, the battery must be replaced.
- Never top up with sulphuric acid.
- Recharge batteries if they do not supply the necessary engine starting power. In cold weather (outdoor temperature below 0° C) wait 3 minutes before repeating the starting operation.
- Quick emergency recharging should be performed only when a battery is in good condition.




199

II.12 TIGHTENING STAY BOLTS




2694

II.13 A. CORRECT CLIP POSITIONING ON BATTERY TERMINAL TIGHTENING CLIP ON BATTERY TERMINAL - B. CORRECT - C. INCORRECT




2695

II.14 A. EFFICIENT CLIP B. INEFFICIENT CLIP




2696

II.15 POSITIONING A BATTERY CLIP WITH A RUBBER Mallet



2697

II.16 REMOVING A BATTERY CLIP WITH A SUITABLE EXTRACTOR



5107

II.17 CHECKING ELECTROLYTE LEVEL WITH A GLASS TUBE

- Never bring a flame (matches, cigar lighter etc.) close to batteries especially when they are being charged with an external charger.
- Ensure system isolation before carrying out battery replacement.
- Never rest tools or objects on battery covers. Never step on batteries.

As mentioned before, good functioning of the electric system depends on correct use of the battery which should undergo continuous and efficient maintenance.

Connections

Perfect electrical contact of the battery clips to battery terminals is of the utmost importance. Battery terminal clips should be in perfect condition, free from corrosion, from galvanic oxidation and electrolyte salts. They should be tightened to a moderate torque to prevent warping (fig. II.12 and II.13).

Clips are marked + (positive) and – (negative) and are of different diameters to avoid connection errors. Finally, cable length should be adequate.

Fixing

Correct fixing of the battery in the mounting tray ensures its long life. Tightening through L bracket or frame, torque should be moderate to prevent warping or cracking of battery caps (fig. II.11).

Electrolyte level

Periodically check electrolyte level in each single battery cell. Topping up, if necessary, should be carried out after resting the battery (i.e. with no current input for 5 or 6 hours). Use only distilled or purified water and a plastic funnel. Depending on battery type, plates should be immersed by 10 to 15 mm.

For ebonite batteries – therefore with non translucent case – use a glass tube to check the level (fig. II.17).

Cleaning

Periodically wash batteries with a jet of water. Then blow dry with compressed air and use woollen cloths. Smear clips with anti-acid neutral grease (do not use lubricants).

Checking the state of charge of the battery

Make sure you respect polarity when connecting an external charger to battery terminals. To avoid explosions, disconnect the recharging equipment from the mains BEFORE disconnecting clips from battery terminals. For the same reason, electrolyte level check should only be carried out by means of an electric torch.

If the vehicle is expected to remain stationary for more than eight days, battery terminals must be disconnected. Check the state of charge at regular intervals and recharge if necessary. Checking the state of charge is a basic step in the maintenance operation sequence.

The efficiency of the battery can be checked through electrolyte density to which it is strictly connected. This measurement is carried out by means of a suitably calibrated hydrometer (fig. II.19). Compare the reading on its scale with that shown on figure II.20 to obtain the exact state of efficiency of the battery (percentage reading).

To avoid obtaining an unreliable reading, do not take this measurement in the following cases:

When electrolyte level is not as specified: in this case top up with distilled water and wait 1 – 2 hours before carrying out a quick 10/15 minute recharging.

- When battery temperature is different from ambient temperature (25° C): in this case wait for the battery to reach the correct temperature.
- When the electrolyte is boiling: in this case wait until all bubbles in the hydrometer reach the surface.

To obtain a correct electrolyte level reading position the hydrometer vertically and take the reading at the emerging point.

If the vehicle is expected to remain stationary over a long period of time, store batteries in a dry and ventilated place and recharge them each time electrolyte density is below 1200 g/l.

Visual inspection


Check efficiency of clips, fastening brackets etc. at regular intervals ensuring batteries are perfectly clean.

Measuring electrolyte density


The electromotive force of the batteries depends on electrolyte density and increases accordingly.




Remember that daily self-discharge of a battery requiring standard servicing is 1% of its rated capacity.



II.18 CHECKING STATE OF CHARGE OF SEALED BATTERIES



II.19 CHECKING ELECTROLYTE DENSITY




II.20 HYDROMETER. THE PERCENTAGE SCALE INDICATES THE STATE OF CHARGE

| Voltage | Specific weight 25°C | Charging percentage | Guaranteed starting | |
|---------|----------------------|---------------------|---------------------|-----|
| 13.2 | 1.300 | 100% | YES | YES |
| 12 | 1.190 | 50 % | YES | NO |
| 11.6 | 1.146 | 25 % | NO | NO |

2702

II.21 TABLE OF ELECTROLYTE DENSITIES (SPECIFIC WEIGHT) OR ELECTROMOTIVE FORCE VALUES IN VOLTS AND RECHARGING PERCENTAGE



2703

II.22 PERFORMANCE CURVE OF OPEN CIRCUIT ELECTROMOTIVE FORCE VARIATION DEPENDING ON ELECTROLYTE DENSITY AT 25° C. PERCENTAGE SCALE REPRESENTS THE CHARGING STATE

| Electrolyte | Batteries | |
|--|------------------------------|-------------------------------|
| | Normal climates (below 32°C) | Tropical climates (over 32°C) |
| Filling density | 1270 | 1270 |
| Density at end of charge | 1270 ÷ 1280 | 1220 ÷ 1230 |
| Max. temp. per single cell during charging | 1270 | 60 °C |

2704

II.23 TABLE OF ELECTROLYTE DENSITIES DEPENDING ON CLIMATES

Standard batteries

Before recharging the battery top up the electrolyte level in each single cell with distilled or purified water (use plastic funnels).

Disconnect the earth and positive leads from their respective terminals, then proceed as follows:

- Connect the clips to the battery terminals observing polarity.
- Select the recharging voltage on the external charger.
- Connect the charger to the mains and switch it on.
- Regulate the charging current according to table in figure II.9.

During recharging the temperature of the electrolyte should not exceed 50° C.

End of charge is indicated by boiling electrolyte. Voltage on battery terminals is then 15 to 16.2 V (for a 12 V battery).

Dry charge battery

Top up with the electrolyte supplied with the battery kit.

Before use, this type of battery must be rested 2 hours to allow the plates to absorb the acid. Top up level again after resting for 2 hours, if necessary.

If after operation the electrolyte density is lower than 1220 g/l at a temperature of 25° C, recharge the battery with an external device.

The recharge current value should not exceed 20% of battery rated capacity.

Maintenance free batteries

Use an open circuit digital voltmeter to check the state of charge of this type of battery.

Recharging of batteries requiring no maintenance is carried out at constant voltage and current intensity is one tenth of rated capacity.

If the voltage value exceeds 16V, the recharging current should be decreased.

End of charge

End of charge is automatically ensured by external devices equipped with a special probe. If the external device is not fitted with a probe, end of charge is indicated by boiling electrolyte. Switch off the battery charger through the proper switch (MAR/AR) before disconnecting extension leads from battery terminals.



Wait for electrolyte temperature to reach ambient temperature and then check the charge percentage using a digital voltmeter or an appropriate hydrometer (fig. II.20). Discharged battery electrolyte freezes at -5° C.

Recharging batteries by means of an external charger

Perform connections as indicated in figures II.24 and II.25.

- A. External charger
- B. Battery on-board the vehicle
- 1. Amperometer
- 2. Timer
- 3. Selector
- 4. Voltmeter
- 5. Positive power cable disconnected from battery terminal
- 6. Negative power cable disconnected from battery terminal
- 7. Main current switch (if fitted)
- 8. Earth

 Table figure II.9 page II.8.




For maintenance free batteries recharging current values must be halved.


Battery end of charge is indicated by boiling electrolyte (45s–50s C) and emission of explosive gases.

To avoid damaging the battery inside and prevent battery explosions, strictly adhere to the following directions:


- top up the electrolyte to the correct level;
- charger voltage characteristics must meet vehicle system specifications;
- battery must be disconnected from vehicle mains;
- the intensity of the charging current must be proportional to the battery's rated capacity .



II.24 EXTERNAL CHARGER TO VEHICLE BATTERY CONNECTION DIAGRAM



II.25 CONNECTING EXTERNAL CHARGER TO BATTERY ON-BOARD THE VEHICLE



511

II.26 EXTERNAL TROLLEY TO VEHICLE BATTERY CONNECTION DIAGRAM

Starting from external trolley

Owing to the large quantity of delivered energy (several hundredths of ampere), voltage and rated capacity of batteries assembled on the external trolley should meet vehicle system specifications.

Ensure the external trolley knife switch is open. First connect the trolley positive extension cable to battery power cable positive terminal (RED). Then connect the trolley negative extension cable to power cable negative terminal (BROWN).

Close the vehicle's knife switch, then close the external trolley's knife switch, once the preheating stage is over, start the engine. When the engine is running open the external trolley's knife switch. Disconnect the clip for the negative extension cable first, then disconnect the positive one.


Above connections are shown in fig. II.26, as follows:

- A. Trolley with batteries for starting vehicle from the outside
- B. Battery on vehicle
 1. External trolley knife switch
 2. Positive extension cable to be connected to positive clip (+) of vehicle battery
 3. Negative extension cable to be connected to negative clip (-) of vehicle battery
 4. Positive power cable for supply of vehicle components
 5. Negative power cable connected to engine earth (M1)
 6. Main current switch (if fitted)
 7. Vehicle's metal frame (earth)




Observe vehicle system polarity.

Take great care when positioning external trolley power clips: they should cover maximum possible terminal surface area without however touching the battery fixing brackets.



512

II.27 CONNECTING VEHICLE BATTERIES TO EXTERNAL TROLLEY FOR REMOTE STARTING OPERATION

Starter motor**Specifications**

5113

BOSCH**EV-12V-2,2kW****Daily
Turbodaily****Quick diagnosis**

| Defect | Possible cause | Remedy |
|---|---|--|
| Lead in torque insufficient | <ol style="list-style-type: none"> 1. Discharged batteries 2. Circuit connections oxidized or loose 3. Brushes inefficient 4. Field windings shorted 5. Broken or shorted armature 6. Ovalized commutator | <p>Recharge or replace battery</p> <p>Check battery and starter motor connections</p> <p>Check length, sliding and pressure of brushes</p> <p>Replace windings</p> <p>Replace commutator</p> <p>Grind or replace</p> |
| Lead in torque adequate but engine will not start | <ol style="list-style-type: none"> 1. Free wheel or solenoid faulty | <p>Replace</p> |
| Pinion does not mesh | <ol style="list-style-type: none"> 1. Flywheel ring gear worn | <p>Change parts concerned</p> |

Supplier

BOSCH KB 24V 5,4kW

Model

EV 12V 2,2 kW

Type:

4 poles, series excitation, mesh by solenoid driven fork

Direction of rotation


clockwise

Rated voltage


12 V

Rated output


2,2 kW




WIRING DIAGRAM



LAYOUT WITH CONNECTIONS



PINION ADJUSTMENT



1. SUPPORT
2. PINION MESH DRIVE SOLENOID
3. PINION
4. PINION MESH FORK
5. ARMATURE
6. FRAME
7. INDUCANCE WINDINGS
8. BRUSH HOLDER
9. COVER
10. SCREW

EXPLODED VIEW

On-board testing

Current absorption test

- Connect main lead clips of equipment to battery terminals observing polarity (fig. II.28).
- Connect inductive clip to positive cable observing polarity and direction of arrow marked on same clip.
- Turn test selector to "INT" (internal) position.
- Prevent engine starting and actuate starter motor for 15 seconds.

Observe voltage and current values.

- Voltage should not drop below 19.5 V if two 12V series-connected batteries are used.
- The value of current absorbed by the starter motor should not exceed battery capacity in Ah by about three times.
- If the above two conditions are met, the starter motor is working properly.

Testing circuit voltage drop

Connect positive clip to terminal 30 of starter motor and negative clip to starter motor frame (fig. II.29).

- Turn test selector on "EST" (external) position.
- Prevent engine starting and actuate starter motor.


Voltage reading on digital voltmeter during starting stage may vary by about 0.5 V compared to readings obtained during the previous test (current absorption test). If this is so, conditions of circuit and connections are satisfactory.

Excessive voltage drop test


Connect positive clip of external voltmeter to battery positive terminal and negative clip to terminal 30 of starter motor (fig. II.30).

- Turn test selector to "EST" (external) position.
- Prevent engine starting and actuate starter motor.


Voltage reading on digital voltmeter should not exceed 0.5 V if the circuit is efficient.




II.28 CURRENT ABSORPTION TEST



II.29 VOLTAGE DROP TEST ON CIRCUIT AND CONNECTIONS




II.30 CIRCUIT VOLTAGE DROP TEST



5119

II.31 TESTING STARTER MOTOR EARTH



5120

II.32 TESTING VOLTAGE DROP ON SOLENOID CONTACTS

Testing starter motor earth


- Connect the external voltmeter negative cable to battery negative terminal and voltmeter positive cable to starter motor body (fig. II.30).
- Turn test selector to “EST” (external) position.
- Prevent engine starting and actuate starter motor.

Voltage reading on digital voltmeter should not exceed 0.25 V if solenoid contacts are efficient.

Testing voltage drop on solenoid contacts

- Position external voltmeter cables on solenoid contacts observing polarity.
- Turn test selector to “EST” (external) position.
- Prevent engine starting and actuate starter motor.

Voltage reading on digital voltmeter should not exceed 0.25 V if contacts are efficient.



5121

II.33 TESTING STARTING CIRCUIT WITH EQUIPMENT 99309003

In addition to previously mentioned tests, troubleshooting on a starter motor can be carried out at the test bench using the appropriate equipment and facilities.

Readings resulting from these tests should be compared with data supplied by the manufacturer.

Disassembly

Lock the starter motor in a vice provided with lead caps. Dismantle the starter motor according to instructions.

NOTE. To facilitate dismantling operations use only a plastic hammer.

Remove the control relay and take out the compensating plate.

Remove the brush holder support, be careful not to damage winding terminals.

After disassembly wash all components quickly. Use only detergents for electrical components: petrol, solvent or trichlorethylene.



Given their volatility, strict compliance with safety standards concerning inflammable liquids is recommended, as well as the use of protective glasses and gloves.

Accurately blow dry washed parts with compressed air (4 bar approx.) and use clean cloths.

Check all parts for wear or defects. Damaged, shorted or worn parts should be replaced.

NOTE. Regular replacement is also recommended for brushes, seals, washers, Grower washers and for the pinion fixing nut on armature shaft.

Should the armature commutator need remachining (eccentricity) use a hard steel turning tool to turn commutator until all eccentricity is eliminated.

If it is necessary to remove the windings proceed as follows: mark pole pieces, then slightly heat new windings and refit pole pieces observing marks made during disassembly.

When using the tester, rest the polar body on a working plane insulated from the test bench earth and from the earth.

Change relays with corroded contacts.

Extreme care is required during the armature insulation test.

Possible vibrations of the steel segment located on the armature body mean that armature levers are shorted or that mica removal is incorrect. Correct mica removal should be in the shape of a clear-cut U.

Reassembly


During reassembly make sure that the armature (without brushes) turns freely.

Also check that brushes slide easily in their seat, check spring pressure on brushes (1.2 kg), and spring pressure on coupling rod.

Lubricate bright sections with corrosion proof oils and slightly smear the pinion with specific grease.

NOTE. Do not put oil or grease on the commutator.

When reassembling the brush holder support make sure not to damage winding terminals.



77649

11.34 BENCH TEST

On completion of assembly check that the pinion slides freely by working on coupling relay and make sure of armature free rotation.

Special attention should be paid to the position of brush polarity jumpers as well as to winding terminals both with regard to brushes and control and starting relays.

Make sure there is no short circuit (owing to vibrations) between winding terminals and polar body or brush holder support. Also make sure there is no contact or risk of contact between winding terminals and armature.

Bench test

Fix the starter motor firmly to the bench by means of fastening chains. Starter motor cover on commutator side should be removed.

Connect power leads to starter motor terminals observing polarity.

Should values read during test be other than those of performance curves shown on figure, dismantle the motor again and repeat the checking sequence for each single component.

NOTE. Bench test values mainly depend on the state of charging and capacity of batteries and on test duration which should be as short as possible.

Power curves

Power depends on two factors: torque and rotation speed.

Power is nil when the starter motor is idling (no load) and when it is in stall (locked).

Power is maximum at curve vertex.

Rated power is normally read at 2/3rds of the curve.

Torque curve

Torque is nil when the starter motor is idling and maximum when it is in stall.

Speed curve

Rotation speed curve is maximum when the starter motor is idling and is nil when it is in stall.

Voltage curve

It depends on the state of bench batteries and on current absorbed by the starter motor.

Should values read during bench test vary significantly from testing values, the starter motor is faulty.

Repeat the disassembling and checking sequence for each single component.

General information

The purpose of the starter motor is to convert the electric power produced by the battery (or batteries) into mechanical power that causes the engine to turn.

Basic data

Direct current starter motor operation is based on the magnetic induction principle.

"A conductor placed in a magnetic field and through which current is flowing is subject to a force which is proportional to magnetic field and current intensity. Such force reaches its peak value when magnetic field and conductor are at right angles."

In the starter motor the magnetic field is generated by the stator or fixed windings. The armature houses inductive windings which are immersed in the inductive magnetic field and crossed by current thereby developing a motive torque on the armature shaft.

Technical and practical hints

Excitation winding. It generates the electromagnetic field between the polar pieces into which the armature turns.

Field windings. This is the starter motor static system where the electromagnetic field is generated.


Field windings are series connected to the armature through the brushes and produce the starter motor lead-in torque.

They are secured to the frame by means of polar pieces.


Medium and high power windings consist of copper straps; insulation between each strap is ensured by a layer of paint. Ohmic winding resistance is less than 1 ohm.

Besides series connected field windings, high power starter motors are also provided with parallel connected winding enabling slow rotation and pinion feed in the flywheel coupling stage.


As soon as the best position is attained, an adequately located electrical contact enables the current to flow to field windings thus supplying the maximum armature lead-in torque.




II.35 PERSPECTIVE VIEW OF STARTER MOTOR



II.36 STARTER MOTOR WIRING DIAGRAM




II.37 FIELD WINDING




II.38 ARMATURE WINDINGS

2333



II.39 POLAR FRAME

2731



II.40 TORQUE PERFORMANCE DEPENDING ON VOLTAGE

2735

Armature winding. This winding is made up of several windings connected between each other by commutator segments.

The current flowing through windings via negative and positive brushes generates the starter motor driving torque.

Braking winding (starter motor with pinion translation). When the starter motor is cut off, this winding is short-circuited at the armature winding via a control relay contact; this way the starter motor is rapidly brought to rest position.

Clutch winding. This type of winding is present in relays provided with a retaining winding. It is short-circuited after contacts are closed.

Polar frame. Field windings are fastened to the frame by means of polar pieces. Its property is to increase the excitation field magnetic flux through its metal agglomerate.

Commutator. The commutator feeds direct current to the different armature winding sections via the brushes.

All ends of windings forming the armature winding lead to the commutator which is made up of copper blades insulated from each other by insulated segments.

Torque. This is the turning power that the starter motor transmits to the engine during the initial starting stage. Voltage at battery terminals affects the starting torque in a substantial way.

NOTE. Torque is zero when the starter motor is idling and is at its peak value when the starter motor is in stall.

Duration of the starting stage. Starter motor operation must be brief as its current absorption (about 450 A) affects the battery as a short circuit. Duration of the starting stage should not exceed 30 seconds.

Should the starting operation be repeated owing to particular conditions (e.g. low temperatures), leave batteries at rest for about 3 minutes.

Electromagnet (solenoid). Purpose of this electromagnet is to close the starter motor power circuit via the excitation current of its own coil and with a current absorption of several hundred amperes.

It consists of two windings:

- clutch winding
- retaining winding.

The first winding enables pinion fork and flywheel coupling.

The second one prevents pinion fork from getting detached from flywheel during the entire starting stage.

Armature. This is the rotating section of the starter motor housing the armature winding. It also includes the blade collector and the clutch pinion. Lead-in torque is generated inside the armature.

For correct operation of the armature the following conditions should be met:

- electrical insulation of armature winding from the sheet pack
- commutator insulation
- perfect seal of bushings at armature terminals.

Polar pieces. They increase the magnetic flux of the excitation field.


Pinion. This is a toothed wheel that engages with the flywheel ring gear during the starting stage thus conveying the torque generated by the armature to the crankshaft.

The flywheel ring gear is fitted with different types of clutches according to the required power value:


- translation and screwing of the armature spindle on the helical groove by means of a fork
- armature translation
- pinion translation.

Rated power. Starter motor rated power mainly depends on two factors: torque and rotation speed.


Rated power is generally read at 2/3rds of the curve and is calculated on the basis of a given temperature and a given battery capacity.



II.41 ELECTROMAGNET (SOLENOID)




II.42 POLAR PIECES




II.43 POWER PERFORMANCE DEPENDING ON VOLTAGE

2737


2738



II.41 ROLLER WHEEL
A. COUPLING STAGE - B. FREE STAGE



II.45 BRUSH HOLDER BRUSH PRESSURE ON COMMUTATOR IS THROUGH SPIRAL SPRING



II.46 RPM PERFORMANCE DEPENDING ON VOLTAGE

Koller free wheel. When the engine is running and pinion rpm increase (speed is higher than normal idling starter motor speed), the roller free wheel cuts in with the purpose of inhibiting transmission of torque supplied by armature to pinion.

Roller movement enables pinion/armature engagement and disengagement.

This is possible, during the starting stage, as pinion and armature move in the narrow section of a curved race.

In this condition the cylindrical section of the pinion becomes integral with the armature (torque transmission to engine flywheel) thus obstructing the free wheel guide.

As soon as the engine is started pinion rpm increase. Overcoming the force of the springs, the pinion moves the rollers to the larger section of the curved race thus separating pinion from armature.

Now the starter motor does not convey torque to the pinion. However, the pinion will remain in mesh with the engine flywheel until the ignition switch is turned off.

During the second part of the starting stage, springs return rollers to rest position - i.e. the narrow section of the free wheel guide - so that the pinion may be coupled securely to the armature.

Brushes. Purpose of the brushes is to connect the induced circuit and convey the electric current to the armature winding.

Reliability of the starter motor is based on brush length, quality and pressure on the commutator as well as on perfect sliding of the brush holder.

Furthermore, brushes must rest completely on the commutator and their entire surface must adhere to it.

Voltage. Voltage drop during the starting stage depends on starter motor current absorption and on battery capacity.

Minimum speed during starting stage. Starter motor rotation speed increases according to voltage present at battery terminals.

However; minimum speed -- below which Diesel engine starting is not ensured -- depends on ambient temperature.

Pre-engaged starter motors

Starter motors of this type are operated through electromagnet (solenoid) coupling.

The protruding end of the electromagnet is provided with a slit housing the coupling lever pin.

On pinion end the armature spindle has a helical groove with a driving nut which is in mesh with the pinion through the roller free wheel.

Helical groove enables pinion and flywheel coupling.

The driving nut is fitted with a guide ring connected to the above-mentioned coupling lever.

The spring is positioned between the guide ring and the driving nut.

Purpose of the spring is to enable the lever to complete its stroke thus closing both jumper and contact.


During the starting stage the lever pushes driving pin and pinion against the toothed wheel.

Owing to the helical groove, the pinion rotates and engages with the flywheel. The lever reaches its end of stroke and closes the power contact thereby transmitting the driving torque to the flywheel.


NOTE. Starting current stays on even if the pinion hits one of the ring gear teeth.

When the starting stage is over, the roller free wheel previously integral with the armature -- separates the armature from the pinion, in case engine rpm exceed starter motor rpm.

The coupling process consists of two stages: translation and engagement. However; starter motor coupling occurs in one stage only.




II.47 MINIMUM STARTING SPEED




II.48 STARTER MOTOR ASSEMBLY


A. PINION - B. FREE WHEEL - C. COUPLING LEVER - D. COUNTER SPRING - E. RETAINING WINDING - F. CLUTCH WINDING - G. FIELD WINDING - H. COMMUTATOR - I. ARMATURE - L. POLAR PIECE - M. COUPLING SPRING




II.49 HELICAL GROOVE



2746



2747



2748

Pinion engagement. As soon as terminal 50 of ignition switch is energized the coupling lever moves against the spring thereby inhibiting closing of armature and winding connection contacts.

As previously mentioned, the lever pushes the driving nut and the pinion against the ring gear; owing to the helical groove, driving nut and pinion rotate.

Translation. If the pinion finds a space between the flywheel teeth, it meshes with the ring gear as deeply as the coupling lever permits, that is until the jumper presses against the solenoid contacts. In this condition, pinion translation is completed (ref. B).

Should the pinion not engage with the ring gear (tooth against tooth), the coupling lever compresses the spring until it reaches the jumper contact stop: the starter motor starts to turn (rif. A).

The pinion slides on the tooth head and engages owing to the preloaded spring and to pressure produced by the helical groove screwing effect.

As solenoid contacts are closed when translation is completed, the armature – now rotating – pushes the toothed wheel pinion – owing to the helical groove – in contact with the armature spindle.

In this condition the pinion is integral with the armature spindle via the roller free wheel and enables the starter motor to operate the engine.

It should be remembered that the torque supplied by the starter motor is zero when the armature turns but its spindle slides on the flywheel tooth. Rotation speed in this case is only sufficient to carry out the coupling operation.

As soon as the pinion is in the coupling position – and is not therefore free to turn – the starter motor is opposed by the counter effect of the flywheel inertia and supplies the maximum torque required to start the engine.

Disengagement. The pinion remains in mesh until the coupling lever is held in connection position.

After the engine is started flywheel rpm are higher than pinion rpm; as this condition could impair starter motor efficiency, the free wheel cuts in to release the armature spindle from the pinion.


As soon as the ignition switch is disconnected driving nut and pinion return to their rest position under action of the counter spring.

Ignition switch with starter-assisted services

Specifications




MARELLI
NUMBER NR



SIPEA

1775

Daily-Turbodaily
Turbodaily 4x4



MARELLI

Q 213C

Daily-Turbodaily
Turbodaily 4x4


General directions

Supplier's name, manufacturing date, IVECO trademark must be stamped on the key switch.

The switch is supplied with two two-edged keys and manufacturer's code lock.

The steering lock cannot function unless the key has been set to position "0" (Stop) and removed from its seat.

The switch must be fitted with an antistarting repeater device.



19-12

WIRING DIAGRAM

Switching sequence

| Position | | | | Function |
|----------|----|-----|----|---|
| 0 | | | | |
| 30 | 15 | 15A | 50 | STOP Key can be removed |
| I | | | | |
| 30 | 15 | 15A | 50 | RUNNING Key cannot be removed |
| II | | | | |
| 30 | 15 | 15A | 50 | STARTING Key cannot be removed and will return automatically to position I |

Ignition switch for starter-assisted services

SIMPLIFIED DIAGNOSIS

Disconnect ignition switch connector blocks **A** and **B**:

Set multimeter to VOLT:


Ensure 12 Volts are available by setting one multimeter prod to terminal +30 of connector block **B** and the other one to earth.

Set multimeter to OHM.

Turn the key to position 15 and ensure the presence of 0 Ω by setting multimeter prods to terminals +30 and 15 of switch connector blocks.



Turn the key to position 50 and ensure the presence of 0 Ω by setting multimeter prods to terminals +30 and 50 of switch connector blocks.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Electrical System workshop manual Print no. 603.47.961
Diagram no. 1

KEY ROTATION DIRECTION



52502

LAYOUT WITH CONNECTIONS

5125

| Connector | Function | Cable colour |
|-----------------|---|--------------|
| A 1 (15) | Services | 1187 |
| 2 (50) | Starting | 8888 |
| B 1 (30) | Supply | 7777 |
| 2 (15/A) | Connection of relay for user cutoff during starting stage | 8850 |

Pre/after-heating electronic control unit (Daily vehicles)

SIMPLIFIED DIAGNOSIS

Engage parking brake and set transmission in neutral.
Disconnect connectors **A** and **C** from preheating control unit.
Set multimeter to VOLT.


Leave ignition switch in rest position. Ensure 12 Volts are available by setting one multimeter prod to connector **A** and the other one to earth.
Turn the key to position 15 and ensure the presence of 12 Volts by setting one multimeter prod to terminal 3 of connector **C** and the other one to earth.

Turn the key to position 50 and ensure the presence of 12 Volts by setting one multimeter prod to terminal 4 of connector **C** and the other one to earth.

Set multimeter to OHM.


Set ignition switch to rest position. Ensure the presence of 0 Ω by setting one multimeter prod to terminal 2 of connector **C** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 2

86011




LAYOUT WITH CONNECTIONS

| Connector | | Function | Cable colour |
|-----------|---|--------------------------------------|--------------|
| A | 1 | Supply (+30) | 8875 |
| B | 5 | To thermostarter | 8870 |
| C | 2 | Earth | 0000 |
| | 3 | Positive after ignition switch (+15) | 8870 |
| | 4 | Positive after ignition switch (+50) | 8888 |
| | 6 | To preheating warning lamp | 5553 |


Pre/after-heating electronic control unit (Daily vehicles)

86011




5127

CONNECTOR END VIEW



5128

FRONT VIEW



5129

PREHEATING TIME PERFORMANCE CURVE

| Preheating curve area | Description |
|-----------------------|--|
| A | Period during which both warning lamp and preheating system are in operation |
| B | Tolerance field during which the warning lamp goes out while preheating remains on |
| C | Period during which the warning lamp is off and preheating is on. This 15 to 20 secs. steadily operative stage is calculated from the moment the warning lamp is switched off |
| D | After heating period with plugs on and warning lamp off. This 15 to 20 secs. steadily operative is calculated from the moment the starting stage is over (with engine running) |
| E | Period during which both warning lamp and preheating are off |

Pre/after-heating electronic control unit (Turbodaily vehicles)

SIMPLIFIED DIAGNOSIS

Engage parking brake and set transmission in neutral.

Disconnect connectors **A** and **B** from preheating control unit and hood/engine loom junction block.

Set multimeter to VOLT.

Leave ignition switch in rest position. Ensure 12 Volts are available by setting one multimeter prod to terminal 1 of connector **A** (+30) and the other one to earth.


Turn the key to position 15 and ensure the presence of 12 Volts by setting one multimeter prod to terminal 2 of connector **B** (15) and the other one to earth.

Turn the key to position 50 and ensure the presence of 12 Volts by setting one multimeter prod to terminal 3 of connector **B** (50) and the other one to earth.

Set multimeter to OHM.


Set ignition switch to rest position. Ensure the presence of 0 Ω by setting one multimeter prod to terminal 4 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.




Print no. 603.42.961 Diagram no. 2

86011




LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | 1 (30) : Supply (+30) | 8870 |
| | 2 (FGK) : To thermostarter | 8870 |
| | 3 (T) : To radiator motor water temperature sender unit | 5577 |
| | 4 (31) : Earth | 0000 |
| B | 1 - : Not used | - |
| | 2 (15) : Positive after the ignition switch (15) | 8870 |
| | 3 (50) : Positive after the ignition switch (50) | 8888 |
| | 4 (L) : To preheating on warning lamp | 5553 |
| | 5 - : Not used | - |
| | 6 (MV) : To fuel delivery solenoid valve | 9972 |



11.51 PREHEATING TIME AS A FUNCTION OF VOLTAGE AT FGK TERMINAL



11.52 AFTER-HEATING TIME RESULTING FROM THE SUM OF COOLER TOLERANCE AND TEMPERATURE SENSOR TOLERANCES

Operation and specifications

The electronic control unit is protected against the following external faults:

- inverted polarity
- thermostarter shortcircuit
- temperature sensor shortcircuit
- warning lamp shortcircuit
- supply voltage value higher than rated voltage (24 instead of 12V).

Both thermostarter and solenoid valve are always supplied with direct voltage (intermittent supply is not available).

The control unit cuts in automatically when sensor resistance is $>2150 -4\%+2\% \Omega$ (2064 - 2173 Ω).

Automatic cut-in temperature resulting from the sum of control unit and temperature sensor tolerances ranges from zero to +4 °C.

After-heating time depends on sensor resistance:

| Resistance | After-heating |
|---------------|--|
| 2390 Ω | 72 \pm 3,6 s |
| 3790 Ω | 84 \pm 4,2 s |
| 6200 Ω | 104 \pm 5,2 s |
| ∞ | ~ 250 s (WEHRLE) ~ 300 s (ITALAMEC) |

Characteristic values of the thermostarter electronic control unit change with reference to resistance and the type of engine coolant temperature sender unit (see figure 11.52).

I - Automatic thermostarter cut-in stage with ignition switch in position +15 (services)

With coolant temperature exceeding the present operation value, the system is off (the warning lamp only turns on for about 2 seconds for initial checking purposes).


The system is anable when the engine coolant temperature is lower than the preset value (the warning lamp remains on throughout the preheating time)

Thermostarter

SIMPLIFIED DIAGNOSIS


Disconnect connector **A** from thermostarter.
Set multimeter to OHM.

Set ignition switch to rest position. Check for 0 Ω by setting one multimeter prod to connector **A** (+30) and the other one to terminal 2 of connector **A** of pre/after heating electronic control unit (page II.31).
If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 2

19010



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|----------------------|--------------|
| A | Thermostarter supply | 8870 |


Preheating system operation switch (Turbodaily vehicles)

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from switch.
Set multimeter to OHM.


Set ignition switch to rest position. Check for 0 Ω by setting one multimeter prod to connector **A** and the other one to terminal 3 of connector **A** of pre/after heating electronic control unit (page 11.31).

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 2

47105



3558

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--------------------|--------------|
| A | Temperature signal | 5577 |

2° Thermostarter preheating stage

Thermostarter is supplied with direct voltage.

Fuel delivery solenoid valve is not energized.

Preheating warning lamp is on (when it goes off preheating is completed and the engine can be started).

Duration of preheating time (in seconds) depends on voltage value at FGK terminal of the electronic control unit (diagram in figure II.51 page II.32).

3° Automatic cut-off time

- When the preheating warning lamp goes off, the thermostarter is still supplied for 30±8 seconds after which, if engine starting has not occurred, the thermostarter is turned off by the electronic control unit.

Warning lamp operation sequence

| Engine coolant temperature | Operation/function | W/lamp on | | Thermostarter on | | Solenoid valve on | |
|--|--|-----------|----|------------------|----|-------------------|----|
| | | YES | NO | YES | NO | YES | NO |
| Higher than preset value for preheating cut-in | Turn ignition key, starting switch in running position (voltage at terminal "15") | ● | ▲ | | ● | | ● |
| | After 2±0.2 seconds | | | | ● | | ● |
| | Turn ignition key, starting switch in running position (voltage at terminal "15") | ● | | ● | | | ● |
| | After 2 seconds | ● | | ● | | | ● |
| Lower than preset value for preheating cut-in | Preheating stage (duration according to diagram) | ● | | ● | | | ● |
| | Starter motor is actuated before preheating stage is completed (warning lamp on. This incorrect operation is inhibited; the control unit is reset) | | ● | | ● | | ● |
| | End of preheating stage | | ● | ● | | | ● |
| | If starting is not performed within 30±1.5 secs. from end of preheating stage (waiting time) | | ● | | ● | | ● |
| | Engine starting stage (lasting throughout starter motor turning time) | ● | | ● | | ● | |
| | Air heating in intake manifold, engine started (after heating) | ● | | ● | | ● | |
| | End of after-heating stage | | ● | | ● | | ● |

* Warning lamp goes out when test is completed or if 15 is not supplied (W/HRLE).

▲ Warning lamp remains on throughout test duration even if 15 is not supplied (ITALAMEC).

4 Engine starting stage

Thermostarter, fuel delivery solenoid valve and warning lamp remain on throughout the engine starting stage.

5° Air heating in the intake manifold iwth engine started (after-heating stage)

When starter motor is turned off, thermostarter, fuel delivery solenoid valve and warning lamp remain on for the time shown on the table below. This depends on engine coolant temperature.



If engine starting is performed before preheating is completed (warning lamp on) the electronic control unit returns to zero and the warning lamp is turned off.

The control unit does not signal thermostarter and/or fuel delivery solenoid valve failure.

The following table refers to the failure code (blink code) that is to say to warning lamp operation sequence.

Failure Code (Blink Code)

| Circuit under examination | System and/or component | Defect | Fault diagnosis from warning lamp | | | | | Diagnosis duration | | |
|--------------------------------------|-------------------------|---|-----------------------------------|-----------------------------------|-------------------|----------|-------------------|--------------------|----------------------------------|-------------------------------|
| | | | Type of signal | | Operation | | | 60 secs | Until key switch is cut off "15" | Until control unit is cut off |
| | | | W/lamp off | W/lamp blinking 1 Hz 4 Hz | Key position "15" | Starting | After-heating end | | | |
| | | Inverted polarity | ● | | | | | | | |
| | | Supply voltage higher than rated voltage (24V instead of 12V) | ● | | | | | | | |
| | | Supply failure "30" | | ● | | ● | | | ● | |
| | | Supply failure "15" | ● | | | | | | | |
| Defects outside control unit circuit | Thermostarters | Break | | ● | | ● | | | ● | |
| | | Shortcircuit | | ● | | ● | | | ● | |
| | Solenoid valve | Break | | ● | | ● | | | ● | |
| | | Shortcircuit | ● | | | | ● | | | |
| | Temperature sensor | Break | | ● | | | | ● | ● | |
| | Warning lamp | Break | ● | | | | | | | |
| | | Shortcircuit | ● | | | | | | | |
| Defect inside control unit circuit | Thermostarter relay | Contacts not closed | | | ● | ● | | | ● | |
| | | Contacts stuck | | | ● | | | ● | | ● |
| | Solenoid valve relay | Contacts not closed | | | ● | | ● | | ● | |
| | | Contacts stuck | | | ● | | | ● | | ● |

Thermostarter – Solenoid valve for connection to atmosphere from fuel tank (Turbodaily vehicles)


SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from solenoid valve.

Set multimeter to OHM.


Set ignition switch to rest position. Check for 0 Ω by setting one multimeter prod to connector **A** and the other one to terminal 6 of connector **A** of pre/after heating electronic control unit (page II.31).

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 7

78000



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--|--------------|
| A | Supply of fuel delivery solenoid valve | 9972 |


Engine stopping solenoid valve

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from solenoid valve.
Set multimeter to VOLT.


Set ignition switch to position 15. Check for 12 V by setting one multi-meter prod to connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 1

28002



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|------------------------------------|--------------|
| A | Supply of engine stopping solenoid | 9903 |

GCR (General Current Relay) closing switch (bus)

SIMPLIFIED DIAGNOSIS


Disconnect connector **A** from switch.
Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 6 of connector **A** and the other one to earth.

Check for 0 Ω by setting one multimeter prod to terminal 5 of connector **A** and the other one to earth.


Press switch key and check for 0 Ω by setting one multimeter prod to terminals 1/5 and the other one to terminals 2/6.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 1

53023



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|--|--------------|
| 1 | To swing sliding door control device | 0000 |
| 2 | GCR operation control device | 0012 |
| 3 | --- | — |
| 4 | --- | — |
| A 5 | Earth | 0000 |
| 6 | Earth for GCR operation control device | 0012 |
| 7 | --- | — |
| 8 | --- | — |
| 9 | Supply (+15/A) of switch lighting | 8879 |
| 10 | Earth | 0000 |

General Current Relay (GCR) (bus)

SIMPLIFIED DIAGNOSIS

Transmission in neutral, parking brake engaged.

Disconnect connector **A** from GCR.

Set multimeter to OHM.

Operate GCR closing switch. Check for 0 Ω by setting one multimeter prod to terminal of connector **A** and the other one to earth.


Disconnect connector **B** from GCR and reconnect connector **A** to GCR.

Set multimeter to Volts.

Operate GCR closing switch. Check for 12V by setting one multimeter prod to the GCR terminal (from which connector **B** has just been removed) and the other one to earth.


If readings are other than specified, remedy as required by either repairing the circuit or replacing the component.

Then repeat the test.



Print no. 603.42.961 Diagram no. 1

25900



5136

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--|--------------|
| A | GCR connector block | 0012 |
| B | Supply of starter motor, ignition switch and C.I.U. | 7777 |
| C | To battery positive terminal | 7777 |
| D | Supply (battery +) for safety unit switch and tachometer | 7777 |
| E | Positive for GCR coil | 7777 |

GCR opening switch (bus)

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from switch.


Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 6 of C.I.U. connector **A** and the other one to terminal 1 of connector **A**.

If reading is other than specified, repeat the test by setting multimeter prod to terminal 2 of connector **A**.


Check for 0 Ω by setting multimeter prods directly to terminals 1 and 2 of the switch.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 1

53009



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | 1 To safety unit switch | 0000 |
| | 2 Control device for opening GCR energizing relay | 0000 |

Safety unit control switch (bus)

SAFETY UNIT (BUS) 52029

Disconnect connectors **A** and **B** from switch.
Set multimeter to Volts


Check for 12 V by setting one multimeter prod to terminal 5 of connector **B** and the other one to earth.

Operate the GCR closing switch and turn the ignition switch in position 15.

Check for 12 V by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.


Repeat the same test with terminal 4 of connector **B**.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 1

52029



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--|--------------|
| A | 1 Supply (+15) of engine stopping solenoid | 9903 |
| | 2 To engine stopping solenoid | 9903 |
| | 3 Hazard lights on indicator | 1111 |
| | 4 Earth | 0000 |
| B | 1 To GCR opening switch | 0000 |
| | 2 Control device for connection of hazard and interior lighting with safety unit switch on | 7772 |
| | 3 earth | 0000 |
| | 4 To terminal 12 of C.I.U. connector D | 0000 |
| | 5 Supply (battery +) | 7772 |
| | 6 To GCR closing switch | 0012 |

Main current switch

SIMPLIFIED DIAGNOSIS

Turn main current switch (MCS) handle in circuit opening position.

Set multimeter to OHM.

Ensure infinite resistance is available by setting multimeter prods to MCS terminals.


Turn handle by 90°. Check for 0 Ω (zero ohm) by setting multimeter prods to MCS terminals.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 1

52600



2/03

* TO BATTERY NEGATIVE TERMINAL

** TO CRANKCASE EARTH POINT

LAYOUT WITH CONNECTIONS

Description

Supplier's name and identification letters/numbers, device serial no. and production date according to IVECO STD. 10-0812 (N.P.0.00013) should be stamped on the switch.

Handle operating torque
Max locking thickness

1,5 ÷ 2 Nm
12 mm

TO CLOSE CONTACTS TURN HANDLE 90° CLOCKWISE

Heated fuel filter

1. Connect connector **A** from fuel filter.

2. Connect connector **A** from fuel filter.


3. Set multimeter to OHM.

4. Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to C.I.U. connector E terminal 1.

5. Disconnect connector **B** from fuel filter.

6. Check for 0 Ω by setting one multimeter prod to terminal B of connector **B** and the other one to C.I.U. connector F terminal 6.


7. If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 2

47106

61101



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|-------------------------------------|--------------|
| A | 1 Fuel heating relay control device | 8832 |
| | 2 Earth of fuel heating switch | 0000 |
| B | A Earth of fuel heating resistance | 0000 |
| | B Supply of fuel heating resistance | 7733 |

Ignition timer operation switch


SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from switch.

Set multimeter to OHM.


Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to C.I.U. connector terminal 6.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 2

47109



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | 1 To ignition timer variable resistance | 8848 |
| | 2 Supply (+15) | 8848 |

Ignition timer variable resistance


SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from resistor:

Set multimeter to OHM.


Check for 0 Ω by setting one multimeter prod to terminal **I** of ignition timer switch connector and the other one to connector **A**.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 2

61103



5141

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|--|--------------|
| A I | Supply (+15) of variable resistor with ignition timer switch | 8848 |


CHARGING

| | Page |
|--|------|
| ALTERNATORS | 3 |
| SPECIFICATIONS | 3 |
| TESTS | 8 |
| TESTING MAX CURRENT OUTPUT | 8 |
| TESTING VOLTAGE DROP IN CHARGING CIRCUIT | 8 |
| TESTING VOLTAGE DROP IN EARTH CIRCUIT | 9 |
| VOLTAGE REGULATOR CALIBRATION TEST | 9 |
| ALTERNATOR DRIVE BELT TENSIONING | 9 |
| DISMANTLING AND BENCH TESTING | 10 |
| REASSEMBLY | 10 |
| CHARGING CIRCUIT | 11 |
| GENERAL | 11 |
| BASIC DATA | 11 |
| TECHNICAL/PRACTICAL HINTS | 13 |
| ELECTRONIC VOLTAGE REGULATOR | 19 |
| THEORETICAL OPERATION | 21 |
| VOLTMETER | 22 |

CHARGING

Alternators


Specifications



021

MARELLI


AA125R 14V-55A



044

BOSCH


KI → 14V 23/55A



047

BOSCH

KI → 14V 50-90A




023

BOSCH

KI → 14V 50-90A

Quick diagnosis

| Defect | Possible cause | Remedy |
|---|---|--|
| No charging | 1. Break in charging circuit (warning light, thermoswitch, connector; ecc.) | Check charging circuit connection, clean and tighten terminals at alternator and battery (or batteries). |
| | 2. Voltage regulator not working properly | Replace the component |
| | 3. Rotor winding broken | Replace the component |
| | 5. Brushes worn | Replace the component |
| | Low charging | 1. Belt loose |
| 2. Voltage regulator defective | | Replace the component |
| 3. Excess wear of rotor rings or brushes | | Replace the component |
| 4. Diodes shortcircuited | | Replace the component |
| 5. Stator windings or rotor windings shortcircuited | | Replace the component |
| Excessive charging | 1. Circuit connections loose | Check connections to terminals and wire terminals for battery, starter motor and alternator |
| | 2. Voltage regulator not working properly | Replace the component |
| | 3. Earth defect | Check earth connections |



Supplier

MARTELL

Model

AA125R 11V 35A

Type

startthreephase, claw type rotor, 9-diode rectifier and built-in voltage regulator


Direction of rotation (drive side)

clockwise

Rated voltage


14 V

03000




201

WIRING DIAGRAM



202

LAYOUT WITH CONNECTIONS



1. NUT AND WASHERS

2. FAN

3. SPACER

4. SUPPORT

5. KEY

6. ROTOR

7. STATOR

8. STAY ROD

9. SUPPORT

10. RECTIFIER BRIDGE



11. VOLTAGE REGULATOR

12. COVER

EXPLODED VIEW


Supplier BOSCH
 Model KI 14V - 23/55A
 Type three-phase, claw type rotor, 9-diode rectifier and built in electronic voltage regulator
 Direction of rotation (drive side) clockwise
 Rated voltage 14V

03000



WIRING DIAGRAM

LAYOUT WITH CONNECTIONS



1. NUT AND WASHERS
2. PULLEY
3. FAN
4. SCREW
5. SUPPORT
6. BALL BEARING
7. SCREW
8. PLATE
9. KEY
10. ROTOR
11. RING
12. BEARING
13. O RING
14. STATOR
15. SCREW
16. RECTIFIER BRIDGE
17. BUSH
18. INSULATING BUSHES
19. SUPPORT
20. CAPACITOR
21. WASHER
22. SCREW
23. VOLTAGE REGULATOR
24. SCREW

EXPLODED VIEW

Supplier

BOSCH

Model

KC - 14V 50-90A

Type

threephase, claw type rotor; 9 diode rectifier and built-in electronic voltage regulator


Direction of rotation (drive side)

clockwise

Rated voltage


14V

03000




5118

WIRING DIAGRAM



5116

LAYOUT WITH CONNECTIONS




1. NUT
2. SPRING WASHER
3. PULLEY
4. SPACER
5. SCREW
6. SUPPORT
7. BALL BEARING
8. PLATE
9. ROTOR
10. BALL BEARING
11. RING
12. STATOR
13. BUSH
14. SUPPORT
15. SCREW
16. VOLTAGE REGULATOR
17. BRUSH ASSSEMBLY
18. SCREW
19. RECTIFIER BRIDGE
20. SCREW
21. SUPPORT
22. SCREW


EXPLODED VIEW

Supplier BOSCH
 Model KC - 14V - 90A
 Type threephase, claw type rotor; 9 diode rectifier and built in electronic voltage regulator
 Direction of rotation (drive side) clockwise
 Rated voltage


03000




WIRING DIAGRAM



LAYOUT WITH CONNECTIONS




1. END
2. SPRING WASHER
3. PULLEY
4. SPACER
5. SCREW
6. SUPPORT
7. BALL BEARING
8. HALE
9. ROTOR
10. BALL BEARING
11. END
12. STATOR
13. BUSH
14. SUPPORT
15. SCREW
16. VOLTAGE REGULATOR
17. BRUSH ASSEMBLY
18. SCREW
19. RECTIFIER BRIDGE
20. SCREW
21. SUPPORT
22. SCREW




5150

III.1 MAXIMUM OUTPUT TEST



III.2 TESTING VOLTAGE DROP OF CHARGING CIRCUIT



III.3 TESTING VOLTAGE DROP ON EARTH CIRCUIT

TESTS

Testing maximum output on vehicle



Never let the engine run with the electrical connections for the charging circuit disconnected or slack at the battery terminals.

Proceed as follows:

- Connect clamps for cables of the "Electrical System Test" equipment 99309003 to battery terminals observing polarity (fig. III.1).
- Position the test selector in INT (internal).
- Fit the inductive clamp to the main alternator cable, observing polarity and direction of the arrow (stamped on the clamp).
- Start up the engine and rev it up.
- Actuate the load rheostat lever until the reading on the ammeter is equal to the maximum alternator output value.
- Press the ammeter operation switch using the inductive clamp.

Check the battery voltage and the alternator current.

These values should be the same, within 10%, as far as charging current is concerned.

The voltage reading should correspond to calibration figures recommended by the Manufacturer.

If alternator output values are low and the warning light signalling a defective diode (DEFECT) located between the two digital indicators comes on, the cause may be due to a defective diode or a broken alternator field.

Testing voltage drop in the circuit

Proceed as follows:

- Connect the main equipment cables to the batteries observing polarity (fig. III.2).
- Connect the outer voltmeter with the negative clamp to the battery POSITIVE terminal and the positive clamp to 30 or B+ of alternator. Position the test selector on EST (external).
- Connect the inductive clamp to the alternator cable observing polarity and arrow direction.
- Rev up the engine until current output is 10 A.

Check the reading on the voltmeter: it should not exceed 0.6 V if circuit and connections are in good working order.

Voltage drop test on earth circuit

Proceed as follows:

Connect main equipment cables to batteries observing polarity (fig. III.3).

Connect the outer voltmeter with the negative clamp to the alternator body and the positive clamp to the battery negative terminal.

Position the selector on EST (external).

Connect the inductive clamp to the alternator cable observing polarity and arrow direction.

Rev up until current output is 10A.

Check that the reading on the voltmeter is zero, if connections are satisfactory.

Voltage regulator calibration test

Proceed as follows:

Connect outer voltmeter leads to battery terminals observing polarity (fig. III.4).

Position selector on EST (external).

Connect the inductive clamp to the alternator cable observing polarity and arrow direction.

Start the engine and rev it up slightly until the ammeter reading is a little less than 8 A.

Ensure the reading on the voltmeter corresponds to the figure recommended by the Manufacturer.

Tensioning alternator belt


Proceed as follows:

Slacken nuts fixing alternator support and tensioning bracket (fig. III.5).


Introduce a lever between the alternator and the engine in order to suitably tension the drive belt.

Tighten both alternator fixing nuts, starting with the one in the adjustment slot.


Check that the belt sags by 10 mm. approx. if pressure is applied to its centre area.




III.4 VOLTAGE REGULATOR CALIBRATION TEST



III.5 TENSIONING ALTERNATOR DRIVE BELT





III.7 BENCH TEST

If faults are detected in a generator (alternator) during the previous diagnostic checks on the vehicle, then it must be bench tested.

This involves removing the alternator from the vehicle or the engine in order to eliminate the problem(s) with the aid of suitable tools or equipment and following the Manufacturer's instructions.

Dismantling and bench testing

Lock the alternator pulley in a vice with lead caps. Dismantle the alternator following the instruction given on the pages which follow.

NOTE. In order to facilitate certain dismantling operations, simply use a plastic hammer.

When the pulley has been removed, withdraw the washer, the fan, the key and the spacer.

Remove the brush holder taking care not to break or damage it.

Remove the rods and washers and remove the rectifier side support, tapping the rotor shaft lightly with the plastic hammer.

Remove the rotor by tapping lightly with the plastic hammer on the edge of the rectifier end mounting.

Carefully unsolder the three phases with the aid of pliers, in order to dissipate part of the heat and prevent overheating.

When dismantling a component, quickly wash the parts using liquid for electrical components, protect the parts with a plastic bag.



On account of their volatility observe the safety regulations for inflammable liquids and wear the special goggles and protective gloves.

Carefully dry the parts which have been washed using compressed air (about 4 bar) and dry rags.

Make sure the parts do not show signs of wear or damage. The parts which are damaged, short-circuited or worn, should be replaced like the brushes, seals and washers.

Continue the checks using the multimeter with the parts resting on a work surface which is insulated by the bench earth.

Particular attention should be paid during the insulation tests for the stator and the rotor. If the insulation of the rotor between the slip rings and the poles is insufficient, replace the rotor.

The insulation between any of the phases and the stator assembly should be perfect: if this is not the case, replace it.

The power diodes should be checked, one by one, for direct and reverse polarity.

If the values are incorrect, the rectifier should be replaced.

The exciter winding should also be checked using an ohmmeter: if the values are abnormal, the rotor should be replaced.

If the bearings need replacing, this should be carried out using new bearings which are hermetically sealed with grease.

If during the visual inspection the rotor slip rings show signs of grooves or excess wear the rotor should be replaced.

Reassembly

When refitting, after having carefully welded the phases, make sure that terminal 30 or B+ is properly insulated. Also check the seal of the O-ring in the rectifier end mounting bearing.

Lubricate the rotor shaft moderately and assemble the control end mounting fixing the alternator with the rods.

After refitting, check that the rotor rotates freely and insulation of terminal 30 or B+.

If, during the test, the values differ considerably from the typical curve, dismantle it once again and repeat the checks.

NOTE. The bench test values depend greatly on the battery charge conditions and capacity and the length of the test, which should be as short as possible. The curve shows that at low speeds, the current output is nil which it reaches the maximum value of around 3000 rpm. Start the test from the level of the voltage (respectively of the rotor speed) (self-excitation).

The nominal current output is usually measured at 2000 or the engine.

Charging circuit

General

The efficiency of the electrical system depends on the state of charge of the batteries and on the voltage regulator (alternator).

The alternator takes mechanical energy from the engine and transforms it into electric energy.

Basic data

The principle on which the alternator operates is the application of the law of electromagnetic induction:

"In a fixed conductor immersed in a variable magnetic field an electromotive force (EMF) is generated for the lines of force of the field and the speed".

The variable magnetic field in a threephase alternator is composed of the number of NS magnetic poles arranged in alternating order and of an exciter winding; the rotor:

The system continuous voltage starts at the exciter winding and includes:


- the ignition switch
- the control panel protective thermoswitch
- the charging warning light
- a possible insulation diode
- the alternator D+ terminal
- the voltage regulator.

When the ignition is switched on, the energizing current from the batteries circulates in the winding, generating an electromagnetic field in which it reinforces the residual force lines for the magnetic poles.


If the rotor turns, the field generates an alternating, sinusoidal voltage in the alternator fixed windings.

The density of the electromagnetic field which is generated in the exciter winding depends on the intensity of the current flowing through it.


This current is limited by means of an adjustment device, dealt with later in this chapter.




III.8 EMF GENERATOR IN A FIXED CONDUCTOR IMMERSIED IN A VARIABLE MAGNETIC FIELD



III.9 EMF GENERATOR IN A FIXED CONDUCTOR IMMERSIED IN A VARIABLE MAGNETIC FIELD




III.10 NO EMF (AS THE LINES OF FORCE ARE PARALLEL TO THE FIXED CONDUCTOR)




2833

III.11 CLAW-TYPE ROTOR: N-S POLAR EXPANSIONS



2834

III.12 CLAW-TYPE ROTOR: EXCITER WINDING MARKED IN BLACK



2835

III.13 ROTOR ENERGIZING CIRCUIT DIAGRAM
 A. BATTERY - B. IGNITION SWITCH - C. FUSE - D. WARNING LAMP - E. DIODE - F. ALTERNATOR

The alternator stator (or fixed) windings (fig. III.12, page III.14), where the EMF is generated, are equal to and independent of one another:

The windings are arranged with an angular opening of 120° in such a way as to give rise to three alternating voltages, offset by 120°, with the same intensity and frequency (fig. III.14).

The stator winding coils are arranged in a preset manner in a special support known as the stator:

The current, generated by the three stator windings, is completely unsuitable for recharging the battery and for operating the electronic components on board the vehicle.

For this reason, the three phases are suitably converted, by means of a diode bridge, into direct current.

In reality, the wave form of the continuous voltage measured at the generator terminals, is pulsating (fig. III.15).

Instant variations of induced voltages depend on the state of charge of on-board batteries and on changes in engine speed values.

Charge variations at the generator, due to the state of charge of the batteries and the connectors engaged, as well as variations in engine speed, cause the induced voltage values in the stator windings to change moment by moment.

In order to keep these variations within pre-established limits, there is a device which regulates the rotor winding energizing current.

Regulation of the maximum intensity of the current generated in the stator windings is virtually automatic in as far as their apparent resistance increases proportionally with the rotor rotation speed.

This very effectively limits the generator output curve.

This phenomenon is shown by the typical curve usually found in service manuals.

It should be noted that the current intensity curve, though based on the rev number, starting from a certain speed remains practically parallel to the rpm axis (fig. III.16).

Technical/practical hints

Self-excitation. The alternator supplying a direct current (with the aid of its diodes) is capable of self excitation.

For this reason, disconnected from the battery, the alternator supplies a very high continuous voltage which is dangerous for both the system and the vehicle's electrical and electronic components.

Therefore, NEVER disconnect the batteries with the engine running.

Exciter or rotor winding. The exciter winding is the alternator's dynamic system where the direct current passes through and generates the lines of electromagnetic forces.

The ohmic resistance of the rotor winding varies according to rotor type and output characteristics.

The exciter winding is insulated from the rotor casing.

Armature or field (stator) windings. This is the alternator static system where the induced electromotive forces are generated.

Connections between field windings may be of the star or delta type.


Star type connection. The alternator line voltage is obtained from the product of the voltage of one of the three field windings multiplied by 1.732 (fig. III.21 page III.15).

The resulting current is equal to the current circulating in one of the three windings.


Delta type connection. The alternator line voltage is equal to the voltage of one of the three field windings (fig. III.21 page III.15).

The current value is obtained from the product of the current circulating in one of the three windings multiplied by 1.732.


Alternators with Delta type connections should be installed on vehicles featuring high current consumption.



III.14 THREEPHASE SINUSOIDAL VOLTAGE OFFSET 120°




III.15 CONTINUOUS PULSATING VOLTAGE DOWNSTREAM OF A DIODE BRIDGE. A. NO LOAD B. CHARGE



III.16 TYPICAL OUTPUT CURVE
A. WORKING CURRENT (2/3 OF MAXIMUM CURRENT)


III.17 CHARGING CIRCUIT



5156


III.17 CHARGING CIRCUIT

A. ALTERNATOR - B. SYSTEM - C. BATTERIES



5157

III.18 SLIP RINGS



5158

III.19 STATOR FOR THREE-PHASE ALTERNATOR

Belt. The belt, usually a flat type, is used for the transmission of the mechanical energy from the engine to the alternator.

The condition of the belt and its correct tension are vital to the efficiency of the alternator.

Make sure the belt does not yield by more than 10 mm when the relevant force (varying from type to type) is applied to it.

Capacitor. The capacitor is of the electrolytic type and its value usually ranges between 2.2 and 3 μF . It is connected between terminal B+ and the alternator casing if the latter is not of the insulated type.

If, however, the characteristic whistling noise of the current output from the radio persists, a suitable size lowpass coil should be connected in series to the radio equipment supply cable.

Also make sure that the reception aerial is duly earthed.

Energizing current. This is the direct current which flows through the exciter or rotor winding.

Its values may vary from a minimum of 200 mA (current limited by the resistance of the charging warning light) to a maximum of 2A (current limited by the voltage regulator) according to the state of the battery charge.

Maximum current. This is the maximum current which the alternator can supply. This information is usually given on the alternator casing and on the typical curve.

The nominal power of the alternator in Watts (W) is obtained from the product of the maximum current and the nominal voltage of the system.

Working current. The working current (at which the alternator chooses to operate) is obtained from 2/3 of the typical output curve.

Typical curve. The typical curve graphically reproduces the trend of the current output based on the alternator speed.

The curve shown in figure III.16 page III.13 shows that at minimum speed the current output is nil as the alternator is connected to the batteries via terminal B+ and is therefore connected with the nominal voltage. As the rpm number increases, the output curve reaches its maximum level at around 4500 rpm.

The working current is usually fixed at 2/3 of the typical curve: this value should always be higher than the overall current consumption figure of all on-board connectors with the exception of the starter motor.

A typical curve diagram should always be available while a bench test of the alternator is performed.

Exciter diodes. Exciter diodes have very little power (1 to 3 A). They lead to the field windings and are aimed at rectifying the current required for correct operation of the voltage regulator.

Exciter diodes are usually located on an insulated plate inside the alternator; heat dissipation is not required in view of the very slight current absorption.


A break or short circuit in any one of the diodes implies that the charging current is not working properly; they should be checked with the alternator dismantled, using an ohmmeter set on a scale of ohm x 1.

Power diodes. The power diodes are used to convert the alternating current into direct current; they are usually made from silicon as are resistant to high temperatures (175° C).


Power diodes are press fitted onto supports which act as heat dissipators; the positive diode is insulated by the alternator earth.

When an alternator with terminal B- insulated from the chassis earth is used (generally on buses or vehicles carrying dangerous materials), then both diode supports are insulated from the alternator body.


A break or short circuit in one or more of the power diodes implies that the charging circuit is not working properly; they should be checked, with the alternator dismantled, using an ohmmeter set on a scale of ohm x 1.




III.20 STAR CONNECTION
A₁ A₂ A₃ BRANCH POINTS - P₁ P₂ P₃ WINDING TERMINALS
 $V = V_f \times 1.732$ $I = I_f$



III.21 DELTA CONNECTION
A₁ A₂ A₃ BRANCH POINTS - P₁ P₂ P₃ WINDING TERMINALS
 $I = I_f \times 1.732$ $V = V_f$




III.22 ANTIJAMMING NETWORK
A. CAPACITOR - B. FILTER - C. RADIO




2845

III.23 ALTERNATOR NOMINAL CHARACTERISTICS
 KI, TYPE → CLOCKWISE ROTATION – 14V, NOMINAL VOLTAGE – 23, WORKING CURRENT RPM (23x100=G/M) – 55A, NOMINAL CURRENT



2846

III.24 DIODE
 A. SYMBOL – B. HALF-WAVE RECTIFIER
 C. TECHNICAL DIAGRAM



2847

III.25 CLAW-TYPE ROTOR AND RELEVANT LINES OF FORCE

Electromotive force (EMF). This is a physical phenomenon through which it is possible to maintain a difference in electrical potential between two points in an open electrical circuit or to allow a current to flow through a closed circuit.

Its physical size is a voltage expressed in volts (V).

Frequency. The frequency is the number of cycles which are reproduced in a second. It is expressed in Hertz (Hz).

The frequency is inversely proportional to the period T.

The period T is the length of time during which a wave form passes through the same values.

The link between time and frequency is: $f = 1/T$.

A sinusoidal signal, at a given frequency, can give rise to interference with the radio equipment.

In order to minimize this interference, an electrolytic capacitor is fitted on terminal B+ of the alternator.

Lines of force. The lines of force are imaginary lines which indicate the direction of the force. The different lines of force in a space make up the field of force or magnetic field.

They are further increased if the magnet is immersed in a coil in which a direct current is flowing.

Terminal W. Bosch alternators types GI, KI, NI and TI have a terminal marked with the letter W where there is an alternating voltage whose frequency depends on the rotor coupling and the alternator revs conforming to the equation:

$$f = \frac{P \cdot n}{60}$$

where **f** is the frequency, **P** is the polar coupling and **n** the alternator rpm.

Terminal W is usually used for the indirect measurement of the speed in diesel engines.

Residual magnetism. This is the magnetism which remains in a magnetic iron casing after the magnetic force has been removed.

Brush holders. The two brushes make the connection between terminal D+, exciter diodes and voltage regulator with the exciter winding via the slip rings.

The minimum length for the brushes is usually 7 mm.

The brush holder may be assembled on the voltage regulator:


Pulley. In order to have a current output at low engine speeds, the ratio between the alternator pulley and crankshaft pulley should be between 1 ÷ 1.8 and 1 ÷ 2.1. In this way the alternator rotation speed almost doubles that of the engine.

The pulley race should be free from cracks or grease.


Bridge rectifier. This is a static device which converts the field winding alternating voltage into continuous voltage by means of a 6 or 12 diode bridge.

Positive half waves pass through positive diodes which lead to terminal B+ of the alternator, whilst negative half waves pass through negative diodes which are connected by means of their support to the system earth.

The rectifier bridge prevents a return of current to the field windings from the battery.




III.26 RECTIFIER BRIDGE DIAGRAM
A. ROTOR WINDINGS - B. EXCITER DIODES
C. POWER DIODES




26-15

III.27 RECTIFIER BRIDGE (MARELLI)




26-16

III.28 PROTECTION AGAINST EXCESS VOLTAGE
Z. ZENER DIODE SYMBOL




III.29 CLAW TYPE ROTOR
A. BEARING – B. RINGS – C. EXCITER WINDINGS – N.S. POLAR EXPANSIONS

2892



III.30 BRUSHES A. MINIMUM LENGTH 7 mm

2853



III.31 ALTERNATOR WITH INSULATED B- TERMINAL
A. BATTERY – B. G.C.R. – C. WIRING SYSTEM – D. ALTERNATOR

5158

Rotor. The rotor comprises alternating magnetic poles and exciter windings also known as rotor windings (fig. III.29).

The rotor is very compact and the slip rings and ball bearings are fitted to the end of the shaft.

The rotor is designed in such a way as to support the centrifugal force produced by its rotation; this rotation speed may vary between 12000 and 14000 rpm.

Battery charging warning light. When the ignition switch is turned to position 15 (services) this warning light makes it possible for the current to flow from the battery to the voltage regulator and consequently to the exciter winding.

This is in order to ensure that the alternator provides a current even at low engine speeds.

As soon as the alternator produces an EMF which is opposed to that produced by the battery, the warning light goes out (this takes place when the EMF electromotive forces between points D+ and B+ are nil).

If the warning light remains on, this means that there is a fault though not necessarily a lack of current.

Check the tension of the belt, the length of the brushes (fig. III.30) and the insulation of the rotor winding.

When the warning light flashes there may be a defect in the voltage regulator, the exciter diodes or one of the battery components or a decrease in pressure in the brushes at the slip rings.

It should be remembered that in systems where the alternator is not equipped with exciter diodes, the battery recharging circuit warning light is controlled by a special relay.

Stator. The stator is a hollow cylinder made up of laminations 0.5 mm thick. Open slots in the stator inside have the purpose of housing induced or stator windings.

The number of slots depends on the number of rotor poles multiplied by the number of phases.

Example: a threephase alternator with a 12-pole rotor is fitted with 36 slots ($12 \times 3 = 36$).

The power of a generator depends on the number of its slots.

Nominal voltage. This is the alternator operating voltage; it is stamped on the alternator casing.

Threephase voltage. The induced voltages in a threephase alternator are offset 120°.

They are linked by means of a star or delta type connection; the flow is of the sinusoidal type with equal amplitude and frequency.

Fan. The ventilation of the rectifier bridge is achieved by means of a centrifugal fan connected to the pulley.

When assembling the fan, bear in mind the alternator direction of rotation.


For large capacity alternators, the cold air is taken from outside with a sleeve assembled in the engine compartment for this purpose.

Electronic voltage regulator


The integrated circuit voltage regulator is subordinate to terminal D+, to the three exciter diodes and to the alternator rotor winding.

No adjustments or maintenance can be carried out on this type of voltage regulator.


Check that it is correctly fixed to the alternator casing. If it is connected to earth by means of a cable, this check is of vital importance.





III.32 FANS A. CLOCKWISE ROTATION - B. CLOCKWISE OR COUNTERCLOCKWISE ROTATION





III.33 AIR FLOW GENERATED BY A MEDIUM SIZED ALTERNATOR



III.34 ELECTRONIC VOLTAGE REGULATOR (MARELLI)



III.35 "BUFFER" CONNECTION FOR A BATTERY TO AN ALTERNATOR AND RELEVANT VOLTAGE AND CURRENT CURVES



III.36 ALTERNATOR OPERATION AND RELEVANT VOLTAGE CURVE

As it is known, voltage at battery terminals depends on the AMOUNT of current passing through it.

In order to avoid excessive voltage (16V approximately for a 12V battery), the amount of current supplied by the alternator should be adjusted to the battery's ACTUAL requirements.

Electronic voltage regulators presently in use work, via a specific preset voltage detector; on the necessary amount of energizing current (and consequently for the amount of current supplied by the alternator) based on battery requirements as well as on the requirements of all electrical components on-board the vehicle.

In practice, in the charging circuit, where the alternator is connected in parallel, or as a "buffer" to the battery, the maximum voltage value is linked to the power P and the current I in the formula:

$$P = U \cdot I$$

where

P is the nominal alternator power

U is the voltage

I is the current intensity.

If the alternator is disconnected from the battery (and therefore not forming a "buffer" connection) then the latter behaves like a "no load" generator.


As a result, the voltage at the terminals exceeds the nominal voltage of the system, several times over.

Theoretical operation


The voltage regulator controls the exciter current, that is to say the field influenced by the alternator rotor winding, and consequently the current supplied by the alternator (provided the latter is connected to the batteries).

The current output of a generator (alternator) over a load (battery) should be regulated on the basis of the voltage at battery terminals (according to electrolyte density). Regulation of the current output is worked out with the assistance of an electronic device which uses the characteristics of zener diode and transistors for this purpose.


Zener diodes perform a stabilizing action as they either conduct or block at preset voltage values according to voltage variations.



III.37 ZENER DIODE IN A DIRECT CURRENT CIRCUIT
R, RESISTANCE - U_z , ZENER VOLTAGE



III.38 TRANSISTOR IN A DIRECT CURRENT CIRCUIT
R, LOAD - R_b , POLARITY RESISTANCE



5161

III.39 VOLTMETER CONNECTION
 A. BATTERIES – B. IGNITION SWITCH – C. WIRING SYSTEM –
 D. VOLTMETER


Voltmeter

The voltmeter is connected after the ignition switch. Its purpose is to provide useful information as soon as the engine is switched on.

Engine switched off. If after a few seconds the instrument pointer stops below the green sector; the battery is discharged.

Engine running. If the instrument pointer stops in the area below the green sector; the charging circuit is faulty.

If the instrument pointer stops outside the green sector; the circuit is charged with excessive voltage.



2858

III.40 VOLTMETER A. RECHARGING CIRCUIT NOT WORKING PROPERLY – B. RECHARGING CIRCUIT WORKING PROPERLY – C. OVERVOLTAGE

INSTRUMENTS


| | Page |
|---|------|
| COMBINED MODULE | 3 |
| ELECTRONIC REV COUNTER | 4 |
| ELECTRONIC REV COUNTER SENDER UNIT | 5 |
| ENGINE COOLANT TEMPERATURE GAUGE WITH BUILT-IN WARNING LAMP | 6 |
| ENGINE COOLANT TEMPERATURE SWITCH AND SENDER UNIT | 7 |
| FUEL LEVEL INDICATOR WITH BUILT IN WARNING LAMP | 8 |
| FUEL LEVEL INDICATOR WITH RESERVE CONTACT WARNING LAMP | 9 |
| ELECTRONIC TACHOMETER WITH CLOCK | 10 |
| ELECTRONIC TACHOGRAPH/TACHOMETER SENDER UNIT | 11 |
| ENGINE OIL PRESSURE W/LAMP SWITCH | 13 |
| PARKING BRAKE W/LAMP SWITCH | 14 |
| IVECO CONTROL DISPLAY PANEL | 15 |
| ENGINE COOLANT LEVEL INDICATOR CONTROL DEVICE | 17 |
| ENGINE OIL LEVEL INDICATOR CONTROL DEVICE | 18 |
| BRAKE FLUID LEVEL INDICATOR CONTROL DEVICE | 19 |
| FRONT WHEEL BRAKE LINING WEAR CIRCUIT SENSOR | 20 |
| REAR WHEEL BRAKE LINING WEAR CIRCUIT SENSOR | 21 |
| AIR CLEANER RESTRICTION SWITCH | 22 |
| POWER STEERING FLUID LEVEL INDICATOR CONTROL DEVICE | 23 |

| | Page |
|--|------|
| FRONT DIFFERENTIAL LOCK W/LAMP SWITCH | 24 |
| REAR DIFFERENTIAL LOCK W/LAMP SWITCH | 25 |
| ALL-WHEEL DRIVE W/LAMP SWITCH | 26 |
| FRONT DIFFERENTIAL LOCK CONTROL SWITCH | 27 |
| MAX SPEED WITH ALL-WHEEL DRIVE ON SPEED SWITCH | 28 |
| FRONT DIFFERENTIAL LOCK DEVICE | 29 |

INSTRUMENTS

Combined module

58901



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|---------------------|---|--------------|
| A (black) | 1 Fuel reserve w/lamp | 5555 |
| | 2 Supply (+15) of combined module | 8879 |
| | 3 Electronic rev counter | 5519 |
| | 4 Positive of tachometer light and combined module after the rheostat | 4444 |
| | 5 Positive with exterior lighting switch | 4411 |
| | 6 Engine coolant level w/lamp | 5520 |
| | 7 Fuel level indicator | 5557 |
| | 8 Engine coolant temperature w/lamp | 5528 |
| | 9 Engine coolant temperature gauge control device | 5552 |
| B (white) | 1 Rear door w/lamp | 6624 |
| | 2 Rear fog lamp w/lamp | 2287 |
| | 3 High beam lights w/lamp | 2285 |
| | 4 Parking lights w/lamp | 4411 |
| | 5 Engine oil pressure w/lamp | 5503 |
| | 6 Available for optional extra w/lamp | 6008 |
| | 7 Available for optional extra w/lamp | |
| | 8 Turn signal lights w/lamp | 1112 |
| | 9 Battery charging failure w/lamp | 7778 |
| C (green) | 1 Parking brake w/lamp | 6662 |
| | 2 Air cleaner restriction w/lamp | 6663 |
| | 3 Brake system failure w/lamp | 6613 |
| | 4 Water in fuel filter w/lamp | 1115 |
| | 5 ABS system failure w/lamp | 6670 |
| | 6 Preheating w/lamp | 5553 |
| | 7 Earth | 0000 |
| | 8 Power steering fluid level w/lamp | 5525 |
| | 9 Available for optional extra w/lamp | 6006 |

Electronic rev counter

SIMPLIFIED DIAGNOSIS

Disconnect connector blocks **A** and **C** from combined module.


Set multimeter to VOLT:

Turn ignition switch key to position 15. Ensure 12 Volts are available by setting one multimeter prod to terminal 2 of connector block **A** and the other one to earth.

Set multimeter to OHM:


Turn the key to rest position and ensure the presence of 0 Ω (zero ohm) by setting one multimeter prod to terminal 7 of connector **C** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 3

NOTE. Refer to page IV.3 for a complete view of connectors **A** and **C** and relevant wiring.



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--|--------------|
| A | 1 Not used | |
| | 2 Supply (+15) | 8879 |
| | 3 Signal from electronic rev counter sender unit | 5519 |
| | 4 ÷ 9 Not used | |
| C | 1 ÷ 6 Not used | — |
| | 7 Earth | 0000 |
| | 8 Not used | — |
| | 9 Not used | |

Electronic rev counter sender unit

SIMPLIFIED DIAGNOSIS


Disconnect connector **A** from component under examination.

Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to terminal 3 of combined module connector **A** (page IV.3).


Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 3

48030



CONNECTOR WITH TERMINALS

| Connector | Function | Cable colour |
|-----------|--|---------------------|
| A | 1 to electronic rev counter 2 earth | Light blue Brown |

Engine coolant temperature gauge with built-in warning lamp

SIMPLIFIED DIAGNOSIS

Disconnect connector blocks **A** and **C** from combined module.


Set multimeter to VOLT:

Turn ignition switch key to position 15. Ensure 12 Volts are available by setting one multimeter prod to terminal 2 of connector block **A** and the other one to earth.

Set multimeter to OHM:


Turn the key to rest position and ensure the presence of 0 Ω by setting one multimeter prod to terminal 7 of connector **C** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 3

NOTE. Refer to page IV.3 for a complete view of connectors **A** and **C** and relevant wiring.



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour | |
|-----------|----------|--------------------------------------|------|
| A | 1 | Not used | — |
| | 2 | Supply (+15) | 8879 |
| | 3 ÷ 7 | Not used | — |
| | 8 | To engine coolant temperature w/lamp | 5528 |
| | 9 | Signal to engine coolant gauge | 5552 |
| C | 1 ÷ 6 | Not used | — |
| | 7 | Earth | 0000 |
| | 8 | Not used | — |
| | 9 | Not used | — |

Engine coolant temperature switch and gauge sender unit

SIMPLIFIED DIAGNOSIS


Disconnect connector **A** from component under examination.

Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to terminal 8 of combined module connector A (page IV.3).

Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and other one to terminal 9 of combined module connector A.


If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 4

47030

47100



5166

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--|--------------|
| A | 1 To engine coolant temperature w/lamp | 5528 |
| | 2 Signal to engine coolant gauge | 5552 |

Fuel level indicator with built-in warning lamp

SIMPLIFIED DIAGNOSIS


- Disconnect connector blocks A and C from combined module.
- Set multimeter to VOLT:

 - Turn ignition switch key to position 15. Ensure 12 Volts are available by setting one multimeter prod to terminal 2 of connector block A and the other one to earth.

- Set multimeter to OHM:


 - Turn the key to rest position and ensure the presence of 0 Ω by setting one multimeter prod to terminal 7 of connector C and the other one to earth.

- If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 3

NOTE. Refer to page IV.3 for a complete view of connectors A and C and relevant wiring.



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|---------------------------------------|--------------|
| A | 1 To fuel reserve w/lamp | 5555 |
| | 2 Supply (+15) | 8879 |
| | 3 ÷ 6 Not used | |
| | 7 Fuel level indicator control device | 5557 |
| | 8 Not used | |
| 9 Not used | | |
| C | 1 ÷ 6 Not used | |
| | 7 Earth | 0000 |
| | 8 Not used | |
| | 9 Not used | |

Fuel level indicator control device with reserve warning lamp contact

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.


Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to terminal 7 of combined module connector **A1** (page IV.3).


Check for 0 Ω by setting one multimeter prod to terminal 3 of connector **A** and other one to terminal 1 of combined module connector **A**.

Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 3



44031

LAYOUT WITH CONNECTIONS

5168

| Connector | Function | Cable colour | |
|-----------|----------|--------------------------------|------|
| A | 1 | Signal to fuel level indicator | 5557 |
| | 2 | Earth | 0000 |
| | 3 | To fuel reserve w/lamp | 5555 |

Electronic tachometer with clock

SIMPLIFIED DIAGNOSIS

Disconnect connector block **A** from component under examination.


Set multimeter to VOLT:

Turn ignition switch key to position 15. Ensure 12 Volts are available by setting one multimeter prod to terminal 3 of connector block **A** and the other one to earth.

Set multimeter to OHM.


Turn the key to rest position and ensure the presence of 0 Ω by setting one multimeter prod to terminal 5 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 3

40002



5159

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|--|--------------|
| A | 1 Supply (+15) | 7772 |
| | 2 Positive for instrument lighting | 4444 |
| | 3 Supply (+15) | 8879 |
| | 4 Not used | - |
| | 5 Insulated earth | 0066 |
| | 6 Earth | 0000 |
| | 7 Not used | - |
| | 8 Not used | - |
| XIX | 1 To electronic tachometer sender unit | 5514 |
| | 2 To electronic tachometer sender unit | 5517 |
| | 3 To electronic tachometer sender unit | 0058 |
| | 4 Supply (+15) | 5511 |
| | 5 Insulated earth | 0066 |

Electronic tachograph/tachometer sender unit

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.


Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to terminal 1 of tachometer connector B (page IV.10).


Check for 0 Ω by setting one multimeter prod to terminal 3 of connector **A** and other one to terminal 3 of tachometer connector B.

Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A**; and the other one to terminal 2 of tachometer connector B.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 3



40032

LAYOUT WITH CONNECTIONS



51/0

| Connector | Function | Cable colour | |
|-----------|----------|-----------------------------------|------|
| A | 2A | Positive for sender unit | 5514 |
| | 2B | Negative for sender unit | 0058 |
| | 2C | Speed signal | 5517 |
| | 2D | Inverse speed signal | 5516 |
| XX | 1 | To tachometer/tachograph | 5514 |
| | 2 | To tachometer/tachograph | 0058 |
| | 3 | To tachometer/tachograph | 5517 |
| | 4 | Tachometer/tachograph sender unit | |

Tachograph/tachometer sender unit

| Terminal | Function | Symbol |
|----------|----------------------|--------|
| 2A | 8V supply | + |
| 2B | Earth | - |
| 2C | Speed signal | A1 |
| 2D | Inverse speed signal | A2 |

40032



2897

2898

ELECTRICAL CONNECTIONS

Technical data

| | | | |
|-------------------------------|--|---------------------------|-----------------------------|
| Overvoltage protection device | $\pm 150V (0,5 \text{ ms} - 0,2 \text{ Hz})$ | Hermetic | 0.5 bar in oil, 120°C, 100h |
| "VE" operating voltage | $6 \div 15V$ | Signal | A2: inversion of A1 |
| Current absorption | MAX 12 mA | Operating temperature "A" | $30 \div +135$ |
| Connection type | no earth | Operating temperature "B" | $-30 \div +145$ |
| Internal resistance | 1,5 K Ω | Storage temperature "C" | $-40 \div +140$ |
| Wave form | square | Storage temperature "D" | $-40 \div +150$ |
| Initial signal | A1: $L \leq 50mV; H=VE-2V (13V \text{ max})$ | Type of protection | DIN 40050 – IP 66 |
| | | Tightening torque | 50 Nm max |

Engine oil pressure warning lamp switch


SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to OHM.


Check for 0 Ω by setting one multimeter prod to connector **A**, and the other one to terminal 5 of combined module connector B (page IV.3).

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 4

42550



5171

LAYOUT WITH CONNECTIONS


| Connector | Function | Cable colour |
|-----------|-------------------------------------|--------------|
| A | To engine oil pressure warning lamp | 5503 |

Parking brake warning lamp switch

SIMPLIFIED DIAGNOSIS


Disconnect connector **A** from component under examination.
Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to connector **A** and the other one to terminal I of combined module connector C (page IV.3).
If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 4

42102



5172

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|-------------------------------|--------------|
| A – | To parking brake warning lamp | 6662 |

IVECO Control display panel

SIMPLIFIED DIAGNOSIS

Disconnect connector block **A** from component under examination.


Set multimeter to VOLT:

Turn ignition switch key to position 15. Ensure 12 Volts are available by setting one multimeter prod to terminal 6 of connector block **A** and the other one to earth.

Set multimeter to OHM.


Turn the key to rest position and ensure the presence of 0 Ω by setting one multimeter prod to terminal 11 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.




Print no. 603.42.961 Diagram no. 4

50000



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour | |
|-----------|----------|--------------------------------------|------|
| A | 1 | Rear axle brake failure w/lamp | 6667 |
| | 2 | Front axle brake failure w/lamp | 8814 |
| | 3 | Brake system failure w/lamp | 6613 |
| | 4 | Engine oil pressure failure w/lamp | 5503 |
| | 5 | Positive for display panel lighting | 4411 |
| | 6 | Supply (15) | 7772 |
| | 7 | Windscreen washer fluid level w/lamp | 5521 |
| | 8 | Brake fluid level w/lamp | 6661 |
| | 9 | Engine coolant level w/lamp | 5520 |
| | 10 | Engine oil level w/lamp | 5556 |
| | 11 | Earth | 0000 |



IV.41 IVECO CONTROL DISPLAY PANEL

156

IVECO Control display panel

This device indicates low fluid levels and/or brake wear by lighting up warning lights (LEDs).

Description

The functions being checked are the following:

- engine coolant level
- engine oil level
- windshield washer fluid level
- brake fluid level
- front axle brake wear
- rear axle brake wear

Operation

When the ignition switch is turned to services (+15) it is possible to visually inspect the efficiency of all the warning lights (LEDs). They come on for a period of about 5 seconds.

Then, if the system is working properly, the LEDs go out and only the general green LED remains on.

IVECO CONTROL DISPLAY PANEL

Engine and brake system operation check

1. Reset button
2. Device on (general green led)
3. Engine coolant level (red)
4. Engine oil level (red)
5. Windshield washer fluid level (red)
6. Brake fluid level (red)
7. Front axle brake wear (red)
8. Rear axle brake wear (red)

Engine coolant level indicator control device


SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.
Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to terminal 85 of engine coolant level indicator relay


Check for 0 Ω by setting one multimeter prod to terminal 3 of connector **A** and other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 4

44036



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | 1 Not used | |
| | 2 Relay for engine coolant level w/lamp | 5527 |
| | 3 Earth | 0000 |

Engine oil level indicator control device

SIMPLIFIED DIAGNOSIS


Disconnect connector **A** from component under examination.

Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to terminal 10 of IVECO Control display panel connector **A** (page IV.15).


Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 4

44032



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|--------------|--|--------------|
| A 1 | To IVECO Control display panel (engine oil level w/lamp) | 5556 |
| 2 | Earth | 0000 |

Brake fluid level indicator control device


SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination. Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to terminal 8 of IVECO Control display panel connector **A** (page IV.15).



Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 4

44033



5176

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--|--------------|
| A | 1 Earth | 0000 |
| | 2 To IVECO Control display panel (brake fluid level indicator) | 6613 |

Front rh wheel brake lining wear sensor

SIMPLIFIED DIAGNOSIS

Disconnect connector |A| from component under examination.


Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 2 of connector |A| and the other one to terminal 2 of IVECO Control display panel connector A (page IV.15).

Check for 0 Ω by setting multimeter prods to terminals 1 and 2 of sensor connector:


If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.

Repeat the same test with the front lh wheel sensor. Use the wiring diagram on the side as a reference guide.



Print no. 603.42.961 Diagram no. 4

86002



5177

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--|--------------|
| A | 1 Earth | 8814 |
| | 2 To front lh wheel brake lining wear sensor | 8814 |

Rear rh wheel brake lining wear sensor

SIMPLIFIED DIAGNOSIS


Disconnect connector **A** from component under examination.
Set multimeter to OHM.

Check for $0\ \Omega$ by setting one multimeter prod to terminal 2 of connector **A** and the other one to terminal 1 of IVECO Control display panel connector A (page IV.15).


Check for $0\ \Omega$ by setting multimeter prods to terminals 1 and 2 of sensor connector:

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.

Repeat the same test with the rear lh wheel sensor. Use the wiring diagram on the side as a reference guide.



Print no. 603.42.961 Diagram no. 4



86003

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|--|--------------|
| 1 | To rear lh wheel brake lining wear sensor | 6667 |
| A 2 | To IVECO Control display panel (rear axle brake wear w/lamp) | 6667 |

Air cleaner restriction switch

SIMPLIFIED DIAGNOSIS


Disconnect connector **A** from component under examination.
Set multimeter to OHM.

Disconnect connector **A** from component under examination.
Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 2 of connector A and the other one to terminal 2 of combined module connector C (page IV.3).


Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 4

42351



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|-------------------------------------|--------------|
| A | 1 Earth | 0000 |
| | 2 To air cleaner restriction w/lamp | 6663 |

Power steering fluid level indicator control device


SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.
Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to terminal 85 of power steering fluid level indicator relay.


Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Part no. 6742790 Diagram no. 1

44037



LAYOUT WITH CONNECTIONS

| Connector | | Function | Cable colour |
|-----------|---|---|--------------|
| A | 1 | Earth | 0000 |
| | 2 | To power steering fluid level indicator relay | 5525 |

Front differential lock warning lamp switch


SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.
Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to terminal 6 of combined module connector A (page IV.3).


Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 12

53504



518

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|-----------------------------------|--------------|
| A 1 | To front differential lock w/lamp | 6659 |
| A 2 | Earth | 0000 |

Rear differential lock warning lamp switch

SIMPLIFIED DIAGNOSIS


Disconnect connector **A** from component under examination.

Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A**, and the other one to terminal 6 of combined module connector A (page IV.3).


Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 12

53505



3182

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | 1 To rear differential lock w/lamp switch | 6660 |
| | 2 Earth | 0000 |

All-wheel drive warning lamp switch

SIMPLIFIED DIAGNOSIS


Disconnect connector **A** from component under examination.

Set multimeter to OHM.


Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to terminal 1 of combined module connector B (page IV.3).

Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 12



53506

5183

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|---------------------------------|--------------|
| A 1 | Earth | 0000 |
| A 2 | To all-wheel drive warning lamp | 6602 |

Front differential lock control switch

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.


Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to terminal 1 of front differential lock device connector (page IV.29).

Check for 0 Ω by setting one multimeter prod to terminal 3 of connector **A** and other one to terminal 2 of front differential lock connector.


Check for 0 Ω by setting one multimeter prod to terminal 2 of connector and the other one to terminal 87 of front differential lock interlock relay.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 12

53022



4658

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | 1 To rear differential lock device | 8871 |
| | 2 Supply (+15/A) with front differential lock interlock relay | 7772 |
| | 3 To front differential lock device | 8879 |

Speed switch for max speed with all-wheel drive on

SIMPLIFIED DIAGNOSIS

Disconnect connector block **A** from component under examination.


Set multimeter to VOLT:

Move ignition switch key to position 15. Ensure 12 Volts are available by setting one multimeter prod to terminal 4 of connector block **A**, and the other one to earth.

Set multimeter to OHM:


Turn the key to rest position and ensure the presence of 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 12

55002



153

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|---|--------------|
| 1 | Earth | 0000 |
| 2 | To max speed warning lamp with all-wheel drive on | 5551 |
| A 3 | Not used | — |
| 4 | Supply (+15) | 8879 |
| 5 | Not used | — |
| 6 | Vehicle speed signal | 5513 |

Front differential lock device

SIMPLIFIED DIAGNOSIS

Disconnect connector **C** from component under examination.


Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **C** and the other one to terminal 1 of front differential lock control switch.


Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **C** and the other one to terminal 3 of front differential lock switch connector:

Ensure efficiency of 16A fuse.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603-42.961 Diagram no. 12



85025

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|-------------------------------------|--------------|
| A | Supply (battery +) | 7777 |
| B | Earth | 0000 |
| C | 1 Front differential lock operation | 8871 |
| | 2 Front differential lock cutoff | 8879 |

EXTERIOR LIGHTING

| | Page |
|---|------|
| EXTERIOR LIGHTING SWITCH | 3 |
| STEERING COLUMN SWITCH (HIGH/LOW BEAM LIGHTS, FLASHER LIGHT) | 4 |
| HIGH/LOW BEAM HEADLIGHT WITH PARKING LIGHTS | 5 |
| FOG LAMP SWITCH WITH REAR FOG LAMP INTERLOCK DEVICE | 6 |
| FOG HEADLIGHTS | 7 |
| FRONT MARKER LIGHT | 8 |
| SIDE MARKER LIGHT | 9 |
| NUMBER PLATE LIGHT | 10 |
| NUMBER PLATE LIGHT (VANS AND BUSES) | 11 |
| TAIL FOG LIGHT SWITCH | 12 |
| TAIL HEADLIGHT CLUSTER | 13 |
| TAIL HEADLIGHT CLUSTER (VANS AND BUSES) | 14 |
| LAMPS | 15 |
| HEADLIGHTS | 18 |

EXTERIOR LIGHTING
Exterior lighting switch

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination:

Set multimeter to VOLT:

Ensure 12 Volts are available by setting one multimeter prod to terminal 5 of connector **A** and the other one to earth.

Put ignition switch key in position 15. Check for 12 V by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.


Set multimeter to OHM.

Set the key to rest position.

Press switch to 1st release and check for 0 Ω by setting multimeter prods to terminals 3 and 5 of switch connector block.


Repeat the same test with terminals 3-1 and 2-4 but pressing the switch to the 2nd release.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 5

52307



5185

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | 1 Supply (+15) | 2235 |
| | Jumper to cell no. 4 of high/low beam lights operation switch | 2222 |
| | 2 High/low beam lights | 2222 |
| | 3 Parking lights, instrument lighting | 3390 |
| | 4 Positive for high/low beam lights | 2222 |
| | 5 Supply (+30) | 3390 |
| | 6 To day lights variant prearrangement | 3333 |
| | 7 Not used | - |
| | 8 Not used | - |
| | 9 Supply (+15/A) for switch lighting | 8879 |
| 10 Earth | 0000 | |

Steering column switch (high/low beam lights/flasher light)

SIMPLIFIED DIAGNOSIS


Disconnect connector [B] from the C.I.U.

Set multimeter to VOLT:

- Put ignition switch key in position 15.
- Ensure 12 Volts are available by setting one multimeter prod to terminal 8 of C.I.U. connector 'B' and the other one to earth.
- Check for 12 V by setting one multimeter prod to terminal 1 of C.I.U. connector [B] (having pressed the exterior lighting switch twice) and the other one to earth.

Set multimeter to OHM.


- Set the key in rest position. Set the steering column switch in low beam lights position. Check for 0 Ω by setting multimeter prods to terminals 1 and 5 of steering column switch connector 'B'.
 - Now set the switch in high beam lights position. Repeat the same test by setting multimeter prods to terminals 1 and 3 of steering column switch connector 'B'.
 - Position the switch in the flasher light position. Repeat the same test by setting multimeter prods on terminals 2 and 8.
- If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 6

NOTE. Refer to page I.64 for a complete view of steering column switch and relevant wiring.

54033 A-C



3186

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|----------------|--------------------------------|--------------|
| 1 (d) | Supply of high/low beam lights | green |
| 2 (e) | Flasher light | brown |
| 3 (g) | High beam lights | blue |
| 4 (s) | Not used | — |
| B 5 (f) | Low beam lights | grey/black |
| 6 (b) | Not used | — |
| 7 (c) | Not used | — |
| 8 (n) | Flasher light supply | brown |
| 9 (a) | Not used | — |
| 10 (t) | Not used | — |

High/low beam headlight with parking light

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Press the exterior lighting switch (page V.3) to 1st release. Check for 12 V by setting one multimeter prod to terminal 2 of connector **A** and the other one to earth (parking lights).

Put the ignition switch key in position 15 and press the exterior lighting switch to 2nd release. Check for 12 V by setting one multimeter prod to terminal 3 of connector **A** and the other one to earth (low beam lights).


Set the steering column switch in high beam light position. Check for 12 V by setting one multimeter prod to terminal 4 of connector **A** and the other one to earth.

Set multimeter to OHM.

Put the ignition switch key in rest position.


Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 6

30001



5187

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour | |
|-----------|----------|--------------------------------|------|
| A | 1 | Earth | 0000 |
| | 2 | Supply of parking light lamp | 3334 |
| | 3 | Supply of low beam light lamp | 2223 |
| | 4 | Supply of high beam light lamp | 2221 |

Fog light switch with rear fog light interlock device

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Put the ignition switch key in position 15.

Press the exterior lighting switch (page V.3) once.

Check for 12 V by setting one multimeter prod first to terminal 2 and then to terminal 5 of connector **A** and the other one to earth.

Press the exterior lighting switch twice.


Check for 12 V by setting one multimeter prod to terminal 8 of connector **A** and the other one to earth.

Set multimeter to OHM.

Put the ignition switch key in rest position. Check for 0 Ω by setting multimeter prods to terminals 6 and 8 fog lights switch.


Press the fog lights switch. Check for 0 Ω by setting multimeter prods to terminals 1-5 and 2-6 of same switch.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 8

52304



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|--------------------------------------|--------------|
| 1 | Fog light relay control device | 2289 |
| 2 | Supply from exterior lighting switch | 2284 |
| 3 | Not used | — |
| 4 | Not used | — |
| A 5 | Supply from exterior lighting switch | 2289 |
| 6 | Rear fog light interlock switch | 2283 |
| 7 | Not used | — |
| 8 | Supply from exterior lighting switch | 2222 |
| 9 | Supply (15/A) for switch lighting | 8879 |
| 10 | Earth | 0000 |

Fog headlight

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Put the ignition switch key in position 15.

Press the exterior lighting switch (page V.3) (either 1st or 2nd release).

Press the fog light switch (page V.6).


Check for 12 V by setting one multimeter prod to terminal **B** of connector **A** and the other one to earth.

Set multimeter to OHM.

Put the ignition switch key in rest position.


Check for 0 Ω by setting one multimeter prod to terminal A of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 8

30011



5189

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--------------------------------|--------------|
| A | A Earth | 0000 |
| | B Supply of fog headlight lamp | 2228 |

Front marker light

SIMPLIFIED DIAGNOSIS

Disconnect connectors **A** and **B** from component under examination.

Set multimeter to VOLT.

Press exterior lighting switch (page V.3) to 1st release.


Check for 12 V by setting one multimeter prod to terminal of connector **A** and the other one to earth.

Set multimeter to OHM.

Return exterior lighting switch in rest position.


Check for 0 Ω by setting one multimeter prod to terminal of connector **B** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 5

37001



5196

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|-----------------------------|--------------|
| A 1 | Supply of marker light bulb | 3330 |
| B 2 | Earth | 0000 |

Side marker light

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Press exterior lighting switch (page V.3) to 1st release.


Check for 12 V by setting one multimeter prod to terminal 2 of connector **A** and the other one to earth.

Set multimeter to OHM.

Return exterior lighting switch in rest position.


Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 5

37005



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|-------------------------------|--------------|
| A | 1 Earth | 0000 |
| | 2 Supply of marker light bulb | 3335 |

Number plate headlight

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Press exterior lighting switch (page V.3) to 1st release.


Check for 12 V by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

Set multimeter to OHM.

Return exterior lighting switch in rest position.



Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 5

35000



1-92

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | 1 Supply of number plate headlight bulb | 3335 |
| | 2 Earth | 0000 |

Number plate headlight (vans and buses)

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** and **B** from component under examination.

Set multimeter to VOLT.

Press exterior lighting switch (page V.3) to 1st release.


Check for 12 V by setting one multimeter prod to terminal of connector **B** and the other one to earth.

Set multimeter to OHM.

Return exterior lighting switch in rest position.


Check for 0 Ω by setting one multimeter prod to terminal of connector **B** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 5

35000



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---------------------------------------|--------------|
| A | Earth | 0000 |
| B | Supply of number plate headlight bulb | 3335 |

Rear fog light switch

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Put the ignition switch key in position 15.

Press exterior lighting switch (page V.3) to 1st release and check for 12 V by setting one multimeter prod to terminal 5 of connector **A** and the other one to earth.

Press exterior lighting switch to 2nd release and repeat the test.


Set multimeter to OHM.

Return exterior lighting switch in rest position.

Press the rear fog lamp key switch.


Check for 0 Ω by setting multimeter prods to terminals 1 and 5 of rear fog lamp switch.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 8

52006



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour | |
|-----------|----------|--|--------------|
| A | 1 | Supply of rear fog lamp bulb Supply of rear fog lamp w/lamp | 2283 2287 |
| | 2 | Not used | — |
| | 3 | Not used | — |
| | 4 | Not used | — |
| | 5 | Supply of rear fog lamp switch | 2283 |
| | 6 | Not used | — |
| | 7 | Not used | — |
| | 8 | Not used | — |
| | 9 | Supply (15/A) of switch lighting | 8879 |
| | 10 | Earth | 0000 |

Tail headlight cluster

SIMPLIFIED DIAGNOSIS

Disconnect connectors **A** and **B** and **C** from component under examination.

Set multimeter to VOLT.

Put the ignition switch key in position 15 and press the exterior lighting switch (page V.3) to 1st release.

Check for 12 V by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

While keeping exterior lighting switch pressed (to 1st release and then to 2nd release) press the rear fog lamp key switch. Check for 12 V by setting one multimeter prod to terminal of connector **B** and the other one to earth.

Set transmission in reverse gear. Check for 12 V by setting one multimeter prod to connector **C** and the other one to earth.


Set the steering column switch lever in turn signal light position. Check for 12 V by setting one multimeter prod to terminal 2 of connector **A** and other one to earth.

Depress the brake pedal. Check for 12 V by setting one multimeter prod to terminal 3 of connector **A** and the other one to earth.

Set multimeter to OHM.


Put the ignition switch key in rest position. Check for 0 Ω by setting one multimeter prod to terminal 4 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 5 / 7 / 8

34000



5195

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour | |
|-----------|----------|---|------|
| A | 1 | Supply of parking light bulb | 3334 |
| | 2 | Supply of hazard/turn signal light bulb | 1120 |
| | 3 | Supply of stop light bulb | 1177 |
| | 4 | Earth | 0000 |
| B | – | Supply of rear fog light bulb | 2283 |
| C | – | Supply of reversing light bulb | 2227 |

Tail headlight cluster (vans and buses)

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Put the ignition switch key in position 15 and press the exterior lighting switch (page V.3) to 1st release.

Check for 12 v by setting one multimeter prod to terminal 10 of connector **A** and the other one to earth.

While keeping exterior lighting switch pressed (1st release and then 2nd release) press the rear fog lamp key switch. Check for 12 V by setting one multimeter prod to terminal 9 of connector **A** and the other one to earth.

Set transmission in reverse gear. Check for 12 V by setting one multimeter prod to terminal 4 of connector **A** and the other one to earth.


Set the steering column switch lever in turn signal light position. Check for 12 V by setting one multimeter prod to terminal 2 of connector **A** and other one to earth.

Depress the brake pedal. Check for 12 V by setting one multimeter prod to terminal 3 of connector **A** and the other one to earth.


Set multimeter to OHM.

Put the ignition switch key in rest position. Check for 0 Ω by setting one multimeter prod to terminal 8 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961. School bus Basic Wiring Diagram



34000

LAYOUT WITH CONNECTIONS

5196

| Connector | Function | Cable colour |
|-----------|---|--------------|
| 1 | Not used | — |
| 2 | Supply of hazard/turn signal light bulb | 1120 |
| 3 | Supply of stop light bulb | 1177 |
| 4 | Supply of reversing light bulb | 2227 |
| 5 | Not used | — |
| 6 | Not used | — |
| 7 | Not used | — |
| 8 | Earth | 0000 |
| 9 | Supply of rear fog light bulb | 2283 |
| 10 | Supply of parking light bulb | 3334 |

LAMPS

General

The lamps, whether of the incandescent or the halogen type, are directly connected to the vehicle's active (exterior lighting) or passive (interior lighting and optical indicators) safety devices.

The efficiency of the exterior signalling system is of basic importance and in particular the correct functioning and alignment of dipped and driving headlights.

External and internal lighting is regulated by precise rules both in terms of lighting efficiency, voltage and power, and its layout on the vehicle.

Incandescent lamps

Replacement of headlight bulbs, of external optical units and dashboard lamps is not difficult.

However adherence to procedures supplied by the manufacturer is extremely important.

When assembling a new bulb pay attention to the positioning marks on the metal base of the high/low beam lamps to obtain perfect headlight aiming (fig. V.1).


Replacement of bulbs of side and tail optical units is quite simple. However, make sure that lamp housings and connectors leading to system cables are free from oxidation and dust.

Blackened bulbs should be renewed as vibrations can affect their operation.


When bulbs have a silver colouring either the charging system is faulty or one of the connections is loose (overvoltage).

Also check lenses for signs of cracks and efficiency of silentblocks in rear optical units.


Tighten lens fixing screws to a moderate torque.



V.1 DOUBLE-FILAMENT LAMPS
A. INCANDESCENT BULB
B. HALOGEN BULB
ARROWS INDICATE POSITIONING MARKS




V.2 A. TURN SIGNAL, HIGH/LOW BEAM LIGHTS WITH PARKING LIGHTS - B. SIDE MARKER LIGHTS - C. FRONT MARKER LIGHTS - D. TAIL HEADLIGHT CLUSTER (TURN SIGNAL, PARKING, STOP, REAR FOG, REVERSING LIGHTS) - E. NUMBER PLATE LIGHTS




3019

V.3 HALOGEN LAMP (REGENERATION PRINCIPLE)



3020

V.4 PERSPECTIVE AND SCHEMATIC VIEWS OF A LED
A. ANODE - K. CATHODE



3021

V.5 CIRCUITS WITH LED DIODES - A. ANODE - K. CATHODE - R. CURRENT LIMITING PROTECTION RESISTANCE - D. DIODE FOR PROTECTION AGAINST INVERSE CURRENTS

Halogen lamps

Though incandescent, lamps of the H1, H2, H3 and H4 type are based on the regeneration of tungsten particles emitted from the bulb filament via an halogen element (fig. V.3).

Under the effect of temperature, the halide particles (composed of halogen and tungsten) circulate inside the bulb.

When close to the filament, where the temperature rises to over 1400°C, tungsten separates from halogen and once more combines itself with the original material.

The high operating temperature and the use of quartz as an external wrapper of this type of lamps means that their replacement calls for absolute care in handling them (they should only be held by their metal base).

The presence of grease marks on the bulb (left by fingers) at high temperatures can in fact develop a "devitrification" process which impairs the operation of the lamp and reduces its illumination power.

NOTE. In order to protect the steering wheel switch assembly and the key switches from the considerable absorption of initial current, on their switching on halogen lamps are generally operated by relays of suitable power.

LEDs (Light Emitting Diodes)

LEDs are used as optical indicators as they illuminate by supplying a suitable polarisation current (fig. V.4).

They function as a connection diode and should therefore be inserted in circuits observing correct polarity (anode connected to circuit positive, cathode connected to circuit negative).

LEDs operate with an intensity of direct current within the range of 20 and 50 mA, which means that they are protected by an adequate limiting resistance (fig. V.5).

NOTE. In practical applications, the limiting resistance can be inserted either before or after the LED (obviously in both cases the value of the current flowing through the LED is the same).

Fluorescent lamps

Fluorescent lamps are generally of a tubular shape and contain low pressure gas with a small quantity of mercury (fig. V.6).

The electrodes ensuring electrical contact are connected at both ends. The inner surface is lined with a layer of fluorescent substances.

When the current flows, the mercury vapour develops ultra violet radiations which energise the fluorescent material electrons in turn producing photons (luminous emission).

As the emitted light is not as harsh as the light emitted by incandescent lamps, it does not cause glare and eye problems.


Owing to such advantages, the use of fluorescent lamps is suggested for the internal lighting of buses where driver and passengers need an ideal level of comfort without endangering the passive safety of the vehicle.

Figures V.7 and V.8 show the operating diagram of a fluorescent lamp consisting of:

- starter, which generates the pulse necessary to start the spark;
- reactor, which is connected in series and limits the current flowing to the lamp when spark starting has occurred;
- capacitor, which is connected in parallel and suppresses radio noises.


NOTE. The voltage necessary to switch on a fluorescent lamp is higher than the voltage normally operating in an electrical system served by a battery.

It is therefore necessary to insert an inverter -- to be used as output voltage and as required power -- in the lamp supply circuit.




4695

V.6 FLUORESCENT LAMP




4696

V.7 ELECTRICAL CONNECTION OF A FLUORESCENT LAMP – A. LAMP – B. INVERTER




4697

V.8 INVERTER (INTERNAL WIRING SYSTEM)
A. CAPACITOR – B. STARTER – C. REACTOR (SOFT IRON CORE) – D. STATIC INVERTER




5197

V.9 HIGH/LOW BEAM HEADLIGHT
 A. LENS - B. TURN SIGNAL UNIT - C. BODY - D. HALOGEN LAMP (HIGH/LOW BEAM LIGHT) - E. GAITER - F. PARKING LIGHT BULB



3031

V.10 PARABOLA F_1 FOCUSING POINT - F_2 POINT IN FRONT OF THE FOCUSING POINT
 - - - - - PARALLEL RAYS
 ——— CONVERGENT RAYS



3032

V.11 HIGH BEAM LIGHT - F_1 FOCUSING POINT

Headlights

The headlight consists of (fig. V.9):

- lamp holder and bulb
- diffusor or refractor glass
- a lens seal positioned against the parabola
- a body which, together with lens and parabola, makes up the optical unit
- a parabola or reflecting telescope
- gaiter or plug
- adjusting screws.

Diffusor or refractor glass

The diffusor glass determines the distribution of the light beam over the roadway. The type of light diffusion is obtained by means of prisms engraved on the glass or, in case of small headlights, by lenses.

Parabola

The parabola is the basic component of the headlight as it reflects and sheds the light emitted by the bulb.

If the light source (filament) is aligned with the focusing point the light rays are projected outwards in parallel lines. On the contrary, if the light source is in front of the focusing point the light rays are projected outwards in a convergent pattern (fig. V.10).

It is possible to obtain different types of light beams by using different types of parabolas or lamps.

High beam light

The high beam light, whose rays are shown in a parallel line pattern, is obtained by supplying the lamp filament (either of the traditional or the halogen type) which is positioned on the parabola's focusing point (fig. V.11).

Low beam (dipped) lights

The low beam (or dipped) light (convergent rays) is obtained by supplying the filament of the bulb (either of the traditional or halogen type) positioned in front of the parabola's focusing point (figure V.12 ref. F₂). As a rule, this filament is located before the high beam filament.

Contrary to the high beam, where the light rays are shed from the whole of the parabolic surface by means of a suitable filament screening (figure V.12 ref. A), the low beam (or dipped light) is only shed by the upper section of the parabola.

European asymmetrical low beam (dipped) lights

The asymmetrical low beam light in conformity with European standards (fig. V.13), concerning right-hand drive vehicles, follows a horizontal trend along its left-hand side while it shows a 15° angle on its right-hand side. This way, a larger light range is made possible on the right-hand side of the road and the glaring of vehicles coming from the opposite direction is prevented (fig. V.14).

Fog lights


The fog light beam can be compared to the dipped beam as rays conveyed by its parabola have a vertical minimum angle (4°) thus avoiding illumination of the higher section of the roadway and protecting the driver from annoying reflections.

Furthermore, the light beam has a horizontal range of 160° (this is obtained by means of the prism pattern on the glass or by suitable lenses).


Fog lamps are usually fitted with H3 halogen lamps.

Auxiliary high beam (driving) lights


Auxiliary high beam (driving) lights, used in addition to main headlights, are concentrated and convey an intense light beam over a maximum range. They are usually fitted with H4 halogen bulbs.



V.12 LOW BEAM (DIPPED LIGHTS)
F₂ POINT IN FRONT OF THE FOCUSING POINT
A. SCREENING























V.13 VIEW OF THE ASYMMETRICAL LOW BEAM LIGHT



V.14 TREND OF THE EUROPEAN ASYMMETRICAL LIGHT BEAM
A. LIGHT BEAM - B. ROADWAY

List of lamp types assembled on the vehicle

| Type | Connection | Voltage (V) | Power (W) | Use |
|--|---|-------------|------------|--|
|  R2 <small>3199</small> |  | 12 | 40/45 | Low beam lights High beam lights |
|  H4 <small>3011</small> |  | 12 | 55/60 | Low beam lights High beam lights |
|  H3 <small>3023</small> |  | 12 | 55 | Fog lights |
|  P21W <small>3024</small> |  | 12 | 21 | Turn signal lights Stop lights Rear fog lights Reversing lights |
|  C5W <small>3912</small> |  | 12 | 5 | Blue lights |
|  C10W <small>3912</small> |  | 12 | 10 | Interior lighting ceiling lamps |
|  R5W <small>3025</small> |  | 12 | 5 | Number plate lights Tail parking lights Marker lights |
|  T4W <small>3027</small> |  | 12 | 4 | Front marker lights Swivel spotlight |
|  2W <small>3028</small> |  | 12 | 2 | Instrument and warning lamp lights |
|  LED <small>3029</small> |  | 1,2 ÷ 1,5 | 10 ÷ 50 mW | IVECO Control warning lamps |

SIGNALS

| | Page |
|--|------|
| STEERING COLUMN SWITCH (TURN SIGNAL LIGHTS) | 3 |
| FRONT TURN SIGNAL LIGHT | 4 |
| TURN SIGNAL SIDE REPEATER | 5 |
| HAZARD LIGHT SWITCH WITH BUILT-IN WARNING LAMP | 6 |
| STOP SIGNAL SWITCH | 7 |
| REVERSING LIGHT SWITCH | 8 |
| HORN | 9 |
| ELECTRIC/AIR HORN SWITCH | 10 |
| HAZARD LIGHTS ON WARNING LAMP | 11 |

SIGNALS
Steering column switch (Turn signal lights)

SIMPLIFIED DIAGNOSIS

Disconnect connector **B** from C.I.U.

Set multimeter to VOLT:

Move ignition switch key to position 15.

Ensure 12 Volts are available by setting one multimeter prod to terminal 9 of C.I.U. connector **B** and the other one to earth.


Set multimeter to OHM:

Put the key in rest position.

Set the steering column switch to lh turn signal light. Check for 0 Ω by setting multimeter prods to terminals 9 and 6 of steering wheel switch connector **B**. Set the steering wheel switch to rh turn signal light position.

Check for 0 Ω by setting multimeter prods to terminals 9 and 7 of steering wheel switch connector **B**.


If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 7

NOTE. Refer to page I.64 for a complete view of steering wheel switch and relevant wiring.

54033 B



5186


LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|----------------|----------------------------|------------------|
| 1 (d) | Not used | — |
| 2 (e) | Not used | — |
| 3 (g) | Not used | — |
| 4 (s) | Not used | — |
| B 5 (f) | Not used | — |
| 6 (b) | Lh turn signal light | light blue/black |
| 7 (c) | Rh turn signal light | light blue |
| 8 (n) | Not used | — |
| 9 (a) | Turn signal flashing light | violet |
| 10 (t) | Not used | — |

Front turn signal light


SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.
 Set multimeter to VOLT:
 Put the ignition switch key in position 15.
 Set steering wheel switch (page VI.3) to turn signal light position.
 Ensure 12 Volts are available by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.
 Set multimeter to OHM.
 Put the key in rest position. Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to earth.
 If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 7

32002



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | 1 Supply of hazard/turn signal headlight bulb | 1129 |
| | 2 Earth | 0000 |

Turn signal side repeater

SIMPLIFIED DIAGNOSIS


Disconnect connector **A** from component under examination.

Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to terminal 9 of C.I.U. connector 1.


Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 7

33001



5202

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | 1 Earth | 0000 |
| | 2 Supply of hazard/turn signal side repeater bulb | 1126 |

Hazard light switch with built-in warning lamp

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT:

Check for 12 V by setting one multimeter prod to terminal 2 of connector **A** and the other one to earth.

Put ignition switch key to position 15.

Ensure 12 Volts are available by setting one multimeter prod to terminal 8 of connector **A** and the other one to earth.


Set multimeter to OHM.

Put the key in rest position.

Press the hazard light switch. Check for 0 Ω by setting multimeter prods to switch terminals 4 and 2.


Check for 0 Ω by setting multimeter prods to switch terminals 7 and 1 first and then to terminals 7 and 3.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 7

52302



52303

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|--|--------------|
| 1 | Supply of steering wheel switch (side rh turn signal light bulb) To side rh turn signal light bulb | 1111 1124 |
| 2 | Supply (+30) | 7728 |
| 3 | Supply of steering wheel switch (side lh turn signal light bulb) To side lh turn signal light bulb | 1111 1126 |
| 4 | Supply of electronic flasher light (hazard/turn signal light with hazard light switch) | 8872 |
| A 5 | Supply of turn signal light bulbs with hazard light switch on | 1103 |
| 6 | Supply (+15) of electronic flasher light (hazard/turn signal light and jumper to switch cell no. 4) | 8872 |
| 7 | Supply of switch lighting bulb | 8879 |
| 8 | Supply (+15) | 8872 |
| 9 | Not used | — |
| 10 | Earth | 0000 |

Stop signal switch

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT:

Put switch key in position 15. Ensure 12 Volts are available by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

Set multimeter to OHM:

Put the key in rest position and operate the switch.


Check for 0 Ω by setting multimeter prods to terminals 1 and 2 of connector **A**.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 8

53501



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|------------------------------------|--------------|
| A | 1 Supply (+15) | 1117 |
| | 2 Stop light bulb switch on device | 1117 |
| | 3 Not used | — |

Reversing light switch

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT:

Put switch key in position 15.


Ensure 12 Volts are available by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

Set multimeter to OHM.

Put the key in rest position and operate the switch.


Check for 0 Ω by setting one multimeter prod to terminal of connector **A** and other one to either connector C or terminal 4 of tail headlight connector **A** (pages V.13/V.14).

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 8

53503



5295

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | 1 Supply (+15) | 2268 |
| | 2 Reversing light bulb switch on device | 2227 |

Horn

SIMPLIFIED DIAGNOSIS

Disconnect connectors **A** and **B** from component under examination.


Set multimeter to VOLT.

While keeping the steering wheel pushbutton pressed check for 12 V by setting one multimeter prod to terminal of connector **A** and the other one to earth.

Set multimeter to OHM.


Return the steering wheel pushbutton to rest position. Check for 0 Ω by setting one multimeter prod to terminal of connector **B** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 10

2200!



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|-------------|--------------|
| A | Horn supply | 1116 |
| B | Earth | 0000 |

Electric/air horn switch (bus)

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.


While keeping the relevant steering wheel pushbutton pressed check for 12 V by setting one multimeter prod to terminal 5 of connector **A** and the other one to earth.

Set multimeter to OHM.


Check for 0 Ω by setting multimeter prods to terminals 5 and 1 of horn switch.

Press the switch key and repeat the test.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961. School bus Basic Wiring Diagram



52200

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|--|--------------|
| 1 | Horn switch on device | 1116 |
| 2 | Not used | - |
| 3 | Not used | - |
| 4 | Not used | - |
| A 5 | Supply of electric/air horn switch on device | 1116 |
| 6 | Not used | - |
| 7 | Air horn switch on device | 1133 |
| 8 | Not used | - |
| 9 | Supply (I5/A) for switch lighting | 8879 |
| 10 | Earth | 0000 |

Hazard lights on warning lamp (bus)

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from warning lamp and operate safety unit switch.


Set multimeter to VOLT.

Check for 12 V by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth. If reading is other than specified set one multimeter prod to terminal 2 of connector **A** and repeat the test.

Set multimeter to OHM.


Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth. Press the switch key and repeat the test. If reading is other than specified set one multimeter prod to terminal 2 of connector **A** and repeat the test.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 18

58202



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | – Supply of hazard lights on warning lamp bulb | |
| | – Earth of warning lamp bulb with safety unit switch on | |

SERVICES

| | Page |
|---|------|
| STEERING COLUMN SWITCH (WINDSCREEN WIPER UNIT AND ELECTRIC WASHER PUMP) | 3 |
| WINDSCREEN WIPER UNIT | 4 |
| WINDSCREEN WIPER INTERMITTENT OPERATION DEVICE | 5 |
| CONTROL DEVICE FOR WINDSCREEN WASHER FLUID LEVEL INDICATOR | 7 |
| HEADLAMP WASHER UNIT SWITCH | 8 |
| HEADLAMP WASHER UNIT TIMER | 9 |
| HEADLAMP ELECTRIC WASHER PUMP | 10 |
| ENGINE COOLING ELECTROMAGNETIC COUPLING OPERATION SWITCH | 11 |
| INTERIOR LIGHTING SWITCH | 12 |
| CAB INTERIOR CEILING LAMP WITH SWIVEL SPOTLIGHT | 13 |
| FRONT/REAR DOOR STEP LIGHT | 14 |
| INTERIOR LIGHTING SWITCH | 15 |
| INTERIOR LIGHTING – BLUE LIGHTS SWITCH | 16 |
| BLUE AND NORMAL INTERIOR LIGHTING CEILING LAMP | 17 |
| STEP LIGHTING CEILING LAMP | 18 |
| LUGGAGE COMPARTMENT CEILING LIGHT | 19 |
| CIGAR LIGHTER | 20 |
| ASHTRAY LIGHT | 21 |
| INTERIOR LIGHTING SWITCH | 22 |
| INTERIOR HEATING MOTOR | 23 |
| INTERNAL AERATOR SWITCH WITH BUILT IN WARNING LAMP | 24 |
| HEADLAMP ALIGNMENT CONTROL SWITCH | 25 |

| | Page |
|---|------|
| HEADLAMP ALIGNMENT UNIT ACTUATOR | 26 |
| POWER WINDOW SWITCH | 27 |
| POWER WINDOW MOTOR | 28 |
| ADJUSTABLE REARVIEW MIRROR SWITCH | 29 |
| HEATED REARVIEW MIRROR SWITCH WITH BUILT-IN WARNING LAMP | 30 |
| ELECTRICALLY-OPERATED HEATED REARVIEW MIRROR | 31 |

SERVICES**Steering column switch (Windscreen wipers – Electric washer pump)****SIMPLIFIED DIAGNOSIS**

Disconnect connector **IK** from C.I.U.

Set multimeter to VOLT.

Put the ignition key in position 15.

Check for 24 V by setting one multimeter prod to terminal 6 of connector **IK** and the other one to earth.

Set multimeter to OHM and take the following measurements on steering column switch terminals.

Turn the ignition key to OFF position.


Move the steering column switch lever to "intermittent operation". Check for 0 Ω by setting multimeter prods to terminals 2 3 and 1 6.

Put the steering wheel switch in "low speed" position. Check for 0 Ω by setting multimeter prods to terminals 5 and 6


Put the steering column switch lever in "high speed" position. Check for 0 Ω by setting multimeter prods to terminals 4 and 6

Put the lever in "windshield washing" position. Check for 0 Ω by setting multimeter prods to terminals 5 and 6.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 9

54033 E-F**LAYOUT WITH CONNECTIONS**

| Connector | Function | Cable colour |
|-----------|--|-------------------|
| 1 (l) | Windscreen wipers (intermittent operation) | yellow |
| 2 (p) | Windscreen wipers (resetting) | light blue/white |
| 3 (m) | Windscreen wipers (low speed) | light blue/yellow |
| 4 (i) | Windscreen wipers (high speed) | grey |
| 5 (q) | Windscreen washer electric pump | green/black |
| 6 (h) | Supply of windscreen wiper unit and washer electric pump | pink/black |

Windscreen wiper unit (Gear motor)

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT:

Turn ignition switch key to position 15.


Ensure 12 Volts are available by setting one multimeter prod to terminal 3 of connector **A** and the other one to earth.

Set multimeter to OHM.


Set the key to rest position.

Ensure the presence of 0 Ω by setting one multimeter prod to terminal 6 of connector **C** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 9



65000

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------------|-----------------------------|--------------|
| 1 (31b) | Windscreen wipers resetting | 8873 |
| 2 (53) | Low speed | 8882 |
| A 3 (53a) | Gearmotor supply | 8880 |
| 4 (53b) | High speed | 8881 |
| 5 | Not used | - |
| 6 (31) | Earth | 0000 |

Windscreen wiper unit intermittent operation

SIMPLIFIED DIAGNOSIS

Remove component under examination from the C.I.U.

Set multimeter to VOLT:

Turn ignition switch key to position 15.


Ensure 12 Volts are available by setting one multimeter prod to terminal 3 of connector E9 (page I.54) and the other one to earth.

Set multimeter to OHM.

Set the key to rest position.


Ensure the presence of 0 Ω by setting one multimeter prod to terminal 6 of C.I.U. connector E9 and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 9

59100



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| I | Windscreen wiper unit low speed timing | — |
| II | Windscreen wiper unit control after activation of windscreen washer electric pump | — |
| III | Supply | — |
| IV | Windscreen wiper unit low speed | — |
| V | Windscreen wiper unit resetting | — |
| VI | Earth | — |

Windscreen washer electric pump

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Turn ignition switch key to position 15.


Put steering column switch in windscreen washing position. Ensure 12 Volts are available by setting one multimeter prod to terminal 2 of connector **A** and the other one to earth.

Set multimeter to OHM.

Set the key to rest position.


Ensure the presence of 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 9

64000



5212

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|----------------------------|--------------|
| A | 1 Earth | 0000 |
| | 2 Electric pump enablement | 8886 |

Windscreen washer electric pump

SIMPLIFIED DIAGNOSIS


Disconnect connector **A** from component under examination.

Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to terminal 7 of IVECO Control display panel connector (page IV.15).


Check for 0 Ω by setting one multimeter prod to terminal 3 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 4

44035



3213

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--|--------------|
| A | 1 Not used | — |
| | 2 To IVECO Control display panel (windscreen washer fluid level) | 5521 |
| | 3 Earth | 0000 |

Headlamp washer unit switch

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOI T.

Press the exterior lighting switch (page V.3) to 1st release.


Check for 12 V by setting one multimeter prod to terminal 5 of connector **A** and the other one to earth.

Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to terminal 5 of headlamp washer unit timer connector (page VII.9).


Press the switch and check for 0 Ω by setting multimeter prods to terminals 1 and 5 of same switch.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 9

53004



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--|--------------|
| A | 1 Supply from exterior lighting switch | 3330 |
| | 2 Not used | — |
| | 3 Not used | — |
| | 4 Not used | — |
| | 5 To headlamp washer unit timer | 3330 |
| | 6 Not used | — |
| | 7 Not used | — |
| | 8 Not used | — |
| | 9 Supply (+15/A) for switch lighting | 8879 |
| | 10 Earth | 0000 |

Headlamp washer unit timer

MULTIMETER DESCRIPTION

Disconnect connector **A** from component under examination.
Set multimeter to Ω or V .

Check for 12 V by setting one multimeter prod to terminal 30 of connector **A** and the other one to earth.

Set the ignition key to position 15 and check for 12 V by setting one multimeter prod to terminal 56 of connector **A** and the other one to earth.

Set multimeter to Ω or V .

Return the key to rest position. Check for 0 Ω by setting one multimeter prod to terminal 31 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.





Figure 40-329d Diagnostic

66010



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|---------------------------------------|--------------|
| 30 | Supply (+15) | 8823 |
| 31 | Earth | 0000 |
| A P | Headlamp washer pump enablement | 8821 |
| S | Headlamp washer pump switch on device | 3330 |
| 56 | Supply (+15/A) | 8820 |

Headlamp washer electric pump

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.


Press the exterior lighting switch (page V.3) to 1st release and operate the headlamp washer unit switch (page VII.8).

Check for 12 V by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

Set multimeter to OHM.


Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 9

66005



5216

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---------------------------|--------------|
| A | 1 Electric pump operation | 8821 |
| | 2 Earth | 0000 |

Engine cooling electromagnetic coupling switch

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Put the ignition key in position 15.


Check for 12 V by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

Set multimeter to OHM.

Return the ignition key to rest position.


Ensure resistance value is $= \infty$ by setting multimeter prods to connector terminals 1 and 2.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 10

47104



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | 1 Engine cooling electromagnetic coupling operation | 7772 |
| | 2 Supply (+15/A) | 7772 |

Interior lighting switch


SIMPLIFIED DIAGNOSIS

Disconnect connectors **A** and B from component under examination.
Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal of connector B and the other one to connector D of cab interior ceiling lamp (page VII.13)


Check for 0 Ω by setting one multimeter prod to terminal of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 11

52021



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--|--------------|
| A | Earth | 0000 |
| B | To cab interior ceiling lamp with swivel spotlight | 0003 |

Cab interior ceiling lamp with swivel spotlight

SIMPLIFIED DIAGNOSIS

Disconnect connectors **A**, **B**, **C** and **D** from component under examination.

Set multimeter to VOLT.


Check for 12 V by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to connector **C** and the other one to earth.


Open the door and check for 0 Ω by setting one multimeter prod to connector **D** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.47.961 Diagram no. 11

39022



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | Lamp supply (+30) | 4418 |
| B | Earth | 0000 |
| C | Earth | 0000 |
| D | Ceiling lamp illumination via door opening system | 0003 |

Ceiling lamp for front/rear door step lighting (vans)

SIMPLIFIED DIAGNOSIS

Disconnect connectors |A| and B from component under examination.


Set multimeter to VOLT.

Check for 12 V by setting one multimeter prod to terminal of connector |A| and the other one to earth.

Set multimeter to OHM.


Open the rear door and check for 0 Ω by setting one multimeter prod to connector |B| and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 11

39014 | **39016**



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|-------------------|--------------|
| A | Lamp supply (+30) | 4418 |
| B | Lamp supply (+30) | 4418 |

Interior lighting switch (bus)

SIMPLIFIED DIAGNOSIS

Disconnect connectors **A** from component under examination.


Set multimeter to VOLT.

Check for 12 V by setting one multimeter prod to terminal 5 of connector **A** and the other one to earth.


Set multimeter to OHM.

Press the switch key and check for 0 Ω by setting multimeter prods to terminals 1 and 5 of same switch.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 11



52021

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|------------------------------------|--------------|
| 1 | Supply for interior lighting | 4440 |
| 2 | Not used | — |
| 3 | Not used | — |
| 4 | Not used | — |
| 5 | Supply (+30) | 4441 |
| A 6 | Not used | — |
| 7 | Not used | — |
| 8 | Not used | — |
| 9 | Supply (+15/A) for switch lighting | 8879 |
| 10 | Earth | 0000 |

Interior lighting – Blue lights switch (Bus)

SIMPLIFIED DIAGNOSIS

Disconnect connector [A] from component under examination.


Set multimeter to VOLT.

Check for 12 V by setting one multimeter prod to terminal 5 of connector [A] and the other one to earth.

Set multimeter to OHM.


Press the switch key and check for 0 Ω by setting multimeter prods to terminals 1 and 5 of same switch.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 11

52017



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|------------------------------------|--------------|
| 1 | Supply of blue interior lamps | 4442 |
| 2 | Not used | — |
| 3 | Not used | — |
| 4 | Not used | — |
| 5 | Supply (+30) | 4418 |
| A 6 | Not used | — |
| 7 | Not used | — |
| 8 | Not used | — |
| 9 | Supply (+15/A) for switch lighting | 8879 |
| 10 | Earth | 0000 |

Blue and normal interior lighting ceiling lamp (bus)

SIMPLIFIED DIAGNOSIS

Disconnect connectors **A**, **B**, **C**, **D** from component under examination. Set multimeter to VOLT.


Press the interior lighting switch (page VII.15) and check for 12 V by setting one multimeter prod to terminal of connector **A** and the other one to earth.

Press the interior blue lighting switch (page VII.16) and check for 12 V by setting one multimeter prod to connector **B** and the other one to earth.


Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to connector **D** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 11



39019

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|-------------------------|--------------|
| A | Supply of normal lights | 4440 |
| B | Supply of blue lights | 4422 |
| C | Supply of normal lights | 4440 |
| D | Earth | 0000 |

Step lighting ceiling lamp (bus)


SIMPLIFIED DIAGNOSIS

Disconnect connectors **A** and **B** from component under examination. Set multimeter to VOLT.

Check for 12 V by setting one multimeter prod to end of cable **A** and the other one to earth.


Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to end of cable **B** and the other one to terminal 1 of connector C2 (Workshop Manual chart 16). If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603:12.961 Diagram no. 11

39003



5221

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | Lamp supply (+30) | 4418 |
| B | Ceiling lamp illumination via swing-sliding door opening system | 0003 |

Luggage compartment ceiling lamp (bus)

SIMPLIFIED DIAGNOSIS


Disconnect connectors **A** and **B** from component under examination.
Set multimeter to VOLT.

Check for 12 V by setting one multimeter prod to terminal of connector **A** and the other one to earth.

Set multimeter to OHM.


Check for 0 Ω by setting one multimeter prod to terminal of connector **B** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 11

39005



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | Lamp supply (+30) | 4423 |
| B | Ceiling lamp supply via luggage compartment door opening system | 0000 |

Cigar lighter

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.


Set multimeter to VOLT.

Check for 12 V by setting one multimeter prod to terminal 2 of connector **A** and the other one to earth.

Set multimeter to OHM.


Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **B** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 10

85000



5226

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--|--------------|
| A | Parking light positive for cigar lighter | 4443 |
| B | 1 Earth | 0000 |
| | 2 Cigar lighter supply (+30) | 7721 |

Ashtray light

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Press the exterior lighting switch (page V.3) once.

Check for 12 V by setting one multimeter prod to terminal 2 of connector **A** and the other one to earth.

Set multimeter to OHM.


Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 5

39020




LAYOUT WITH CONNECTIONS

| Connector | | Function | Cable colour |
|-----------|---|--|--------------|
| A | 1 | Earth | 0000 |
| | 2 | Parking light positive for ashtray light | 4420 |

Interior lighting switch (bus)


SIMPLIFIED DIAGNOSIS

- Disconnect connector **A** from component under examination.
 - Set multimeter to VOLT.
 - Put the ignition switch key in position 15.
 - Check for 12 V by setting one multimeter prod to terminal 5 of connector **A** and the other one to earth.
 - Set multimeter to OHM.
 - Return the key to rest position.
 - Press the switch key and check for 0 Ω by setting multimeter prods to terminals 1 and 5 of same switch.
- If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 11

52030



5228

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--------------------------------------|--------------|
| A | 1 Interior heating motor operation | 7003 |
| | 2 Not used | — |
| | 3 Not used | — |
| | 4 Not used | — |
| | 5 Supply (+15/A) | 7706 |
| | 6 Not used | — |
| | 7 Not used | — |
| | 8 Not used | — |
| | 9 Supply (+15/A) for switch lighting | 8879 |
| | 10 Earth | 0000 |

Interior heating motor (bus)

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Put the ignition switch key in position 15.


While keeping the interior heating switch key pressed (page VII.22) check for 12 V by setting one multimeter prod to terminal 2 of connector **A** and the other one to earth.

Set multimeter to OHM.

Return the key to rest position.


Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.47.961 Diagram no. 11

12009



5279

LAYOUT WITH CONNECTIONS

| Connector | | Function | Cable colour |
|-----------|---|------------------------|--------------|
| A | 1 | Earth | 0000 |
| | 2 | Interior heating motor | 7003 |

Internal aerator switch with built-in warning lamp

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Put the ignition switch key in position 15.

Check for 12 V by setting one multimeter prod to terminal 4 of connector **A** and the other one to earth.


Set multimeter to OHM.

Return the key to rest position.

Set the switch to either one of the two available positions and check for 0 Ω by setting multimeter prods to terminals 4-7 and 3-8 of same switch.


Put the switch in the other position and check for 0 Ω by setting multimeter prods to terminals 4-1 and 3-2 of same switch.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 11

52311



5239

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|------------------------------------|--------------|
| 1 | To internal aerator motor | 8858 |
| 2 | To internal aerator motor | 8855 |
| 3 | To internal aerator motor | 2220 |
| 4 | Supply (+15/A) | 7706 |
| 5 | Not used | - |
| 6 | Not used | - |
| 7 | To switch cell no. 2 | 8855 |
| 8 | To switch cell no. 1 | 8858 |
| 9 | Supply (+15/A) for switch lighting | 8879 |
| 10 | Earth | 0000 |

Headlamp alignment control switch

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.
Set multimeter to VOLT.


Press the exterior lighting switch (page V.3) once.

Check for 12 V by setting one multimeter prod to terminal 5 of connector **A** and the other one to earth.

Set multimeter to OHM.


Check for 0 Ω by setting one multimeter prod to terminal 4 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 6

52312



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--|--------------|
| A | 1 To headlamp alignment unit actuator | 9934 |
| | 2 To headlamp alignment unit actuator | 9935 |
| | 3 To headlamp alignment unit actuator | 9936 |
| | 4 Earth | 0000 |
| | 5 Supply from exterior lighting switch | 2235 |

Headlamp alignment unit actuator

SIMPLIFIED DIAGNOSIS


Disconnect connector **A** from component under examination.

Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to terminal 3 of headlamp alignment unit actuator switch (page VII.25).


Repeat the test with multimeter prods set to terminal 2 of connector **A** and terminal 2 of the switch and terminal 3 of connector **A** and terminal 1 of the switch.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.47.961 Diagram no. 6

30100



1233

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | 1 To headlamp alignment unit control switch | 9936 |
| | 2 To headlamp alignment unit control switch | 9935 |
| | 3 To headlamp alignment unit control switch | 9934 |

Power window switch

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Put the ignition switch key in position 15.

Check for 12 V by setting one multimeter prod to terminal 4 of connector **A** and the other one to earth.

Set multimeter to OHM.


Return the key to rest position.

Check for 0 Ω by setting one multimeter prod to terminal 3 of connector **A** and the other one to earth.

While keeping the switch pressed in either one of the two available positions check for 0 Ω by setting multimeter prods to terminals 4-2 and 3-1 of same switch.


With the switch pressed in the other position check for 0 Ω by setting multimeter prods to terminals 4-8 and 3-7 of same switch.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 13

53300 53302



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--------------------------------------|--------------|
| A | 1 Jumper to switch cell no. 8 | 8863 |
| | 2 To power window motor | 8863 |
| | 3 Jumper to switch cell no. 10 | 0000 |
| | 4 Supply (+15/A) | 8871 |
| | 5 Not used | - |
| | 6 Not used | - |
| | 7 Jumper to switch cell no. 2 | 8863 |
| | 8 To power window motor | 8863 |
| | 9 Supply (+15/A) for switch lighting | 8879 |
| | 10 Earth | 0000 |

Power window motor

SIMPLIFIED DIAGNOSIS


Disconnect connector [A] from component under examination.

Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 1 of connector [A] and the other one to terminal 2 of power window switch (page VII.27).


Check for 0 Ω by setting one multimeter prod to terminal 2 of connector [A] and the other one to terminal 8 of power window switch connector.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.47.961 Diagram no. 13

80000 80001



5235

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|------------------------|--------------|
| [A] 1 | To power window switch | 8863 |
| [A] 2 | To power window switch | 8863 |

Adjustable rearview mirror switch

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Put the key in position 15.

Check for 12 V by setting one multimeter prod to terminal 4 of connector **A** and the other one to earth.


Repeat the same test on terminal 5.

Set multimeter to OHM.

Return the key to rest position.


Check for 0 Ω by setting one multimeter prod to terminal 7 of connector **A** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 13

52310



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|---|--------------|
| 1 | To lh rearview mirror adjustment motor | 8857 |
| 2 | To common terminal for rearview mirror adjustment | 8859 |
| 3 | To rh rearview mirror adjustment motor | 8857 |
| A 4 | Supply (+15/A) | 8871 |
| 5 | Supply (+15/A) for switch lighting | 8879 |
| 6 | To lh rearview mirror adjustment motor | 8858 |
| 7 | Earth | 0000 |
| 8 | To rh rearview mirror adjustment motor | 8858 |

Heated rearview mirror switch with built-in warning lamp

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Put the key in position I5.


Check for 12 V by setting multimeter prod to terminal 5 of connector **A** and the other one to earth.

Set multimeter to OHM.

Return the key to rest position.


While keeping the switch key pressed check for 0 Ω by setting multimeter prods to terminals 1 and 5 of same switch.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 | Diagram no. 13

52005



5237

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|-------------------------------------|--------------|
| 1 | To heated rearview mirror resistors | 8830 |
| 2 | Not used | - |
| 3 | Not used | - |
| 4 | Not used | - |
| 5 | Supply (+15/A) | 8879 |
| A 6 | Not used | - |
| 7 | Not used | - |
| 8 | Not used | - |
| 9 | Supply (+15/A) for switch lighting | 8879 |
| 10 | Earth | 0000 |

Electrically-operated heated rearview mirror

SIMPLIFIED DIAGNOSIS

Disconnect connectors **A**, **B**, and **C** from component under examination.

Set multimeter to OHM.


Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to terminal 1 of adjustable rearview mirror switch (page VII.29).

Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to terminal 6 of the switch. Repeat the test with multimeter prods set to terminal 3 of connector **A** and terminal 2 of the switch.


Check for 0 Ω by setting one multimeter prod to terminal of connector **C** and the other one to terminal 1 of heated rearview mirror connector (page VII.30).

Check for 0 Ω by setting one multimeter prod to terminal of connector **B** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 13



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|---|--------------|
| A | 1 To adjustable rearview mirror switch | 8857 |
| | 2 To adjustable rearview mirror switch | 8858 |
| | 3 To adjustable rearview mirror switch | 8859 |
| B | – Earth | 0000 |
| C | – Supply of heated rearview mirror resistor | 8830 |

SPECIAL CIRCUITS

| | Page |
|--|------|
| ABS SYSTEM SOLENOID VALVE AND RELAY UNIT | 3 |
| ABS SYSTEM ELECTRONIC CONTROL UNIT | 4 |
| ABS SYSTEM FRONT AXLE WHEEL SENSORS | 6 |
| ABS SYSTEM REAR AXLE WHEEL SENSORS | 7 |

SPECIAL CIRCUITS**ABS system solenoid valve and relay unit****SIMPLIFIED DIAGNOSIS**

Disconnect connector blocks **A** and **B** from component under examination.

Set multimeter to VOLT:


Check for 12 V by setting one multimeter prod to terminal 6 of connector **A** and the other one to earth.

Check for 12 V by setting one multimeter prod to terminal 10 of connector **A** and the other one to earth.

Set multimeter to OHM.


Check for 0 Ω by setting one multimeter prod to terminal of connector **B** and the other one to earth.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 1-1

88003

**LAYOUT WITH CONNECTIONS**

| Connector | Function | Cable colour | |
|-----------|----------|---|-------------------|
| A | 1 | To terminal 2 of ABS control unit | light blue/green |
| | 2 | To terminal 27 of ABS control unit | light blue/black |
| | 3 | To terminal 18 of ABS control unit | light blue/red |
| | 4 | To terminal 32 of ABS control unit | light blue/yellow |
| | 5 | To terminal 19 of ABS control unit | light blue/white |
| | 6 | Supply (+30) | red |
| | 7 | To terminal 35 of ABS control unit | grey/black |
| | 8 | To terminal 17 of ABS control unit | white |
| | 9 | To terminal 14 of ABS control unit | yellow |
| | 10 | Supply (+30) | red |
| | 11 | To cab loom junction block (cell no. 4) | violet |
| | 12 | To terminal 28 of ABS control unit | grey |

ABS system electronic control unit

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Put the ignition switch key in position 15.


Check for 12 V by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

Set multimeter to OHM.

Return the key to OFF position.


Check for 0 Ω by setting one multimeter prod to terminal 10 of connector **A** and the other one to earth. Repeat the test with multimeter prods set to terminals 20 and 34.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 14

88000



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|--|------------------|
| 1 | Supply (+30) with overvoltage protection relay on | white |
| 2 | To ABS solenoid valve and relay unit (solenoid valve) | light blue/green |
| 3 | To Telma retarder prearrangement | light blue/white |
| 4 | To ABS front lh sensor | Brown |
| 5 | Not used | — |
| 6 | To ABS front lh sensor | Light blue |
| 7 | To ABS rear lh sensor | Light blue |
| A 8 | Not used | — |
| 9 | To ABS rear lh sensor | Brown |
| 10 | Earth | Brown |
| 11 | To ABS front rh sensor | Light blue |
| 12-13 | Not used | — |
| 14 | To ABSS solenoid valve relay unit (relay) | Yellow |
| 15 | Alternator positive (D+) | Light blue |
| 16 | Not used | — |
| 17 | To ABS solenoid valve and relay unit (common for both relay coils) | White |

ABS system electronic control unit

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from component under examination.

Set multimeter to VOLT.

Put the ignition switch key in position 15.


Check for 12 V by setting one multimeter prod to terminal 1 of connector **A** and the other one to earth.

Set multimeter to OHM.

Return the key to OFF position.


Check for 0 Ω by setting one multimeter prod to terminal 10 of connector **A** and the other one to earth. Repeat the test with multimeter prods set to terminals 20 and 34.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 14

88000



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-------------|---|-------------------|
| 18 | To ABS solenoid valve and relay unit (solenoid valve) | light blue/red |
| 19 | To ABS solenoid valve and relay unit (solenoid valve) | light blue/white |
| 20 | Earth | brown |
| 21 | To ABS front rth sensor | brown |
| 22-23 | Not used | - |
| 24 | To ABS rear rth sensor | light blue |
| 25 | Supply (+15) with stop signal switch on | light blue |
| A 26 | To ABS rear lth sensor | brown |
| 27 | To ABS solenoid valve and relay unit (relay) | light blue/black |
| 28 | To ABS solenoid valve and relay unit (relay) | grey |
| 29 | ABS system failure indicator | violet |
| 30-31 | Not used | - |
| 32 | To ABS solenoid valve and relay unit | light blue/yellow |
| 33 | Not used | - |
| 34 | Earth | brown |
| 35 | To ABS solenoid valve and relay unit (solenoid valve) | grey/black |

ABS system front wheel sensors


SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from ABS sensors.


Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 2 of connector **A** and the other one to terminal 4 of ABS control unit connector.
 Check for 0 Ω by setting one multimeter prod to terminal 1 of connector **A** and the other one to terminal 6 of ABS control unit connector.
 Repeat the test with multimeter prods set to terminal 5 of connector **A** and terminal 11 of control unit, terminal 4 of connector **A** and terminal 21 of control unit.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 14



88001

| | |
|----|-------------|
| AS | Front left |
| AD | Front right |

LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|-----------|--------------------------------------|--------------|
| A | 1 To terminal 6 of ABS control unit | light blue |
| | 2 To terminal 4 of ABS control unit | brown |
| | 3 Not used | — |
| | 4 To terminal 21 of ABS control unit | brown |
| | 5 To terminal 11 of ABS control unit | light blue |
| | 6 Not used | — |
| | 7 Not used | — |
| | 8 Not used | — |
| | 9 Not used | — |

ABS system rear axle wheel sensors

SIMPLIFIED DIAGNOSIS

Disconnect connector **A** from ABS sensors.


Set multimeter to OHM.

Check for 0 Ω by setting one multimeter prod to terminal 6 of connector **A** and the other one to terminal 9 of ABS control unit connector.

Check for 0 Ω by setting one multimeter prod to terminal 7 of connector **A** and the other one to terminal 7 of ABS control unit connector.


Repeat the test with multimeter prods set to terminal 8 of connector **A** and terminal 26 of control unit, terminal 9 of connector **A** and terminal 24 of control unit.

If readings are other than specified, remedy as required by either repairing the circuit or replacing the component. Then repeat the test.



Print no. 603.42.961 Diagram no. 14

88001



LAYOUT WITH CONNECTIONS

| Connector | Function | Cable colour |
|------------|------------------------------------|--------------|
| 1 | Not used | — |
| 2 | Not used | — |
| 3 | Not used | — |
| 4 | Not used | — |
| 5 | Not used | — |
| A 6 | To terminal 9 of ABS control unit | brown |
| 7 | To terminal 7 of ABS control unit | light blue |
| 8 | To terminal 26 of ABS control unit | brown |
| 9 | To terminal 24 of ABS control unit | light blue |

INDEX

A

- ABS, relay and solenoid valve unit, VIII.7
- Adaptor, speed, I.36
- Aerator, I.49
- Air-conditioning system, I.49
- Alternator, 14V 50-90A, I.27
- Alternator, 14V 55A, I.27
- Alternators, III.3
- Ashtray, I.32
- Axle, front, I.51
- Axle, rear, I.51

B

- Battery, I.26, II.5
- Battery charging using an external charger, II.13
- Battery, standard type, II.12
- Battery terminals, I.24
- Bus version, I.43

C

- Cab, I.51
- Central control panel, I.68
- Cigar lighter, VII.20
- Circuit, diagnosis, I.52
- Circuit, recharging, III.11
- Circuits, special, VIII.1
- C.I.U. (Central Interconnecting Unit), I.35, I.57
- C.I.U., relays and diode holders, I.58
- Combined module, I.30, IV.3
- Combined module (Daily vehicles), I.66
- Combined module (Turbodaily and Daily vehicles equipped with rev counter), I.67
- Common components, I.57
- Components, replacement instructions, I.26, 53
- Connectors, I.9
- Connectors, AMP type, I.21
- Connectors, cell identification, I.11

- Connectors, C.I.U., I.22, I.61
- Connectors, electronic control units, I.15
- Connectors, MIC-MARK type, I.17
- Connectors, Packard type, I.18
- Connectors, relays, I.23

D

- Dashboard, I.29
- Defect, earth, exterior lighting and signalling, I.56
- Defect, supply, I.56
- Diagnosis, circuit, I.52
- Diagnosis, reading keys, I.6
- Differential lock device, front, IV.29
- Door, swing-sliding, control device, I.44
- Door, swing-sliding, emergency opening from inside, I.45
- Door, swing-sliding, gearmotor and drive shaft, I.44
- Door, swing-sliding, opening from outside, I.45
- Doors, locking system, I.45

E

- Earth concept and electromagnetic compatibility, I.3
- Earth points, location on vehicle, I.6
- Electric heater, I.42
- Electric heater, control system, I.34
- Electric pump, headlight washer, VII.10
- Electric pump, windscreen washer, VII.6
- Electronic components, general instructions, I.2
- Electronic control unit, ABS system, VIII.3
- Electronic control unit, pre/after-heating (Daily vehicles), II.29
- Electronic control unit, pre/after-heating (Turbodaily vehicles), II.31
- Electronic control unit, preheating (Daily vehicles), I.28
- Electronic control unit, preheating (Turbodaily/Turbodaily 4x4 vehicles), I.28
- Engine stopping electromagnet, II.38
- Engine types, I.13

F

- Fuel, filter; heated, *II.44*
- Fuel tank, connection to atmosphere, solenoid valve, thermostarter;(Turbo daily vehicles), *II.37*
- Fuses and relays, auxiliary, *I.36*
- Fuses, relays and diode holders, *I.36*

G

- G.C.R.(General Current Relay), operation, *I.43*
- G.C.R. and opening switch removal, *I.43*
- G.C.R.(bus), *II.40*
- Glass, diffusor/refractor; *V.18*
- Graphs and symbols, *10*

H

- Headlight, alignment actuator; *I.37, VII.26*
- Headlight, auxiliary driving light, *V.19*
- Headlight, high/low beam light with parking light, *I.38, V.5*
- Headlights, *V.18*
- Headlights, timer; washer pump, *VII.19*
- Horns, *I.41, VI.9*
- Horns, electric/pneumatic, switch (bus), *VI.10*

I

- Ignition switch, *I.28*
- Ignition switch, starter assisted services, *II.27, II.28*
- Indicator; control device, brake fluid level, *IV.19*
- Indicator; control device, engine coolant level, *IV.17*
- Indicator; control device, engine oil level, *IV.18*
- Indicator; control device, fuel with reserve w/lamp contact, *IV.8,9*
- Indicator; control device, power steering fluid level, *IV.23*
- Indicator; control device, windscreen washer fluid level, *VII.7*
- Instrument panel, *I.64*
- Instruments, *I.31, IV.1*
- Introduction, *I.4*
- IVECO Control display panel, description, *I.34, IV.15,16*

K

- Key switches, *I.30*

L

- Lamp, ceiling, cab interior with swivel spotlight, *VII.13*
- Lamp, ceiling, driver's place, *I.47*
- Lamp, ceiling, interior; normal and blue light (bus), *I.48, VII.17*
- Lamp, ceiling, luggage compartment (bus) *I.48, VII.19*
- Lamp, ceiling, passengers' door; *I.47*
- Lamp, ceiling, steps, *I.47*
- Lamp, ceiling, steps (bus), *VII.18*
- Lamp, ceiling, steps, front/rear doors (van), *VII.14*
- Lamps, *V.15*
- Lamps, fluorescent, *V.17*
- Lamps, halogen, *V.16*
- LEDs (Light Emitting Diodes), *V.16*
- Light, ashtray, *VII.21*
- Light, front marker, *I.40, V.8*
- Light, front turn signal, *I.39, VI.34*
- Light, fog, *I.39, V.7*
- Light, fog beam, *V.19*
- Light, high beam, *V.18*
- Light, low beam, *V.19*
- Light, low beam, European, asymmetric, *V.19*
- Light, number plate, *I.40, V.10*
- Light, number plate, vans and buses, *V.11*
- Light, side marker, *V.9, I.40*
- Light, tail cluster; *I.41, V.13*
- Light, tail cluster; vans and buses, *V.14*
- Light, tail cluster and number plate, *I.50*
- Light, turn signal side repeater; *I.39, VI.5*
- Lighting, exterior, *I.38, V.1*
- Lighting, interior; *I.37, I.47*
- Lighting, interior, van, *I.50*

M

- Main current switch, *II.43*
- Manual, composition, *9*

Motor; interior heating, *I.49*
 Motor; interior heating (bus), *VII.23*
 Motor; power window, *VII.28*
 Motor; starter, *I.27, II.12*
 Motor; windscreen wipers, *I.41*

O

Overvoltage, *I.55*

P

Plafoniera per illuminazione posto autista, *I.47*
 Parabola, *V.18*
 Power network, *I.1*
 Power network, simplified, Turbodaily vehicles, *II.13*
 Power network, simplified, Turbodaily vehicles, school bus version, *II.4*
 Power window, *I.33*
 Power window, motor, *VII.28*
 Preheating plugs (aspirated engine), *I.29*
 Pushbutton control strip, *I.44*

R

Reading keys, *I.5*
 Reading keys, diagnosis, *I.6*
 Reading keys, component specifications and possible defects, *I.8*
 Rearview mirror; heated, electrically -operated, *VII.31*
 Recharging circuit, *III.1, I.1*
 Relays and diode holders, C.I.U., *I.58*
 Resistor; variable, ignition timer, *II.46*
 Rev counter; electronic, *IV.4*
 Rev counter; electronic, sender unit, *IV.5*
 Rheostat, instrument lighting, *I.32*

S

Sensor; front rh wheel brake lining wear, *IV.20*
 Sensor; rear rh wheel brake lining wear, *IV.21*
 Sensors, front axle wheels, ABS system, *VIII.5*
 Sensors, rear axle wheels, ABS system, *VIII.6*
 Services, *VII.1*

Short circuit, *I.54*
 Signals, *VI.7*
 Special circuits, *VIII.1*
 Starting, *II.1*
 Starting from external trolley, *II.14*
 Steering column switch, *I.33, I.62*
 Steering column switch (high/low beam lights, flasher light), *V.4*
 Steering column switch, (turn signal lights), *VI.3*
 Steering column switch (windscreen wiper unit and washer pump), *VII.3*
 Switch, air cleaner restriction, *IV.22*
 Switch, all-wheel drive, *IV.26*
 Switch, differential lock, front, *IV.24, 27*
 Switch, differential lock, rear, *IV.25*
 Switch, electromagnetic coupling, engine cooling, *VII.11*
 Switch, engine oil pressure, *IV.13*
 Switch, exterior lighting, *V.3*
 Switch, fog lights and tail fog lights interlock, *V.6*
 Switch, fog lights, tail, *V.12*
 Switch, G.C.R. closing (bus), *II.39*
 Switch, G.C.R. opening (bus), *II.41*
 Switch, hazard lights, built in w/lamp, *VII.6*
 Switch, headlight alignment actuator, *I.37, VII.25*
 Switch, headlight washer pump, *VII.8*
 Switch, ignition, *I.28*
 Switch, ignition, *II.27, II.28*
 Switch, ignition timer, *II.45*
 Switch, internal aerator; built-in w/lamp, *VII.24*
 Switch, interior heating (bus), *VII.22*
 Switch, interior lighting, *VII.12*
 Switch, interior lighting (bus), *VII.15*
 Switch, interior lights, blue (bus), *VII.16*
 Switch, main current switch, *II.43*
 Switch, max speed with all wheel drive on speed signal, *IV.28*
 Switch, parking brake, *IV.14*
 Switch, power window, *VII.27*
 Switch, power window and swivel rearview mirrors, *I.34*
 Switch, preheating system (Turbodaily vehicles), *II.36*

Switch, rearview mirrors, *VII.29,30*
 Switch, reversing lights, *VI.8*
 Switch, safety unit, *I.46*
 Switch, safety unit (bus), *II.42*
 Switch, stop signal, *VI.7*
 Switches, 4x4 special functions, location on vehicle, *I.51*
 System specifications, *I.4*

T

Table of contents, *5*
 Tachograph/tachometer, electronic, sender unit, *IV.11*
 Tachometer, electronic, *I.30*
 Tachometer, electronic, clock, *IV.10*
 Temperature gauge, engine coolant, built-in w/lamp, *IV.6*
 Temperature gauge, engine coolant, sender unit, *IV.7*
 Test, battery charge, *II.11*
 Test, circuit continuity, *I.52*
 Tests, *III.8*
 Testing on vehicle, *II.6*

Thermostarter, *I.29, II.35*
 Top console, *I.46*
 Transfer case, *I.51*

V

Voltage drop, *I.54*
 Voltage regulator, electronic, *II.19*
 Voltmeter, *III.22*

W

Warning lamp, hazard lights (bus), *VI.11*
 Warning lamp, hazard lights and top console switches, *I.46*
 Warning lamps, *I.32*
 Welding, cables, ultrasound system, *I.7*
 Windscreen washer electric pump, *VII.6*
 Windscreen wiper unit, gearmotor, *VII.4*
 Windscreen wiper unit, intermittent operation, *VII.5*
 Wire terminal, fastening to conductors *I.25*
 Wire terminals, various connector types, fastening/unfastening, *I.13*

GENERAL LIST OF CONTENTS

| | Page |
|--------------------------------------|------|
| INTRODUCTION | VII |
| GENERAL | I |
| WIRING ON THE VEHICLE | 7 |
| CIRCUITRY DATA SHEETS | 57 |
| OPERATIONAL WIRING DIAGRAMS | 115 |
| MODEL YEAR '98 CIRCUITRY DATA SHEETS | 131 |
| CROSS – REFERENCES | 149 |

INTRODUCTION

Warnings

The symbols listed below are often used in the following pages. For your personal safety and the safety of the vehicle, it is imperative to follow carefully all the instructions and warnings given below.



Shows that failure to comply with the instructions may result in physical injuries.



Shows that failure to comply with the instructions may result in damages to the electrical equipment and/or the systems and/or instruments.



Shows a warning of a general nature.

General conditions for the preparation of the wiring diagrams













- i.c. engine off
- key-operated switch off
- Hand-brake engaged
- Gearbox in neutral
- Liquid level is normal




For more detailed information on the components adopted for the Daily/TurboDaily/TurboDaily 4X4 range, see the manual "Electrical/electronic components", publication n°. 603.42.971.

The technical codes (component codes and cable colour codes) can be found in manual "Warnings and Technical codes" publication n°. 603.42.936.


Abbreviations and graphic symbols used in tents.

| | | |
|--|---|--|
| <p>B Connector on UCI B = identification letter</p> |  | <p>Laminar fuse on UCI 1 = identification number</p> |
| <p>ABS Antilocking braking system</p> |  | <p>Connector between two cables IX = identification number 2 = cell number</p> |
| <p>ACS Automatic clutch</p> |  | <p>Connection to the ground via a component</p> |
| <p>EDC Electronic injection control</p> |  | <p>Connection to the ground via cable</p> |
| <p>EI Housing for remote control switch or diode-holder on UCI</p> |  | <p>Optional electrical connection</p> |
| <p>M Identification of a grounding point</p> |  | <p>Connection present in Daily vehicles</p> |
| <p>SU Ultrasonic welding</p> |  | <p>Connection present in TurboDaily vehicles</p> |
| <p>TGC Main switch</p> |  | <p>Component present in Truck version</p> |
| <p>UCI Central Interconnection Unit</p> |  | <p>Connection or component present in 4x4 version</p> |
| <p>-7777- Cable colour code</p> |  | <p>Connection or component present in van version</p> |
| <p>52307 Component code</p> | | |
|  | | |
|  | | |


DATA SHEET I: STARTING / RECHARGE




DATA SHEET I: STARTING / RECHARGE (BUS)




DATA SHEET I: STARTING / RECHARGE (BUS)



DATA SHEET 18: SAFETY SYSTEM (BUS)




DATA SHEET 18: SAFETY SYSTEM (BUS)




MODEL YEAR '98 CIRCUITRY DATA SHEETS

| | Page |
|--|------|
| DATA SHEET 3: INSTRUMENTS | 133 |
| DATA SHEET 4: VISUAL INDICATORS VISUAL INDICATORS -- IVECO CONTROL | 135 |
| DATA SHEET 5: EXTERIOR LIGHTING (Tail and side lights, cab instrumentation) | 137 |
| DATA SHEET 7: DIRECTION INDICATORS AND EMERGENCY LIGHTS | 139 |
| DATA SHEET 8: STOP, REVERSING AND REAR FOG LIGHTS | 141 |
| DATA SHEET 10: ELECTRICAL WINDSHIELD DEMISTER/HORNS | 143 |
| DATA SHEET 22: CONNECTION VARIANT FOR BO-FROST VEHICLES | 145 |


DATA SHEET 3: INSTRUMENTS




DATA SHEET 3: INSTRUMENTS




DATA SHEET 4: VISUAL INDICATORS



DATA SHEET 4: VISUAL INDICATORS - IVECO CONTROL




DATA SHEET 5: EXTERIOR LIGHTING (Tail and side lights, cab instrumentation)




* 4x4

DATA SHEET 7: DIRECTION INDICATORS AND EMERGENCY LIGHTS




DATA SHEET 8: STOP, REVERSING AND REAR FOG LIGHTS




- 0000 10
- 0000 25
- 0000 30
- 0000 31
- 0000 32
- 0000 33
- 0000 34
- 0000 35
- 0000 36
- 0000 37
- 0000 38
- 0000 39
- 0000 40
- 0000 41
- 0000 42
- 0000 43
- 0000 44
- 0000 45
- 0000 46
- 0000 47
- 0000 48
- 0000 49
- 0000 50
- 0000 51
- 0000 52
- 0000 53
- 0000 54
- 0000 55
- 0000 56
- 0000 57
- 0000 58
- 0000 59
- 0000 60
- 0000 61
- 0000 62
- 0000 63
- 0000 64
- 0000 65
- 0000 66
- 0000 67
- 0000 68
- 0000 69
- 0000 70
- 0000 71
- 0000 72
- 0000 73
- 0000 74
- 0000 75
- 0000 76
- 0000 77
- 0000 78
- 0000 79
- 0000 80
- 0000 81
- 0000 82
- 0000 83
- 0000 84
- 0000 85
- 0000 86
- 0000 87
- 0000 88
- 0000 89
- 0000 90
- 0000 91
- 0000 92
- 0000 93
- 0000 94
- 0000 95
- 0000 96
- 0000 97
- 0000 98
- 0000 99
- 0000 100


DATA SHEET 8: STOP, REVERSING AND REAR FOG LIGHTS



DATA SHEET 10: ELECTRICAL WINDSHIELD DEMISTER/HORNS



DATA SHEET 22: CONNECTION VARIANT FOR BO-FROST VEHICLES



52302

25402

61002

70055

25202

61002

70051

25213

1187

52307


03000

52502

20000

25900

DATA SHEET 22: CONNECTION VARIANT FOR BO-FROST VEHICLES



CROSS-REFERENCES**A**

A connector (Bus), 41

Abbreviations and graphic symbols used in this manual, IX

B

B connector, 42

Basic structure of power network, 5

Bonnet cable, 12

C

C connector, 43

Cab – ceiling – door cables, 14

Cables for safety device (BUS), 18

Cables for the rotary-sliding door opening system (BUS), 17

Cables on the vehicle, 7

Central Interconnection Unit, 37

Circuitry data sheets, 57

Code of components for circuitry data sheets Nos. 16 – 17 – 19, X

Colour coding of cables not supplied by IVECO, X

Connectors between cables, 19

D

D connector (Bus), 44

Data sheet 1: Starting/Recharge (BUS), 63

Data sheet 1: Starting/Recharge, 61

Data sheet 2: Pre-heating (BUS), 69

Data sheet 2: Pre-heating (DAILY), 65

Data sheet 2: Pre-heating (TURBODAILY, TURBODAILY 4x4), 65

Data sheet 3: Instruments, 71

Data sheet 4: Visual indicators – IVECO Control, 75

Data sheet 4: Visual indicators, 73

Data sheet 5: Exterior lighting (Tail and side lights, cab instrumentation), 77

Data sheet 6: Country and traffic beam, 79

Data sheet 7: Direction indicators and emergency lights, 81

Data sheet 8: Stop, reversing and rear fog lights, 83

Data sheet 9: Windshield wipers, 85

Data sheet 10: Electrical windshield demister/horns, 87

Data sheet 11: Interior lighting (BUS), 91

Data sheet 11: Interior lighting, 89

Data sheet 12: All Wheel Drive (TURBODAILY 4x4), 93

Data sheet 13: Exterior rear-view mirrors / window winder, 95

Data sheet 14: ABS, 97

Data sheet 15: TELMA retarder (BUS), 99

Data sheet 16: Rotary-sliding door (DAILY CITY TURBODAILY CITY), 101

Data sheet 17: Centralised door lock, 105

Data sheet 18: Safety system (BUS), 107

Data sheet 19: Air conditioning, 109

Data sheet 20: Automatic clutch, 111

Data sheet 21: Rear differential lock, 113

E

E connector, 45

Engine cable, 11

F

F connector, 46

F connector (Bus), 47

Frame cable, 13

G

G connector, 48

G connector (Bus), 49

General, 1

H

H connector, 50

I

I connector, 51

I connector (Bus), 52

Introduction, VII, IX

J

- Junction between cab cable and bonnet cable, 21, 22
- Junctions between ACS bonnet cable and ACS frame cable (XLVI – XLVII), ACS bonnet cable and ACS power supply cable (XLVIII), 35
- Junctions between bonnet cable and engine cable, 19
- Junctions between bonnet cable and fog lights cable (XXV), cab cable and bonnet cable (XXVI), 27
- Junctions between bonnet cable and frame cable, 20
- Junctions between cab cable and ACS automatic clutch cab cable (XII/A – XII/B), frame bonnet cables and ACS bonnet cable (XX/A – XX/B), 33
- Junctions between cab cable and ACS cab cable (XLI – XLV), ACS cab cable and bonnet cable (XLII – XLIII – XLIV), 34
- Junctions between cab cable and bonnet cable (XXXIV), cab cable and roof cable (XXXV – XXXVI), 31
- Junctions between cab cable and cable for speedometer with electronic adapter (XXXI), cab cable and headlight washer cable (XXXII), frame cable and cable for heated fuel filter (XXXIII), 30
- Junctions between cab cable and door cable (X – XII), cab cable and roof cable (XI), frame cable and side clearance lights cable (XIII), 23
- Junctions between cab cable and rotary-sliding door cable (XXXVII), cab cable and frame cable for Telma retarder (XXXVIII – XXXIX – XL), 32
- Junctions between cab cable and: ABS cable (XVII), window winder/adjustable mirrors cable (XVIII), electronic speedometer cable (XIX) – Junction between bonnet cable and electronic speedometer transmitter cable (XX), 25
- Junctions between door cables and window winder / adjustable mirrors cable, 28
- Junctions between frame cable and ACS frame cable (XLIX), engine cable and ACS frame cable (L), ACS bonnet cable and EDC cable (LI – LII), 36
- Junctions in ABS cable and Telma retarder cable (XXIX/A – XXIX/B), ABS cable and ABS sensor cable (XXX), 29
- Junctions in bonnet cable for IVECO Control, 26
- Junctions in cab cable for right hand side vehicles (XIV – XV – XV/A) and for daily lights variant (XVI), 24

K

- K connector and power terminal, 53

L

- L and M connectors, 54
- L and M connectors (Bus), 55
- Location of grounding points, 6

M

- Main components on frame structure, 3
- Main components on gearbox and engine, 4
- Model Year '98 circuitry data sheets, 131
- Data Sheet 3 : Instruments, 133
- Data sheet 4 : Visual indicators, Visual indicators IVECOControl, 135
- Data sheet 5 : Exterior lighting (Tail and side lights, cab instrumentation), 137
- Data sheet 7 : Direction indicators and emergency lights, 139
- Data sheet 8 : Stop, reversing and rear fog lights, 141
- Data sheet 10 : Electrical windshield demister/horns, 143
- Data sheet 22 : Connection variant for bo-frost vehicles, 145

O

- Operational Wiring Diagrams, 115

P

- Power cables (BUS), 15
- Power cables, 10
- Power network wiring, 5
- Premise, 3

R

- Reading keys, 9, 59
- Roof cable (BUS), 16

U

- UCI connectors, 40
- Ultrasonic welds on the cables, 6

W

- Warnings, IX